




KE2 Low Temp+Defrost (pn 20903)
Quick Start Guide

This reference should remain on site with the installed KE2 Low Temp + Defrost controller.



KE2 Low Temp + Defrost	
Variables Menu - Non-Adjustable (view only)	
HP	Room temperature
CR	Cold temperature
HT	Room temperature is displayed
CT1	Cold temperature is displayed
DP	Digital input 1
HT	Room temperature is displayed
CT2	Cold temperature is displayed
DP2	Digital input 2
SP1	System status
CP1	Compressor status
DF1	Defrost relay
FE1	Fan relay
AL1	Alarm status
Alarms Menu - Non-Adjustable (view only)	
AL1	No Alarm
AL2	No Alarm
AL3	No Alarm
AL4	No Alarm
AL5	No Alarm
AL6	No Alarm
AL7	No Alarm
AL8	No Alarm
AL9	No Alarm
AL10	No Alarm
AL11	No Alarm
AL12	No Alarm
AL13	No Alarm
AL14	No Alarm
AL15	No Alarm
AL16	No Alarm
AL17	No Alarm
AL18	No Alarm
AL19	No Alarm
AL20	No Alarm
AL21	No Alarm
AL22	No Alarm
AL23	No Alarm
AL24	No Alarm
AL25	No Alarm
AL26	No Alarm
AL27	No Alarm
AL28	No Alarm
AL29	No Alarm
AL30	No Alarm
AL31	No Alarm
AL32	No Alarm
AL33	No Alarm
AL34	No Alarm
AL35	No Alarm
AL36	No Alarm
AL37	No Alarm
AL38	No Alarm
AL39	No Alarm
AL40	No Alarm
AL41	No Alarm
AL42	No Alarm
AL43	No Alarm
AL44	No Alarm
AL45	No Alarm
AL46	No Alarm
AL47	No Alarm
AL48	No Alarm
AL49	No Alarm
AL50	No Alarm
AL51	No Alarm
AL52	No Alarm
AL53	No Alarm
AL54	No Alarm
AL55	No Alarm
AL56	No Alarm
AL57	No Alarm
AL58	No Alarm
AL59	No Alarm
AL60	No Alarm
AL61	No Alarm
AL62	No Alarm
AL63	No Alarm
AL64	No Alarm
AL65	No Alarm
AL66	No Alarm
AL67	No Alarm
AL68	No Alarm
AL69	No Alarm
AL70	No Alarm
AL71	No Alarm
AL72	No Alarm
AL73	No Alarm
AL74	No Alarm
AL75	No Alarm
AL76	No Alarm
AL77	No Alarm
AL78	No Alarm
AL79	No Alarm
AL80	No Alarm
AL81	No Alarm
AL82	No Alarm
AL83	No Alarm
AL84	No Alarm
AL85	No Alarm
AL86	No Alarm
AL87	No Alarm
AL88	No Alarm
AL89	No Alarm
AL90	No Alarm
AL91	No Alarm
AL92	No Alarm
AL93	No Alarm
AL94	No Alarm
AL95	No Alarm
AL96	No Alarm
AL97	No Alarm
AL98	No Alarm
AL99	No Alarm
AL100	No Alarm
Basic Setpoints Menu	
SP	Temperature Setpoint
CP	Compressor Start/Stop
DF	Defrost Start/Stop
FE	Fan Start/Stop
AL	Alarm Start/Stop
AL1	Start time of Alarm 1
AL2	Start time of Alarm 2
AL3	Start time of Alarm 3
AL4	Start time of Alarm 4
AL5	Start time of Alarm 5
AL6	Start time of Alarm 6
AL7	Start time of Alarm 7
AL8	Start time of Alarm 8
AL9	Start time of Alarm 9
AL10	Start time of Alarm 10
AL11	Start time of Alarm 11
AL12	Start time of Alarm 12
AL13	Start time of Alarm 13
AL14	Start time of Alarm 14
AL15	Start time of Alarm 15
AL16	Start time of Alarm 16
AL17	Start time of Alarm 17
AL18	Start time of Alarm 18
AL19	Start time of Alarm 19
AL20	Start time of Alarm 20
AL21	Start time of Alarm 21
AL22	Start time of Alarm 22
AL23	Start time of Alarm 23
AL24	Start time of Alarm 24
AL25	Start time of Alarm 25
AL26	Start time of Alarm 26
AL27	Start time of Alarm 27
AL28	Start time of Alarm 28
AL29	Start time of Alarm 29
AL30	Start time of Alarm 30
AL31	Start time of Alarm 31
AL32	Start time of Alarm 32
AL33	Start time of Alarm 33
AL34	Start time of Alarm 34
AL35	Start time of Alarm 35
AL36	Start time of Alarm 36
AL37	Start time of Alarm 37
AL38	Start time of Alarm 38
AL39	Start time of Alarm 39
AL40	Start time of Alarm 40
AL41	Start time of Alarm 41
AL42	Start time of Alarm 42
AL43	Start time of Alarm 43
AL44	Start time of Alarm 44
AL45	Start time of Alarm 45
AL46	Start time of Alarm 46
AL47	Start time of Alarm 47
AL48	Start time of Alarm 48
AL49	Start time of Alarm 49
AL50	Start time of Alarm 50
AL51	Start time of Alarm 51
AL52	Start time of Alarm 52
AL53	Start time of Alarm 53
AL54	Start time of Alarm 54
AL55	Start time of Alarm 55
AL56	Start time of Alarm 56
AL57	Start time of Alarm 57
AL58	Start time of Alarm 58
AL59	Start time of Alarm 59
AL60	Start time of Alarm 60
AL61	Start time of Alarm 61
AL62	Start time of Alarm 62
AL63	Start time of Alarm 63
AL64	Start time of Alarm 64
AL65	Start time of Alarm 65
AL66	Start time of Alarm 66
AL67	Start time of Alarm 67
AL68	Start time of Alarm 68
AL69	Start time of Alarm 69
AL70	Start time of Alarm 70
AL71	Start time of Alarm 71
AL72	Start time of Alarm 72
AL73	Start time of Alarm 73
AL74	Start time of Alarm 74
AL75	Start time of Alarm 75
AL76	Start time of Alarm 76
AL77	Start time of Alarm 77
AL78	Start time of Alarm 78
AL79	Start time of Alarm 79
AL80	Start time of Alarm 80
AL81	Start time of Alarm 81
AL82	Start time of Alarm 82
AL83	Start time of Alarm 83
AL84	Start time of Alarm 84
AL85	Start time of Alarm 85
AL86	Start time of Alarm 86
AL87	Start time of Alarm 87
AL88	Start time of Alarm 88
AL89	Start time of Alarm 89
AL90	Start time of Alarm 90
AL91	Start time of Alarm 91
AL92	Start time of Alarm 92
AL93	Start time of Alarm 93
AL94	Start time of Alarm 94
AL95	Start time of Alarm 95
AL96	Start time of Alarm 96
AL97	Start time of Alarm 97
AL98	Start time of Alarm 98
AL99	Start time of Alarm 99
AL100	Start time of Alarm 100

Parts List

The following parts are included in the KE2 Low Temp controller kits:

■ **Kit # 20903 with 120/208-240 VAC controller**

- A** (1) KE2 Low Temp controller
- B** (1) high voltage safety shield
- C** (2) temperature sensors
- D** (6) 90° spade connectors
- E** (2) straight spade connectors
- F** (5) self-tapping screws
- G** (1) 1/2" plastic knockout plug
- H** (1) air sensor mount
- I** (3) course thread screws
- J** (1) controller programming sticker
- (1) **Warranty card** (not shown)

Supplies List

The KE2 Low Temp is supplied with all of the accessories required for the controller to work, however, standard truck stock items will also be required to install the controller. To simplify the installation, a list of items has been provided.

- **Conduit to go between the controller and the evaporator**
- **(2) Conduit connectors** (straight or elbow as required)
- **(8) High voltage wires matched to the load of the heaters, fans, liquid line solenoid, and the controller.**
- **(8) Spade Connectors matched to the gauge of high voltage wires**
- **Wire labeling** (numbers, colors, etc.)
- **Wire ties**
- **18 gauge twisted shielded pair** (if extending sensor wires)
- **Foam insulation if running wires outside the space.**
- **Silicone** (for sealing any box penetrations)

Accessories to Aid in Installation

The following parts are available separately:
(1) 25' Wire Harness pn 20670 or **40' Wire Harness** pn 20737
(1) KE2 Terminal Board* pn 20996
 Further information on the Wire Harness can be found in literature Q.1.21, and for the KE2 Terminal Board in Q.1.30.

* When used with the KE2 Low Temp controller, the fuses must be sized to match the application (i.e. Replace existing fuses with 30 Amp Time Delay fuses for fans and compressor)



KE2 LowTemp Quick Start Guide

Arriving at the Jobsite

When arriving at any jobsite, it is good practice to verify the correct operation of the system. Even systems running for a considerable amount of time without requiring a service call may not be running properly.

Inspect the coil to see the current frost pattern. If the unit has not recently performed a defrost, look for the heaviest area of frost. This will be used to locate the coil sensor.

Installers should account for a full system diagnostic in the installation estimate for the controller.

Although it may seem unnecessary, identifying system issues before the controller is installed will save time overall. It will also allow the controller to provide the highest energy savings.

Verify the system is running correctly. Taking several measurements will help determine the current health of the system. Using the diagram below, fill in the necessary information.

Two of the most critical indicators of system health are the superheat and subcooling.

Superheat - Superheat is the most overlooked inefficiency in existing systems. Typically the superheat on a TEV is set when there is not product in the controlled space, if it is set at all.

When applying the controller to an existing system with a mechanical expansion valve, the superheat should be between 6-8 degrees

for low temperature applications and 8-10 degrees for medium temperature.

Subcooling - There should be a solid column of liquid at the inlet of the valve. This can be verified by looking at the sight glass, however, the proper method requires measuring the subcooling of the liquid entering the valve.

Verify Temperature Difference

A typical Temperature Difference (TD) between the coil temperature and the air temperature is between 5 and 15°F. An insufficient TD, between the coil and air temperature, indicates a system issue that needs to be addressed before installing the KE2 Low Temp.

Understanding Frost

The air exiting side of the evaporator is often the coldest spot on the coil. As air travels through the fins of the evaporator, the Relative Humidity will reach 100%. Moisture will begin to drop out of the air and deposit on the coil surfaces to form frost. Although frost typically has a negative connotation when discussed in refrigeration, initial frost formation has a positive effect. Some may even say "frost is our friend." It is not uncommon to see a small amount of frost on the coils that have KE2 Low Temp controllers installed. The KE2 Low Temp is continually measuring, monitoring, and managing the frost to assist in maximum energy efficiency. When the efficiency of the coil is reduced due to excessive frost, the KE2 Low Temp will initiate a defrost.

Trouble Shooting Diagram

Refrigerant _____

Suction Pressure _____ PSI


Suction Temp (evaporator outlet) _____ °F

Saturation Temp (calculated from Suct. Pressure) _____ °F

Superheat _____ °

Discharge Pressure _____ PSI

AMPS _____







KE2 LowTemp Quick Start Guide

IMPORTANT Preliminary Steps Determine the coil sensor location

- A** To determine the most appropriate sensor location, when arriving on site, put the system into defrost.
- B** The location where frost is last to disappear is where the coil sensor should be placed. Monitor both the air entering side, as well as the air exiting side, of the evaporator coil. Don't be surprised if the last place for frost to disappear is on the air exiting side. It is usually near the right or left end of the coil.

 It is important to verify all heating elements are working properly.




Steps to Ensure Proper Coil Sensor Location

- C** KE2 Therm recommends locating the coil sensor as described above. Typically the coldest spot is on the side of the suction header/expansion valve side of the evaporator. Select two places that are the last to defrost, preferably at each end of the evaporator.

More often than not on coils, the location of the sensor is a short distance from the end, approximately 1 to 1-1/2" away from the right and left edges of the active coil surface. The ice tends to grow from these edges towards the center. Therefore, the sensor location is best situated approximately 1 to 1-1/2" from the outer edges and typically near the bottom 1/3rd portion of the evaporator. The sensor needs to be as far away from the defrost heat sources as possible.

Note: Insert plug (Item G from parts list) into coil housing when mounting sensor wire to prevent damage to the sensor from sharp edges. The plug provided should be inserted into the inner housing to access the coil. Installer must puncture plug to insert sensor.



- D** Make note of the location you have determined for placement of the coil sensors.




KE2 LowTemp Quick Start Guide

1 Determining Location


■ The controller is designed to be as versatile as possible. The location should be discussed with the end users to determine if they have a preference. It is designed so it can be installed inside or outside the controlled space.

■ The controller can also be located at the condenser, but should not be installed outdoors without an enclosure to protect it from sunlight and moisture (must be within operating range -40°F to 120°F)




1

On the evaporator



On the wall



At the entrance



2 Cut a length of conduit to go from the controller to the evaporator


■ Measure the distance between the controller and evaporator to account for the extra length necessary to properly route conduit.

Determine the number of wires to go to the controller.

- Controller power (2 wires)
- Fan control (2 wires)
- Defrost (heater) control (2 wires)
- Liquid line solenoid (2 wires)

Note: Install in accordance with local wiring codes. KE2 Therm does not accept responsibility for incorrect or unsafe wiring.

2




3 Cut wires to length

■ Once the number of wire is determined, cut the wires to length.

■ The wire should be long enough to account for the necessary connections in the controller and evaporator.


■ Using different colored wires, (blue - fan, orange - heaters, yellow - solenoid) will simplify the installation and troubleshooting. If only a single color is available, both ends of the wires should be labeled with matching numbers. This will save time when wiring the evaporator.

3



Determine the current draw of the unit.

- 4** ■ Use the nameplate to determine the Amp rating of the unit. This information should be used to select the proper sized wire. It should also be used to verify the unit does not exceed the relay rating on the KE2 Low Temp controller.




Preparing conduit

- 5** ■ Feed the wires through the conduit.
- The conduit connectors can be added at this time. Determine if a straight or 90 degree connector is most appropriate for the installation, and attach to the conduit.
 - Securely connect one end of the conduit to the controller.




Wiring the controller

- 6** ■ Locate the Voltage Selector Switch.
- It is a 2 position switch with red indicator.
 - The selected voltage will be displayed on the face of the switch
- !** The controller will still illuminate the display when 115V is applied with 208-240V selected, however the controller may not function properly. If 208-240V is applied with 115V selected the controller's display will cycle rapidly.




115V



208-240V

Controller Power


- 7** ■ Strip the end of the wires used to provide power to the controller
- Crimp on female spade connectors (Item E from list on page 1)
 - Plug into the board as indicated in Wiring Schematic.
- Note:** All terminals should be crimped to withstand 30lb pull test.



Liquid Line Solenoid /Compressor Relay

- 8** ■ Strip the end of the 2 wires used for the liquid line solenoid.
■ Locate 2 90° female spade connectors in the accessories kit.
■ Crimp on the female connectors.
■ Plug the connectors to the COM and NO positions of the Liquid Line Solenoid /Compressor Relay


Confirm compressor load is not over 30 FLA.



Defrost (Heater) Relay

- 9** ■ Strip the end of the 2 wires used for the defrost control.
■ Locate 2 additional 90° female spade connectors in the accessories kit.
■ Crimp on the female connectors.
■ Plug the connectors to the COM and NO positions of the Defrost Relay.


Confirm combined heater load is not over 30 amps.



Fan Relay

- 10** ■ Strip the end of the 2 wires used for fan control.
■ Locate 2 90° female spade connectors in the accessories kit.
■ Crimp on the female spade connectors.
■ Plug the connectors to the COM and NO positions of the Fan Relay.

Confirm combined fan motor load is not over 30 FLA.



Install Safety cover

- 11** ■ Once all of the high voltage wiring is complete, install the plastic cover on the controller.
- Locate the cover and 3 small screws from the accessories kit.
 - Position the cover over the 3 mounting posts.
 - Using the 3 small coarsely threaded screws attach the controller to the plastic posts.

Connecting sensor wires to controller

- The temperature sensors are designed to be attached to the controller using 2 position screw terminals. The terminals are located on the controller's lid, on the bottom side of the display.
- Connect all sensors to the appropriate locations, which can be determined from the label on the circuit board or from the Wiring Schematic.
- The sensors are not polarized, so wire location does not effect sensor performance.

Set the controller in a safe place.




Preparing the Evaporator

- 12** ■ The evaporator wiring will require access to the high voltage terminal block on the coil.
- Turn off power to the system.
 - Verify power is no longer present using a multimeter.



Evaporator wiring

- 13** ■ Now that the conduit is prepared, it can be connected to the evaporator.
- Locate the proper sized knockout and carefully remove knockout.
 - Connect conduit to the evaporator




Existing wiring.

- 14** ■ Start by removing all of the existing wires from the terminal strip.
- Determine the location of the following: incoming power, fan leads, heater leads, defrost termination leads, and fan delay leads.


Evaporator wiring – Controller

- 15** ■ Strip the end of the wires used to power the controller.
- Attach to the line power to provide continuous power to the controller.



Evaporator wiring – Fans

- 16** ■ Strip the ends of the wires (connected to the KE2 Low Temp) used to control the evaporator fans.
- The fan wires from the controller can be attached to the terminal block using either screw down terminals or spade connectors.
- Attach the **black wire with blue stripes to the L1/Line**. This wire will be connected to COM of fan relay on the controller.
- Attach **blue wire with black stripes to the NO terminal** on the Fan Relay to one set of the fan leads. This wire will be connected to the NO of the fan relay on the controller.
- Connect L2/Neutral to remaining fan leads.




Evaporator wiring – Heater

- 17** ■ Strip the ends of the wires being used for heater control.
- The heater wires can be attached to the terminal block using either screw down terminals or spade connectors.

Remove defrost termination (Klixon®) from circuitry

- 18** ■ Attach the **black wire with orange stripe to the L1/Line**. This wire will be connected to COM of defrost relay on the controller.
- Attach the **orange wire with the black stripe to the NO** terminal on the Defrost Relay to one of each of the defrost leads.
- Connect L2/Neutral to the remaining defrost leads.

! The defrost safety should not be removed from the circuit. Its purpose is to prevent the heaters from over heating and causing damage.



Evaporator wiring – Liquid Line Solenoid /Compressor

- 19** ■ Strip the ends selected to control the liquid line solenoid.
- Attach the **black wire with the yellow stripe to the L1**. This wire will be connected to the COM of the L.L. Solenoid/Compressor.
- Attach the **yellow wire with black stripe connects to the NO** terminal on the L.L. Solenoid/Compressor relay to a solenoid lead
- Connect L2/Neutral to the remaining L.L. Solenoid/Compressor lead.




Figure 8 - Wiring Schematic - Ladder Diagram





Figure 8 - Wiring Schematic - Using KE2 Terminal Board






KE2 LowTemp Quick Start Guide


Installing the sensors

- 20** ■ Although not required, sensors should be labeled with their function. This will eliminate confusion when connecting the sensors to the controller.



Air Sensor Bracket

- 21** ■ Install the Air Temperature Sensor using the Stainless Steel self-piercing screw and bracket from the accessory kit.
- The end with the single loop is designed to be mounted with the screw included.
 - The end with multiple loops is designed to hold the sensor.
 - Locate the best place to install the sensor.
 - The sensor should be located between 6 and 12 inches away from the face of the evaporator. This distance prevents the sensor from sensing heat from the heating elements during the defrost cycle, but close enough to accurately sense the return air temperature.
 - The sensor bracket may be bent as necessary to locate the sensor in the proper position.



WARNING!

Do not allow the metal portion of the air sensor to touch anything other than air. It should not touch the bracket, nylon cable tie, or any other solid surface.


Coil Sensor

■ The coil sensor location is of the utmost importance for the proper operation of the controller. It is essential that the sensor is in the coldest location on the coil at the end of the defrost cycle, to ensure a complete defrost. See preliminary steps A-D on page 3 to determine the coldest location on the coil.


Once you have determined the proper sensor location as described in preliminary steps A-D on page 3, the sensor can be installed.

Installing the Sensor Properly

22 It is important to note, the most active portion of the sensor is the first 1/2" of the 1-1/2" long stainless steel probe.



23 As a result, it is important to touch two circuit tubes. When inserting the sensor into the coil, the tip should touch one of the circuit tubes. This location provides an appropriate location for the sensor.




24 Insert the probe into the fins approximately 1/16" deeper than the stainless shielding of the probe. Pinch the two fins gently together to secure the sensor in place. This provides the thermal ballast to ensure a complete defrost every time.

⚠ Extending sensor wires

■ After the sensors are mounted, they are routed back to the controller. If the wires must be extended use **18 gauge twisted shielded pair**. Maximum length for 18 gauge: 100ft.


■ When running the wires back to the controller care must be taken to avoid interference being introduced into the sensor wires. Interference can be introduced when sensor wires are located near high voltage lines. High voltage is defined by Underwriter's Laboratories as being above 30V. The higher the voltage the more likely it is to introduce interference and the more important to avoid.

■ If crossing a high voltage line is necessary, the sensor wiring should be run at right angles to prevent noise.



Setting the dip switch to activate on board buzzer

- 25** ■ To disable the audible alarm buzzer feature of the KE2 Low Temp the dip switch must be switched to OFF (default from the factory is ON)
- The red dip switch is located at the bottom of the controller, and is equipped with a switch that indicates ON or OFF.
 - By selecting OFF, the buzzer will be in an inactive state, and will not sound when any type of alarm occurs.



Buzzer dip switch

Controller Mounting

- 26** ■ Locate the 4 stainless steel screws in the accessories kit
- Install the 4 screws
 - Place the controller on the mounting screws and tighten down the screws.



Final Step

- 27** ■ Leave these installation instructions onsite in a convenient location, where it can be easily located, for future service.

Controller Navigation - Menu Structure




Indicator lights

- **Red light** - Basic Menu - not used; Advanced Menu - pulsing
- **Yellow light** - non-critical alarm (system running)
- **Green light** - compressor on
- **Green flashing** - compressor waiting on timer to start/stop

- Access Setpoint mode by pressing and holding the **ENTER** button until tS (temperature setpoint) displays on the screen
- Use the **▲** up and **▼** down arrows to scroll through the available setpoints.
- Press **ENTER** to view the current setting.
- Use the **▲** up and **▼** to change the setpoint
Press **ENTER** to move between the digits to accelerate the changes.
- Press **ENTER** and hold to confirm each setpoint change
- Press **BACK** to escape.

Accessing the Menus





KE2 LowTemp Quick Start Guide

Specifications

Controller					
Input Voltage:	120V / 208-240V				
Storage Temp:	-13° to 120°F (-25° to 49°C)				
Operating Temp:	-40° to 120°F (-40° to 49°C)				
Display:	4 digit 7-segment LED				
IP Rating:	IP65				
Inputs (4):	2 temperature sensors (KE2 SKU 20199) 2 dual purpose temperature or digital inputs				
Outputs: (3) Relays Single Pole Double Throw		Normally Open		Normally Closed	
		120V	240V	120V	240V
	FLA	30A	30A	N/A	12A
	LRA	98A	80A	N/A	24A
	Resistive	N/A	30A	N/A	30A
	Horsepower	1 hp	2 hp	1/4 hp	1/2 hp
	Pilot Duty	800VA	720VA	290VA	360VA
Communication:	RS-485 (Modbus)				
Temperature Sensor					
Sensor Specs:	-60° to 150°F (-51°C to 66°C) moisture resistant package				

User Interface

The KE2 Low temp's onboard user interface uses the familiar 4- button arrangement to simplify navigation through the controller's menus.

To provide the most pleasant user experience, the menu structure has been split into 2 groups: Basic and Advanced.

Basic Menu

For the majority of users, the Basic menu will provide the necessary parameters to setup the controller.

The Table – Basic Menu provides a listing of the abbreviations for the controller.

Advanced Menu

Some users will require more complex configurations to achieve the desired product performance. These more in depth applications require additional parameters found under the Advanced Menu.

Due to the vast number of potential configurations, users must investigate the proper setup independently of these instructions.

The Table – Advanced Menu provides a listing of the abbreviations and descriptions of available options. For a more in depth description of each parameter contact your KE2 Therm Sales Engineer.

Navigating Setpoints

To move between the setpoint displayed and its associated value, requires a momentary press of the Enter button. To return to the value press the BACK button.

Manual Defrost

To enter Manual Defrost mode, press and hold the BACK and the ENTER buttons simultaneously for three seconds. dEFr will appear on the display.



Changing Setpoints

When the parameter value is displayed it may be changed by using the Up, Down, and ENTER buttons.

The Up and down buttons will increase or decrease numerical values and scroll through the available options on the non-numerical options.

Pressing and holding the ENTER button for 3 seconds will save the displayed value.

To abort changes pressing the BACK button will return the parameter abbreviation.

Advanced Defrost Heater Management:

The KE2 Low Temp incorporates heater management to reduce fogging associated with excessive defrost heat.

To activate this feature:

- Press the UP button and the DOWN button simultaneously, then, after a minimum of 0.2 seconds press the BACK button, the red LED will toggle either on or off.
- The display will go blank
- When the buttons are released, the display will go back to displaying set point that it was displaying before the button combo was pressed.



KE2 LowTemp

Quick Start Guide

Table 3 - Controller Menus and Menu Parameters

Alarms Non Adjustable (view only)

When the KE2 Low Temp is in alarm, it notifies the user by illuminating the amber LED, and displaying the appropriate Alarm Code:

Alarm Code	Alarm Name	Description
nOAL	No Alarm	
AtSA	Air Sensor	Return air temperature sensor is shorted or open
CLSA	Coil Sensor	Coil temperature sensor is shorted or open
AU1A	Auxiliary Input 1 Alarm	Auxiliary temperature sensor is shorted or open
AU2A	Auxiliary Input 2 Alarm	Auxiliary temperature sensor is shorted or open
HtA	High Temperature Alarm	Temperature is above temperature setpoint (tS) + temperature differential (diF) + high temp alarm offset (HAO) for longer than temperature alarm delay (tAd)
LtA	Low Temperature Alarm	Temperature is below temperature setpoint (tS) - low temp alarm offset (LAO) for longer than temperature alarm delay (tAd)
dOOr	Door Open	If door is open and room temperature is 5 degrees above temperature setpoint (tS) + temperature differential (diF) and input stays active for 90 minutes, ignores temperature alarm delay (tAd)
PF	Power Failure	Indicates power has been off and just turned on (only when dPd = CUS)

Setpoints - Basic Menu

Setpoint	Description	Minimum	Default	Maximum	
tS	Temperature Setpoint	-50°F	-10°F	100°F	
diF	Differential	1°	5°	30°	
CSH	Maximum Compressor Starts/ Hour	5 (Off)*	6	10	
dtYP	Type of Defrost, Air or Electric	Air	Elec	Elec	
dPd	Defrost Per Day	0	4	12, CUS	
Only visible if CUS(custom) is selected for dPd (Defrost per day)	tOd	Time of day	0:00	12:00	23:59
	d1	Start time of Defrost #1	0:00, diS	diS	23:59
	d2	Start time of Defrost #2	0:00, diS	diS	23:59
	d3	Start time of Defrost #3	0:00, diS	diS	23:59
	d4	Start time of Defrost #4	0:00, diS	diS	23:59
	d5	Start time of Defrost #5	0:00, diS	diS	23:59
	d6	Start time of Defrost #6	0:00, diS	diS	23:59
	d7	Start time of Defrost #7	0:00, diS	diS	23:59
	d8	Start time of Defrost #8	0:00, diS	diS	23:59
	d9	Start time of Defrost #9	0:00, diS	diS	23:59
	d10	Start time of Defrost #10	0:00, diS	diS	23:59
	d11	Start time of Defrost #11	0:00, diS	diS	23:59
d12	Start time of Defrost #12	0:00, diS	diS	23:59	
dtSP	Defrost Term Temperature Setpoint	35	50 if Elec; diSA if Air	90	
dFt	Defrost Time	0 min	30 min	720 min	
drnt	Drain Time	0 min	2 min	15 min	
Fndf	Fan State During Defrost	OFF	OFF if Elec; On if Air	On	
HAO	High Alarm Offset	0°	10°	50°	
LAO	Low Alarm Offset	0°	4°	10°	
tAd	Temp Alarm Delay	1 min	90 min	180 min	



KE2 LowTemp Quick Start Guide

Setpoints - Advanced Menu - hold back button for 3 seconds to access Advanced Setpoint Mode

Setpoint	Description	Minimum	Default	Maximum	
tS	Temperature Setpoint	-50°F	-10°F	100°F	
diF	Differential	1°	5°	30°	
CSH	Maximum Compressor Starts/Hour	5 (Off)*	6	10	
FrEF	Fan mode during refrigeration mode - ti24, OnCP, PErn	PErn	OnCP	ti24	
AU1	Type of 1st Auxiliary input - diS, SYOF, dOOr, t2nd, dFin, dFLo, inid, trdF, COiL, rtP		diS		
StA1	Digital input active state for 1st Aux input	OPEn	SHrt	SHrt	
AU2	Type of 2nd Auxiliary input - diS, SYOF, dOOr, t2nd, dFin, dFLo, inid, trdF, COiL, rtP		diS		
StA2	Digital input active state for 2nd Aux input	OPEn	SHrt	SHrt	
tS2	2nd room temp setpoint	-50	-50	100	
dtyP	Type of Defrost, Air or Electric	Air	Elec	Elec	
dPd	Defrost Per Day	0	4	12, CUS	
Only visible if CUS(custom) is selected for dPd (Defrost per day)	tOd	Time of day	0:00	12:00	23:59, diS
	d1	Start time of Defrost #1	0:00	diS	23:59, diS
	d2	Start time of Defrost #2	0:00	diS	23:59, diS
	d3	Start time of Defrost #3	0:00	diS	23:59, diS
	d4	Start time of Defrost #4	0:00	diS	23:59, diS
	d5	Start time of Defrost #5	0:00	diS	23:59, diS
	d6	Start time of Defrost #6	0:00	diS	23:59, diS
	d7	Start time of Defrost #7	0:00	diS	23:59, diS
	d8	Start time of Defrost #8	0:00	diS	23:59, diS
	d9	Start time of Defrost #9	0:00	diS	23:59, diS
	d10	Start time of Defrost #10	0:00	diS	23:59, diS
	d11	Start time of Defrost #11	0:00	diS	23:59, diS
d12	Start time of Defrost #12	0:00	diS	23:59, diS	
dtSP	Defrost Term Temperature Setpoint	35°F	50°F if Elec; diS if Air	90°F	
dFt	Defrost Time	0 min	30 min	720 min	
drnt	Drain Time	0 min	2 min	15 min	
FdSP	Fan delay temp	-40°F	20°F	35°F	
Fndt	Max fan delay time	0 min	2 min	20 min	
FndF	Fan State During Defrost	OFF	OFF if Elec; On if Air	On	
Pdt	Defrost pump down time	0 min	0 min	10 min	
HAO	High Alarm Offset	0°	10°	50°	
LAO	Low Alarm Offset	0°	4°	10°	
tAd	Temp Alarm Delay	1 min	90 min	180 min	
Adr	Modbus address	1	1	247	
Unt	Temp units FAH or CEL	FAH	FAH	CEL	

Variables Menu Non Adjustable (view only)

Parameter Name	Status Displayed on Controller	
rtP	Room temperature	
Ct	Coil temperature	
Only visible if AU1 is used	rt1 or Ct1 or din1	rt1 = room temperature is displayed ; Ct1 = coil temperature is displayed; din1 = digital input 1 (depending on the use of the digital input will display: SyOn (system on), SyOF (system off), drOn (door open), drCL (door closed), diOn (defrost interlock on), diOF (defrost interlock off), dLOC (defrost lockout), dAut (defrost auto), inid (initiate defrost), tErD (terminate defrost), t2OF (use main air setpoint), t2On (use second air setpoint)
	rt2 or Ct2 or din2	rt2 = room temperature is displayed ; Ct2 = coil temperature is displayed; din2 = digital input 2 (depending on the use of the digital input will display: SyOn (system on), SyOF (system off), drOn (door open), drCL (door closed), diOn (defrost interlock on), diOF (defrost interlock off), dLOC (defrost lockout), dAut (defrost auto), inid (initiate defrost), tErD (terminate defrost), t2OF (use main air setpoint), t2On (use second air setpoint)
	SySt	System state - dEFr (defrost), drAn (drain), FndL (fan delay), rEFr (refrigerate), OFF (system off)
	CPrl	Compressor relay
	dFrI	Defrost relay
	Fnrl	Fan relay
	ALSt	Alarm state - noAL (no alarm), AtSA (air sensor), CLSA (coil sensor), AU1A (aux input 1 alarm), AU2A (aux input 2 alarm), Hta (high temp alarm), LtA (low temp alarm), dOOr (door open), PF (power failure)



KE2 LowTemp Quick Start Guide

Abbreviations - Alphabetical Listing

Abbreviation	Name	Type	Description
Adr	Modbus Address	Setpoint	Controller's address for communications
Air	Air Defrost	Setpoint	Air Defrost option
ALSt	Alarm State	Variable	Pressing ENTER from ALSt will show alarm menu
AtSA	Air Sensor Alarm	Alarm	Displays when air sensor is shorted or open
AU1	Type of 1st Auxiliary input	Setpoint	dIS, SYOF, d00r, t2nd, dFin, dFLo, indF, trdF, COiL, rtP
AU1A	Auxiliary Input 1 Alarm	Alarm	Displays if type of 1st Auxiliary input (AU1) is set to coil (COIL) or room temp (t2nd) and sensor is shorted or open
AU2	Type of 2nd Auxiliary input	Setpoint	dIS, SYOF, d00r, t2nd, dFin, dFLo, indF, trdF, COiL, rtP
AU2A	Auxiliary Input 2 Alarm	Alarm	Displays if type of 2nd Auxiliary input (AU2) is set to coil (COIL) or room temp (t2nd) and sensor is shorted or open
CEL	Celsius	Setpoint	Option for temperature units
CLSA	Coil Sensor Alarm	Alarm	Displays when coil sensor is shorted or open
CLt	Coil Temp	Variable	Temperature of the coil
COiL	Coil	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - input is to be used as an additional Coil Temperature for defrost termination and fan delay termination
CPrL	Compressor Relay	Variable	Status of whether compressor relay is energized or de-energized
CSH	Compressor Starts/Hour	Setpoint	Maximum number of compressor starts per hour
Ct1	Coil Temperature 1	Variable	Coil temperature if AU1 (1st Auxiliary input) is set to Ct1
Ct2	Coil Temperature 2	Variable	Coil temperature if AU2 (2nd Auxiliary input) is set to Ct2
CUSt	Custom	Setpoint	Option under defrosts per day (dPd)
d1	Defrost #1	Setpoint	Start time of Defrost #1 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d2	Defrost #2	Setpoint	Start time of Defrost #2 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d3	Defrost #3	Setpoint	Start time of Defrost #3 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d4	Defrost #4	Setpoint	Start time of Defrost #4 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d5	Defrost #5	Setpoint	Start time of Defrost #5 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d6	Defrost #6	Setpoint	Start time of Defrost #6 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d7	Defrost #7	Setpoint	Start time of Defrost #7 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d8	Defrost #8	Setpoint	Start time of Defrost #8 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d9	Defrost #9	Setpoint	Start time of Defrost #9 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d10	Defrost #10	Setpoint	Start time of Defrost #10 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d11	Defrost #11	Setpoint	Start time of Defrost #11 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
d12	Defrost #12	Setpoint	Start time of Defrost #12 when in defrosts per day (dPd) is custom (CUSt); based on 24-hour clock
dAUt	Defrost Auto	Variable	Defrost is in Automatic mode, i.e. normal operation
dEFr	Defrost	System State	Displays when system is in defrost mode
dFin	Defrost Interlock	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - digital input that immediately turns off defrost heaters
dFLo	Defrost Lockout	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - digital input that prevents controller from going into defrost mode
dFt	Defrost Time	Setpoint	Maximum time system is allowed in defrost
dFrI	Defrost Relay	Variable	Status of whether defrost relay is energized or de-energized
diF	Differential	Setpoint	Number of degrees air temp must be above room temp setpoint (tS) to return system to refrigeration mode
din1	Digital Input 1	Variable	1st Auxiliary input (AU1) is configured as one of the digital input options
din2	Digital Input 2	Variable	2nd Auxiliary input (AU2) is configured as one of the digital input options
diOn	Defrost Inertock On	Variable	In variables menu, display when 1st or 2nd Auxiliary input (AU1 or AU2) set to dFin (Defrost Interlock) and is active
diOF	Defrost Interlock Off	Variable	In variables menu, display when 1st or 2nd Auxiliary input (AU1 or AU2) set to dFin (Defrost Interlock) and is inactive
dIS	Disabled	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2)- input is not in use
dLOc	Defrost Lockout	Variable	In variables menu, display when 1st or 2nd Auxiliary input (AU1 or AU2) set to dFLO (Defrost Lockout) and is active
d00r	Door Open Alarm	Alarm	If door is open and room temperature is 5 degrees above temperature setpoint (tS) + temperature differential (diF) and input stays active for 90 minutes, ignores temperature alarm delay (tAd)
	Door Input	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - is used to determine if the door is open or closed
dPd	Defrost Per Day	Setpoint	Number of defrosts per day 0-12, CUS (custom)
drAn	Drain	System State	Displays when system is in drain mode



KE2 LowTemp Quick Start Guide

Abbreviations - Alphabetical Listing (continued)

Abbreviation	Name	Type	Description
drCL	Door Closed	Variable	In Variables menu, display when AU1 and AU2 set to d00r and is inactive
drOn	Door Open	Variable	In Variables menu, display when AU1 and AU2 set to d00r and is active
drnt	Drain Time	Setpoint	Amount of time in drain mode
dtSP	Defrost Term Temperature Setpoint	Setpoint	Coil temperature reaches defrost term temperature setpoint to terminate defrost
dtYP	Type of Defrost	Setpoint	Air or Electric
ELEC	Electric	Setpoint	Defrost option
FAH	Fahrenheit	Setpoint	Default for all temperatures displayed
FdSP	Fan delay temp Setpoint	Setpoint	Coil temp must reach this setpoint to turn fans back on after defrost
FndF	Fan State During Defrost	Setpoint	Fans on or off during defrost
FndL	Fan Delay	System State	Displays when system is in fan delay mode
Fndt	Max fan delay time	Setpoint	Maximum time system can stay in fan delay (FndL) mode
FnrL	Fan Relay	Variable	Status of whether fan relay is energized or de-energized
FrEF	Fan mode during refrigeration	Setpoint	Fan on or cycling during refrigeration mode
HtA	High Temperature Alarm	Alarm	Average temperature is above the Temperature Setpoint (tS) + Temperature Differential Setpoint dif + High Alarm Offset (HAO) for the amount of time in the Temperature Alarm Delay (tAd)
HAO	High Alarm Offset	Setpoint	Number of degrees above the Temperature Setpoint (tS) for a High Temp Alarm (HtA) condition.
inid	Initiate Defrost	Variable	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - digital input that will initiate defrost
LAO	Low Alarm Offset	Setpoint	Number of degrees below the Temperature Setpoint (tS) for a Low Temp Alarm (LtA) condition.
LtA	Low Temperature Alarm	Alarm	Average temperature is below the Temperature Setpoint (tS) - Low Alarm Offset (LAO) for the amount of time in the Temperature Alarm Delay (tAd)
NOAL	No Alarm	Alarm	System is clear of alarms
OFF	System Off	System State	The system is currently not running
OnCP	On with compressor	Setpoint	Fans are on when compressor is running
OPEn	Open	Setpoint	Digital input is active/inactive when open
Pdt	Defrost pump down time	Setpoint	Amount of time to pump down the system before defrost
PErn	Permanent	Setpoint	Fans on permanently
PF	Power Failure alarm	Alarm	Alarm indicates that there was an interruption in the power supply to the controller
rEFr	Refrigerate Mode	System State	System mode displayed when controller is in cooling mode
rt1	Room Temperature 1	Variable	Room temperature displayed if AU1 (1st Auxiliary input) is set to rtP (Room Temp)
rt2	Room Temperature 2	Variable	Room temperature displayed if AU2 (2nd Auxiliary input) is set to rtP (Room Temp)
rtP	Room Temp	Variable	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - input is used as an additional room temperature averaged in with the other room temperature inputs
SHrt	Short	Setpoint	Digital input is active/inactive when short
StA1	State of 1st Auxiliary Input	Setpoint	Digital input active state for 1st Auxiliary input (AU1) - set whether it is open or short
StA2	State of 2nd Auxiliary Input	Setpoint	Digital input active state for 2nd Auxiliary input (AU2) - set whether it is open or short
SYOF	System Off	Variable	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - digital input that puts the controller into System Off Mode
SYOn	System On	Variable	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - digital input that puts the controller into System On Mode
SYSt	System State	Variable	Displays mode of system operation
t2nd	2nd Room Temp Setpoint	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - input is used to switch between the main Room Temp Setpoint and the 2nd Room Temp Setpoint
t2Of	2nd Air Off	Variable	Use main air temperature setpoint
t2On	2nd Air On	Variable	Use second air temperature
tAd	Temp Alarm Delay	Setpoint	Amount of time to delay a high temp or low temp alarm
tErd	Terminate Defrost	Variable	In Variables menu, display when 1st or 2nd Auxiliary input (AU1 or AU2) set to trdF (terminate defrost) and is active
ti24	Title 24	Setpoint	Configure the controller to be Title 24 for runtime compliant during refrigeration system's off cycle
tOd	Time of day	Setpoint	Time is displayed based on 24 hour clock
trdF	Terminate Defrost	Setpoint	Choice for input type for 1st or 2nd Auxiliary input (AU1 or AU2) - digital input that will terminate defrost
tS	Temperature Setpoint	Setpoint	Room temperature to be maintained
tS2	Temperature Setpoint 2	Setpoint	Alternate room temperature setpoint
Unt	Temp units	Setpoint	Fahrenheit (FAH) or Celsius (CEL)



KE2 LowTemp
Quick Start Guide