



©2009 Lennox Industries Inc.
Dallas, Texas, USA



**RETAIN THESE INSTRUCTIONS
FOR FUTURE REFERENCE**

⚠ WARNING

Improper installation, adjustment, alteration, service or maintenance can cause personal injury, loss of life, or damage to property.

Installation and service must be performed by a licensed professional installer (or equivalent) or a service agency.

⚠ CAUTION

Physical contact with metal edges and corners while applying excessive force or rapid motion can result in personal injury. Be aware of, and use caution when working near these areas during installation or while servicing this equipment.

⚠ IMPORTANT

This unit must be matched with an indoor coil as specified in Lennox' Engineering Handbook. Coils previously charged with HCFC-22 must be flushed.

⚠ IMPORTANT

The Clean Air Act of 1990 bans the intentional venting of refrigerant (CFCs, HCFCs AND HFCs) as of July 1, 1992. Approved methods of recovery, recycling or reclaiming must be followed. Fines and/or incarceration may be levied for noncompliance.

INSTALLATION INSTRUCTIONS

Dave Lennox *Signature*[®] Collection XP19 Series Units

HEAT PUMPS
505,331M
06/09
Supersedes 05/09

TP Technical
Publications
Litho U.S.A.

Table of Contents

Shipping and Packing List	1
Unit Dimensions	2
XP19 Heat Pumps	2
General Information	2
Recovering Refrigerant from Existing System	4
Removing Existing Outdoor Unit	5
Positioning New Outdoor Unit	5
Removing Panels	6
New or Replacement Line Set	8
Brazing Connections	9
Removing Indoor Unit Metering Device	10
Flushing the System	11
Installing New Indoor Unit Metering Device	12
Testing for Leaks	12
Evacuating the System	14
Servicing Unit Delivered Void of Charge	15
Electrical Connections	16
Start-Up and Charging Procedures	16
System Operations	21
Lennox System Operation Monitor (LSOM)	21
Defrost System	24
Maintenance	29
Two-Stage Compressor Check-out	30
Homeowner Information	30
Field Operational Checklist	32
Start-up and Performance Checklist	32

Shipping and Packing List1

Check the unit for shipping damage and listed times below are intact. If damaged, or if parts are missing, immediately contact the last shipping carrier.

- 1 — Assembled outdoor unit.
- 1 — Bag assembly which contains the followings:
 - 1 — Bushing (for low voltage wiring)
 - 2 — Isolation grommets for liquid and suction lines





Figure 1. Bag Assembly (Parts)



Unit Dimensions -- Inches (mm)²



⚠ WARNING

This product and/or the indoor unit it is matched with may contain fiberglass wool.

Disturbing the insulation during installation, maintenance, or repair will expose you to fiberglass wool dust. Breathing this may cause lung cancer. (Fiberglass wool is known to the State of California to cause cancer.)

Fiberglass wool may also cause respiratory, skin, and eye irritation.

To reduce exposure to this substance or for further information, consult material safety data sheets available from address shown below, or contact your supervisor.

Lennox Industries Inc.
P.O. Box 799900
Dallas, TX 75379-9900

XP19 Heat Pumps³

The XP19 Heat Pumps, which will also be referred to in this instruction as the outdoor unit, uses HFC-410A refrigerant. This outdoor unit must be installed with a matching indoor unit and line set as outlined in the *Lennox XP19 Engineering Handbook*.

This outdoor unit is designed for use in systems that use check thermal expansion valve (CTXV) refrigerant metering devices.

General Information⁴

These instructions are intended as a general guide and do not supersede local codes in any way. Consult authorities who have jurisdiction before installation.

When servicing or repairing HVAC components, ensure the fasteners are appropriately tightened. Table 1 shows torque values for fasteners.

Table 1. Torque Requirements

Parts	Recommended Torque	
Service valve cap	8 ft.- lb.	11 NM
Sheet metal screws	16 in.- lb.	2 NM
Machine screws #10	28 in.- lb.	3 NM
Compressor bolts	90 in.- lb.	10 NM
Gauge port seal cap	8 ft.- lb.	11 NM

USING MANIFOLD GAUGE SETS

When checking the system charge, only use a manifold gauge set that features low loss anti-blow back fittings. See Figure 3 for a typical manifold gauge connection setup.

Manifold gauge sets used with HFC-410A refrigerant systems must be capable of handling the higher system operating pressures. The gauges should be rated for use with pressures of 0 - 800 on the high side and a low side of 30" vacuum to 250 psi with dampened speed to 500 psi. Gauge hoses must be rated for use at up to 800 psi of pressure with a 4000 psi burst rating.

OPERATING SERVICE VALVES

The liquid and vapor line service valves are used for removing refrigerant, flushing, leak testing, evacuating, checking charge and charging.

Each valve is equipped with a service port which has a factory-installed valve stem.

! IMPORTANT

Only use Allen wrenches of sufficient hardness (50Rc - Rockwell Harness Scale minimum). Fully insert the wrench into the valve stem recess.

Service valve stems are factory-torqued (from 9 ft-lbs for small valves, to 25 ft-lbs for large valves) to prevent refrigerant loss during shipping and handling. Using an Allen wrench rated at less than 50Rc risks rounding or breaking off the wrench, or stripping the valve stem recess.




Figure 2. Cap Tightening Distances

! IMPORTANT

To prevent stripping of the various caps used, the appropriately sized wrench should be used and fitted snugly over the cap before tightening.

To Access Angle-Type Service Port:


A service port cap protects the service port core from contamination and serves as the primary leak seal.

1. Remove service port cap with an appropriately sized wrench.
2. Connect gauge to the service port.
3. When testing is completed, replace service port cap and tighten as follows:
 - *With Torque Wrench:* Finger tighten and then tighten per Table 1.
 - *Without Torque Wrench:* Finger tighten and use an appropriately sized wrench to turn an additional 1/6 turn clockwise as illustrated in Figure 2.

To Open and Close Angle-Type Service Valve:

A valve stem cap protects the valve stem from contamination and assures a leak-free seal.

1. Remove stem cap with an appropriately sized wrench.
2. Use a service wrench with a hex-head extension (3/16" for liquid-line valve sizes and 5/16" for vapor-line valve sizes) to back the stem out clockwise as far as it will go.



NOTE - Arrows indicate direction of refrigerant flow.

Figure 3. Typical Manifold Gauge Connection Setup

3. Replace the stem cap and tighten as follows:
 - **With Torque Wrench:** Tighten finger tight and then tighten per Table 1.
 - **Without Torque Wrench:** Finger tighten and use an appropriately sized wrench to turn an additional 1/12 turn clockwise as illustrated in Figure 2.




Figure 4. Angle-Type Service Valve (Font-Seated Closed)

NOTE — A label with specific torque requirements may be affixed to the stem cap. If the label is present, use the specified torque.

NOTE — To prevent stripping of the cap, the wrench should be appropriately sized and fit snugly over the cap before tightening the cap.




Figure 5. Angle-Type Service Valve (Back-Seated Opened)

To Access Ball-Type Service Port:

A service port cap protects the service port core from contamination and serves as the primary leak seal.

1. Remove service port cap with an appropriately sized wrench.
2. Connect gauge to the service port.
3. When testing is completed, replace service port cap and tighten as follows:
 - **With Torque Wrench:** Finger tighten and then tighten per Table 1.

- **Without Torque Wrench:** Finger tighten and use an appropriately sized wrench to turn an additional 1/6 turn clockwise as illustrated in Figure 2.




Figure 6. Ball-Type Service Valve

To Open and Close Ball-Type Service Valve:

A valve stem cap protects the valve stem from contamination and assures a leak-free seal.

1. Remove stem cap with an appropriately sized wrench.
2. Use an appropriately sized wrench to open. To open valve, rotate stem counterclockwise 90°. To close rotate stem clockwise 90°.
3. Replace the stem cap and tighten as follows:
 - **With Torque Wrench:** Finger tighten and then tighten per Table 1.
 - **Without Torque Wrench:** Finger tighten and use an appropriately sized wrench to turn an additional 1/12 turn clockwise as illustrated in Figure 2.

NOTE — A label with specific torque requirements may be affixed to the stem cap. If the label is present, use the specified torque.

Recovering Refrigerant from Existing System⁵

Remove existing HCFC-22 refrigerant using one of the following procedures:

METHOD 1:

If the existing outdoor unit is not equipped with shut-off valves, or if the unit is not operational and you plan to use the existing HCFC-22 to flush the system.

NOTE — Use recovery machine instructions for specific setup requirements.

1. Disconnect all power to the existing outdoor unit.
2. Connect to the existing unit a gauge set, clean recovery cylinder and a recovery machine. Use the instructions provided with the recovery machine on how to setup the connections.

- Remove all HCFC-22 refrigerant from the existing system. Check gauges after shutdown to confirm that the entire system is completely void of refrigerant.




Figure 7. Typical Refrigerant Recovery (Method 1)

NOTE — Use recovery machine instructions for specific setup requirements.

METHOD 2:

Use this method if the existing outdoor unit is equipped with manual shut-off valves, and plan on using new HCFC-22 refrigerant to flush the system.

IMPORTANT: Some system configurations may contain higher than normal refrigerant charge due to either large internal coil volumes, and/or long line sets. The following conditions may cause the compressor to stop functioning:

The following devices could prevent full system charge recovery into the outdoor unit:

- Outdoor unit's high or low-pressure switches (if applicable) when tripped can cycle the compressor **OFF**.
- Compressor can stop pumping due to tripped internal pressure relief valve.
- Compressor has internal vacuum protection that is designed to unload the scrolls (compressor stops pumping) when the pressure ratio meets a certain value or when the suction pressure is as high as 20 psig. (Compressor suction pressures should never be allowed to go into a vacuum. Prolonged operation at low suction pressures will result in overheating of the scrolls and permanent damage to the scroll tips, drive bearings and internal seals).

Once the compressor can not pump down to a lower pressure due to one of the above system conditions, shut off the suction valve. Turn OFF the main power to unit and use a recovery machine to recover any refrigerant left in the indoor coil and line set.

Perform the following task:

- Start the existing HCFC-22 system in the cooling mode and close the liquid line valve.

- Pump as much of the existing HCFC-22 refrigerant with the compressor back into the outdoor unit until you have reached the limitations of the outdoor system. Turn the outdoor unit main power **OFF** and use a recovery machine to remove the remaining refrigerant in the system.

NOTE — It may be necessary to bypass the low pressure switches if equipped to ensure complete refrigerant evacuation.

- When the low side system pressures reach 0 psig, close the suction line valve.
- Check gauges after shutdown to confirm that the valves are not allowing refrigerant to flow back into the low side of the system.

Removing Existing Outdoor Unit6

Perform the following task at the existing outdoor unit:

- Disconnect line set at the service valves.
- Disconnect electrical service at the disconnect switch.
- Remove old outdoor unit.

Positioning New Outdoor Unit7

CAUTION

In order to avoid injury, take proper precaution when lifting heavy objects.

See *Unit Dimensions* on page 3 for sizing mounting slab, platforms or supports. Refer to Figure 8 for mandatory installation clearance requirements.




Figure 8. Installation Clearances

NOTES:

- Service clearance of 30 in. (762 mm) must be maintained on one of the sides adjacent to the control box.
- Clearance to one of the other three sides must be 36 in. (914 mm).
- Clearance to one of the remaining two sides may be 12 in. (305 mm) and the final side may be 6 in. (152 mm).
- 48 in. (1219 mm) clearance required on top of unit.
- A clearance of 24 in. (610 mm) must be maintained between two units.

POSITIONING CONSIDERATIONS




Figure 9. Outside Unit Placement

Consider the following when positioning the unit:

- Some localities are adopting sound ordinances based on the unit's sound level registered from the adjacent property, not from the installation property. Install the unit as far as possible from the property line.
- When possible, do not install the unit directly outside a window. Glass has a very high level of sound transmission. For proper placement of unit in relation to a window see the provided illustration in Figure 9.

PLACING UNIT ON SLAB

When installing unit at grade level, the top of the slab should be high enough above grade so that water from higher ground will not collect around the unit. The slab should have a slope tolerance as described in Figure 10.




Figure 10. Slab Mounting at Ground Level

NOTE — If necessary for stability, anchor unit to slab as described in *Stabilizing Unit on Uneven Surfaces* on page 7.

ELEVATING THE UNIT

This unit is outfitted with elongated support feet as illustrated in Figure 11 which uses a similar method for elevating the unit.




Figure 11. Elevated Slab Mounting using Feet Extenders

If additional elevation is necessary, raise the unit by extending the length of the unit support feet. This may be achieved by using a 2" SCH 40 female threaded adapter.

The specified coupling will fit snugly into the recessed portion of the feet. Use additional 2" SCH 40 male threaded adaptors which can be threaded into the female threaded adaptors to make additional adjustments to the level of the unit.

NOTE — Keep the height of extenders short enough to ensure a sturdy installation. If it is necessary to extend further, consider a different type of field-fabricated framework that is sturdy enough for greater heights.

Removing and Installing Panels8

⚠ CAUTION

To prevent personal injury, or damage to panels, unit or structure, be sure to observe the following:

While installing or servicing this unit, carefully stow all removed panels out of the way, so that the panels will not cause injury to personnel, nor cause damage to objects or structures nearby, nor will the panels be subjected to damage (e.g., being bent or scratched).

While handling or stowing the panels, consider any weather conditions, especially windy conditions, that may cause panels to be blown around and battered.

! WARNING

Unit must be grounded in accordance with national and local codes. Electric Shock Hazard. Can cause injury or death.



Line voltage is present at all components when unit is not in operation on units with single-pole contactors. Disconnect all remote electric power supplies before opening access panel. Unit may have multiple power supplies.

ACCESS PANEL

Removal and reinstallation of the access panel is illustrated in Figure 12.




Figure 12. Access Panel

LOUVERED PANELS

Remove the louvered panels as follows:

1. Remove two screws, allowing the panel to swing open slightly.
2. **Hold the panel firmly throughout this procedure.** Rotate bottom corner of panel away from hinged corner post until lower three tabs clear the slots as illustrated in Figure 13, detail B.
3. Move panel down until lip of upper tab clears the top slot in corner post as illustrated in Figure 13, detail A.

Position and Install Panel—Position the panel almost parallel with the unit as illustrated in Figure 14, detail D with the screw side as close to the unit as possible. Then, in a continuous motion:

- Slightly rotate and guide the lip of top tab inward as illustrated in Figure 13, details A and C; then upward into the top slot of the hinge corner post.
- Rotate panel to vertical to fully engage all tabs.
- Holding the panel's hinged side firmly in place, close the right-hand side of the panel, aligning the screw holes.

When panel is correctly positioned and aligned, insert the screws and tighten.




Figure 13. Removing/Installing Louvered Panels (Detail A, B and C)




Figure 14. Removing/Installing Louvered Panels (Detail D)

STABILIZING UNIT ON UNEVEN SURFACES

With unit positioned at installation site, remove two side louvered panels to expose the unit base pan. Install the brackets as illustrated in Figure 15 using conventional practices; replace the panels after installation is complete.

⚠ IMPORTANT

Unit Stabilizer Bracket Use (field-provided):

Always use stabilizers when unit is raised above the factory height. (Elevated units could become unstable in gusty wind conditions).

Stabilizers may be used on factory height units when mounted on unstable an uneven surface.

To help stabilize an outdoor unit, some installations may require strapping the unit to the pad using brackets and anchors commonly available in the marketplace.




Figure 15. Installing Stabilizer Brackets

New or Replacement Line Set9

This section provides information on installation or replacement of existing line set. If line set are not being installed then proceed to *Brazing Connections* on page 12.

If refrigerant lines are routed through a wall, seal and isolate the opening so vibration is not transmitted to the building. Pay close attention to line set isolation during installation of any HVAC system. When properly isolated from building structures (walls, ceilings, floors), the refrigerant lines will not create unnecessary vibration and subsequent sounds. Also, consider the following when placing and installing a high-efficiency air conditioner.

REFRIGERANT LINE SET

Field refrigerant piping consists of liquid and suction lines from the outdoor unit (brazed connections) to the indoor unit coil (flare or sweat connections). Use Lennox L15 (sweat, non-flare) series line set, or use field-fabricated refrigerant lines as listed in Table 2.

Table 2. Refrigerant Line Set

Model	Field Connections		Recommended Line Set		
	Liquid Line	Suction Line	Liquid Line	Suction Line	L15 Line Set
-024 -036 -048	3/8" (10 mm)	7/8" (22 mm)	3/8" (10 mm)	7/8" (22 mm)	L15-65 15 ft. - 50 ft. (4.6 m - 15 m)
-060	3/8" (10 mm)	1-1/8" (29 mm)	3/8" (10 mm)	1-1/8" (29 mm)	Field Fabricated

NOTE — When installing refrigerant lines longer than 50 feet, see the *Lennox Refrigerant Piping Design and Fabrication Guidelines*, or contact *Lennox Technical Support Product Applications* for assistance. To obtain the correct information from Lennox, be sure to communicate the following points:

- Model (XP19) and size of unit (e.g. -060).
- Line set diameters for the unit being installed as listed in Table 2 and total length of installation.
- Number of elbows and if there is a rise or drop of the piping.

MATCHING WITH NEW OR EXISTING INDOOR COIL AND LINE SET

The RFC1-metering line consisted of a small bore copper line that ran from condenser to evaporator coil. Refrigerant was metered into the evaporator by utilizing temperature/pressure evaporation effects on refrigerant in the small RFC line. The length and bore of the RFC line corresponded to the size of cooling unit.

If the XP19 is being used with either a new or existing indoor coil which is equipped with a liquid line which served as a metering device (RFCI), the liquid line must be replaced prior to the installation of the XP19 unit. Typically a liquid line used to meter flow is 1/4" in diameter and copper.

INSTALLING LINE SET

Line Set Isolation — This reference illustrates procedures, which ensure proper refrigerant line set isolation:

- Installation of **line set on horizontal runs** is illustrated in Figure 16.
- Installation of **line set on vertical runs** is illustrated in Figure 17.
- Installation of a **transition from horizontal to vertical** is illustrated in Figure 18.




Figure 16. Refrigerant Line Set: Installing Horizontal Runs




Figure 17. Refrigerant Line Set: Installing Vertical Runs (New Construction Shown)




Figure 18. Refrigerant Line Set: Transition from Vertical to Horizontal

Brazing Connections¹⁰

Use the following procedure to braze the line set to the new air conditioner unit. Figure 19 is provided as a general guide for preparing to braze the line set to the air conditioner unit.

⚠ WARNING

Polyol ester (POE) oils used with HFC-410A refrigerant absorb moisture very quickly. It is very important that the refrigerant system be kept closed as much as possible. DO NOT remove line set caps or service valve stub caps until you are ready to make connections.

⚠ WARNING



Danger of fire. Bleeding the refrigerant charge from only the high side may result in the low side shell and suction tubing being pressurized. Application of a brazing torch while pressurized may result in ignition of the refrigerant and oil mixture - check the high and low pressures before unbrazing.

⚠ WARNING



When using a high pressure gas such as dry nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).

1. Cut ends of the refrigerant lines square (free from nicks or dents). Deburr the ends. The pipe must remain round, do not pinch end of the line.




Figure 19. Brazing Connections

2. Remove service cap and core from both the suction and liquid line service ports.
3. Connect gauge low pressure side to liquid line service valve.
4. To protect components during brazing, wrap a wet cloth around the liquid line service valve body and copper tube stub and use another wet cloth underneath the valve body to protect the base paint. Also, shield the light maroon R-410A sticker.
5. Flow regulated nitrogen (at 1 to 2 psig) through the refrigeration gauge set into the valve stem port connection on the liquid line service valve and out of the valve stem port connection on the suction service valve.

NOTE — The RFCIV or TXV metering device at the indoor unit will allow low pressure nitrogen to flow through the system.)

6. Braze the liquid line to the liquid line service valve. Turn off nitrogen flow. Repeat procedure starting at paragraph 4 for brazing the suction line to the suction service valve.
7. After all connections have been brazed, disconnect manifold gauge set from service ports, cool down piping with wet rag and remove all wrappings. Do not reinstall cores until after evacuation procedures. Reinstall service caps if desired to close off refrigerant ports.

Removing Indoor Unit Metering Device¹¹

Remove the existing HCFC-22 refrigerant flow control orifice or thermal expansion valve from the indoor coil. The existing indoor unit HCFC-22 metering device is not approved for use with HFC-410A refrigerant and may prevent proper flushing.

REPLACEMENT PARTS

If replacement parts are necessary for the indoor unit, order kit 69J46. The kit includes:




Figure 20. 69J46 Kit Components

TYPICAL FIXED ORIFICE REMOVAL PROCEDURE

1. On fully cased coils, remove the coil access and plumbing panels.
2. Remove any shipping clamps holding the liquid line and distributor assembly.
3. Using two wrenches, disconnect liquid line from liquid line orifice housing. Take care not to twist or damage distributor tubes during this process.

- Remove and discard fixed orifice, valve stem assembly if present and Teflon washer as illustrated in Figure 21.
- Use a field-provided fitting to temporary reconnect the liquid line to the indoor unit's liquid line orifice housing.




Figure 21. Typical Fixed Orifice Removal

TYPICAL TXV REMOVAL PROCEDURE




Figure 22. Typical TXV Removal

- On fully cased coils, remove the coil access and plumbing panels.
- Remove any shipping clamps holding the liquid line and distributor assembly.
- Disconnect the equalizer line from the TXV equalizer line fitting on the suction line.
- Remove the suction line sensing bulb.
- Disconnect the liquid line from the TXV at the liquid line assembly.
- Disconnect the TXV from the liquid line orifice housing. Take care not to twist or damage distributor tubes during this process.

- Remove and discard TXV and the two Teflon rings.
- Use a field-provided fitting to temporary reconnect the liquid line to the indoor unit's liquid line orifice housing.

Flushing the System¹²

! IMPORTANT

The line set and indoor unit coil must be flushed with at least the same amount of clean refrigerant that previously charged the system. Check the charge in the flushing cylinder before proceeding.

! IMPORTANT

If this unit is being matched with an approved line set or indoor unit coil which was previously charged with mineral oil, or if it is being matched with a coil which was manufactured before January of 1999, the coil and line set must be flushed prior to installation. Take care to empty all existing traps. Polyol ester (POE) oils are used in Lennox units charged with HFC-410A refrigerant. Residual mineral oil can act as an insulator, preventing proper heat transfer. It can also clog the expansion device, and reduce the system performance and capacity. Failure to properly flush the system per the instructions below will void the warranty.

! IMPORTANT

The Environmental Protection Agency (EPA) prohibits the intentional venting of HFC refrigerants during maintenance, service, repair and disposal of appliance. Approved methods of recovery, recycling or reclaiming must be followed.




Figure 23. Typical Flushing Connection

⚠ CAUTION

This procedure should not be performed on systems which contain contaminants (Example: compressor burn out).

If the original system used:

- HCFC-22 refrigerant, then flush the system using the procedure provided in this section.
- HFC-410A refrigerant, then proceed to *Installing New Refrigerant Metering Device*.

REQUIRED EQUIPMENT

Equipment required to flush the existing line set and indoor unit coil:

- Two clean HCFC-22 recovery bottles,
- Oilless recovery machine with pump-down feature,
- Two gauge sets (one for HCFC-22; one for HFC-410A).

FLUSHING PROCEDURE

1. Connect the following:
 - HCFC-22 cylinder with clean refrigerant to the suction service valve,
 - HCFC-22 gauge set to the liquid line valve,
 - Recovery machine with an empty recovery tank to the gauge set.
2. Set the recovery machine for liquid recovery and start the recovery machine. Open the gauge set valves to allow the recovery machine to pull a vacuum on the existing system line set and indoor unit coil.
3. Invert the cylinder of clean HCFC-22 and open its valve to allow liquid refrigerant to flow into the system through the suction line valve. Allow the refrigerant to pass from the cylinder and through the line set and the indoor unit coil before it enters the recovery machine.
4. After all of the liquid refrigerant has been recovered, switch the recovery machine to suction recovery so that all of the HCFC-22 suction is recovered. Allow the recovery machine to pull a vacuum on the system.
5. Close the valve on the inverted HCFC-22 drum and the gauge set valves. Pump the remaining refrigerant out of the recovery machine and turn the machine off.

Installing New Indoor Metering Device¹³

XP19 units use CTXV for metering refrigerant only. This section provides instructions on installing CTXV refrigerant metering device.




Figure 24. Tightening Distance

TYPICAL CTXV INSTALLATION PROCEDURE

The CTXV unit can be installed internal or external to the indoor coil. In applications where an uncased coil is being installed in a field-provided plenum, install the CTXV in a manner that will provide access for field servicing of the CTXV. Refer to Figure 25 for reference during installation of CTXV unit.




Figure 25. Typical TXV Installation

1. Remove the field-provided fitting that temporary reconnected the liquid line to the indoor unit's distributor assembly.
2. Install one of the provided Teflon rings around the stubbed end of the CTXV and lightly lubricate the connector threads and expose surface of the Teflon ring with refrigerant oil.
3. Attach the stubbed end of the CTXV to the liquid line orifice housing. Finger tighten and use an appropriately

sized wrench to turn an additional 1/2 turn clockwise as illustrated in Figure 24, or 20 ft-lb.

4. Place the remaining Teflon washer around the other end of the CTXV. Lightly lubricate connector threads and expose surface of the Teflon ring with refrigerant oil.
5. Attach the liquid line assembly to the CTXV. Finger tighten and use an appropriately sized wrench to turn an additional 1/2 turn clockwise as illustrated in Figure 24, or 20 ft-lb.
6. Attach the suction line sensing bulb in the proper orientation as illustrated in Figure 26 using the clamp and screws provided.

NOTE — Insulating the sensing bulb once installed may be required when the bulb location is external to the coil casing.




Figure 26. TXV Sensing Bulb Installation

7. Remove and discard either the flare seal cap or flare nut with copper flare seal bonnet from the equalizer line port on the suction line as illustrated in Figure 27.




Figure 27. Copper Flare Seal Bonnet Removal

⚠ IMPORTANT

When removing the flare nut, ensure that the copper flare seal bonnet is removed.

8. Connect the equalizer line from the TXV to the equalizer suction port on the suction line. Finger tighten the flare nut plus 1/8 turn (7 ft-lbs) as illustrated in Figure 24.

NOTE — To prevent any possibility of water damage, properly insulate all parts of the TXV assembly that may sweat due to temperature differences between the valve and its surrounding ambient temperatures.

See the XP19 Engineering Handbook for approved CTXV kit match-ups and application information.

The reference CTXV kits include:

- 1 — CTXV
- 2 — Teflon rings
- 1 — 1 1/4" wide copper mounting strap for sensing bulb
- 2 — #10 hex head bolts and nuts for securing sensing bulb




Figure 28. CTXV Kit Components

Testing for Leaks¹⁴

After the line set has been connected to the indoor unit and air conditioner, check the line set connections and indoor unit for leaks. Use the following procedure to test for leaks:

⚠ IMPORTANT

Leak detector must be capable of sensing HFC refrigerant.

⚠ WARNING

Refrigerant can be harmful if it is inhaled. Refrigerant must be used and recovered responsibly.

Failure to follow this warning may result in personal injury or death.

WARNING



When using a high pressure gas such as dry nitrogen to pressurize a refrigeration or air conditioning system, use a regulator that can control the pressure down to 1 or 2 psig (6.9 to 13.8 kPa).

WARNING



Fire, Explosion and Personal Safety Hazard.

Failure to follow this warning could result in damage, personal injury or death.

Never use oxygen to pressurize or purge refrigeration lines. Oxygen, when exposed to a spark or open flame, can cause damage by fire and/or an explosion, that could result in personal injury or death.

1. Connect an HFC-410A manifold gauge set high pressure hose to the suction valve service port. (Normally, the high pressure hose is connected to the liquid line port; however, connecting it to the suction port better protects the manifold gauge set from high pressure damage.)
2. With both manifold valves closed, connect the cylinder of HFC-410A refrigerant to the center port of the manifold gauge set. Open the valve on the HFC-410A cylinder (suction only).
3. Open the high pressure side of the manifold to allow HFC-410A into the line set and indoor unit. Weigh in a trace amount of HFC-410A. [A trace amount is a maximum of two ounces (57 g) refrigerant or three pounds (31 kPa) pressure]. Close the valve on the HFC-410A cylinder and the valve on the high pressure side of the manifold gauge set. Disconnect the HFC-410A cylinder.
4. Connect a cylinder of dry nitrogen with a pressure regulating valve to the center port of the manifold gauge set.
5. Adjust dry nitrogen pressure to 150 psig (1034 kPa). Open the valve on the high side of the manifold gauge set in order to pressurize the line set and the indoor unit.
6. After a few minutes, open one of the service valve ports and verify that the refrigerant added to the system earlier is measurable with a leak detector.
7. After leak testing disconnect gauges from service ports.

Evacuating the System¹⁵

Evacuating the system of non-condensables is critical for proper operation of the unit. Non-condensables are defined as any gas that will not condense under temperatures and pressures present during operation of an air conditioning system. Non-condensables and water suction combine with refrigerant to produce substances that corrode copper piping and compressor parts.

WARNING

Danger of Equipment Damage. Avoid deep vacuum operation. Do not use compressors to evacuate a system. Extremely low vacuums can cause internal arcing and compressor failure. Damage caused by deep vacuum operation will void warranty.

IMPORTANT

Use a thermocouple or thermistor electronic vacuum gauge that is calibrated in microns. Use an instrument capable of accurately measuring down to 50 microns.

NOTE — Remove cores from service valves if not already done.

1. Connect manifold gauge set to the service valve ports as follows:
 - low pressure gauge to suction line service valve
 - high pressure gauge to liquid line service valve
2. Connect micron gauge.
3. Connect the vacuum pump (with vacuum gauge) to the center port of the manifold gauge set.
4. Open both manifold valves and start the vacuum pump.
5. Evacuate the line set and indoor unit to an **absolute pressure** of 23,000 microns (29.01 inches of mercury).

*NOTE — During the early stages of evacuation, it is desirable to close the manifold gauge valve at least once to determine if there is a rapid rise in sure indicates a relatively large leak. If this occurs, **repeat the leak testing procedure.***

*NOTE — The term **absolute pressure** means the total actual pressure within a given volume or system, above the absolute zero of pressure. Absolute pressure in a vacuum is equal to atmospheric pressure minus vacuum pressure.*

6. When the absolute pressure reaches 23,000 microns (29.01 inches of mercury), close the manifold gauge valves, turn off the vacuum pump and disconnect the manifold gauge center port hose from vacuum pump. Attach the manifold center port hose to a dry nitrogen

cylinder with pressure regulator set to 150 psig (1034 kPa) and purge the hose. Open the manifold gauge valves to break the vacuum in the line set and indoor unit. Close the manifold gauge valves.

7. Shut off the dry nitrogen cylinder and remove the manifold gauge hose from the cylinder. Open the manifold gauge valves to release the dry nitrogen from the line set and indoor unit.
8. Reconnect the manifold gauge to the vacuum pump, turn the pump on, and continue to evacuate the line set and indoor unit until the absolute pressure does not rise above 500 microns (29.9 inches of mercury) within a 20-minute period after shutting off the vacuum pump and closing the manifold gauge valves.
9. When the absolute pressure requirement above has been met, disconnect the manifold hose from the vacuum pump and connect it to an upright cylinder of HFC-410A refrigerant. Open the manifold gauge valve 1 to 2 psig in order to release the vacuum in the line set and indoor unit.
10. Perform the following:
 - A Close manifold gauge valves.
 - B Shut off HFC-410A cylinder.
 - C Reinstall service valve cores by removing

manifold hose form service valve. Quickly install core with core tool while maintaining a positive system pressure.

- D Replace the stem caps and secure finger tight, then tighten an additional one-sixth (1/6) of a turn as illustrated in Figure 2.

Servicing Units Delivered Void of Charge16

If the outdoor unit is void of refrigerant, clean the system using the procedure described below.

1. Use nitrogen to pressurize the system and check for leaks. Repair all leaks.
2. Evacuate the system to remove as much of the moisture as possible.
3. Use nitrogen to break the vacuum and install a new filter drier in the system.
4. Evacuate the system again. Then, weigh the appropriate amount of HFC-410A refrigerant as listed on unit nameplate into the system.
5. Monitor the system to determine the amount of moisture remaining in the oil. It may be necessary to replace the filter drier several times to achieve the required dryness level. **If system dryness is not verified, the compressor will fail in the future.**




Figure 29. XP19 Wiring

⚠ WARNING



Electric shock hazard. Can cause injury or death.

Line voltage is present at all components on units with single-pole contactors, even when unit is not in operation!

Unit may have multiple power supplies. Disconnect all remote electric power supplies before opening access panel.

Unit must be grounded in accordance with national and local codes.

In the U.S.A., wiring must conform with current local codes and the current National Electric Code (NEC). In Canada, wiring must conform with current local codes and the current Canadian Electrical Code (CEC).

Refer to the furnace or blower coil installation instructions for additional wiring application diagrams and refer to unit nameplate for minimum circuit ampacity and maximum overcurrent protection size.

230VAC SUPPLY VOLTAGE

The XP19 outdoor unit is rated for 230VAC applications only. A hard-start kit is required for applications where the supply voltage is less than 230VAC.

24VAC TRANSFORMER

Use the transformer provided with the furnace or coil blower for low-voltage control power (24VAC - 40 VA minimum)

NOTE — The addition of accessories to the system could exceed the 40 VA power requirement of the factory-provided transformer. Measure the system's current and voltage after installation is complete to determine transformer loading. If loading exceeds the factory-provided transformer capacity, a larger field-provided transformer will need to be installed in the system.

WIRING CONNECTIONS

1. Install line voltage power supply to unit from a properly sized disconnect switch.
2. Ground unit at unit disconnect switch or to an earth ground.

NOTE — Connect conduit to the unit using a proper conduit fitting. Units are approved for use only with copper conductors. A complete unit wiring diagram is located on the back side of the unit's access panel.

NOTE — For proper voltages, select thermostat wire gauge per the following chart:

Table 3. Wire Run Length

Wire Run Length	AWG #	Insulation Type
less than 100' (30m)	18	color-coded, temperature rating 35°C minimum
more than 100' (30m)	16	

3. Install room thermostat (ordered separately) on an inside wall approximately in the center of the area and 5 feet (1.5 m) from the floor. Do not install on an outside wall or where sunlight, drafts or vibrations affect it.
4. Install low voltage wiring from outdoor to indoor unit and from thermostat to indoor unit as illustrated in Figure 29.

THERMOSTAT SECOND-STAGE COOLING CONNECTIONS

The Lennox System Operation Monitor (LSOM) requires a two-stage room thermostat to operating properly.

- Y2 Room Thermostat Wire — Connect the Y2 room thermostat wire from the outdoor unit to the Y2 input on the DCB.
- L Terminal Wiring — Connect L terminal of the room thermostat to the L (brown) field wire connection.
- Y2 DC Solenoid Connector (DC SOL) — The two-pin DC solenoid connector is connected at the factory to the compressor second-state solenoid connector. No field connections are required for this component.

NOTE — Wiring the module incorrectly will cause false LED codes. Table 14 describes LED operation when the module is incorrectly wired and the action required to correct the problem.

Start-Up and Charging Procedures18

⚠ IMPORTANT

If unit is equipped with a crankcase heater, it should be energized 24 hours before unit start-up to prevent compressor damage as a result of slugging.

1. Rotate fan to check for binding.
2. Inspect all factory- and field-installed wiring for loose connections.
3. After evacuation is complete, open both the liquid and vapor line service valves to release the refrigerant charge contained in outdoor unit into the system.
4. Replace the stem caps and tighten to the value listed in Table 1.
5. Check voltage supply at the disconnect switch. The voltage must be within the range listed on the unit's nameplate. If not, do not start the equipment until you have consulted with the power company and the voltage condition has been corrected.
6. Set the thermostat for a cooling demand. Turn on power to the indoor indoor unit and close the outdoor unit disconnect switch to start the unit.
7. Recheck voltage while the unit is running. Power must be within range shown on the nameplate.

- Check system for sufficient refrigerate by using the procedures listed under *Testing and Charging System*.

TESTING AND CHARGING SYSTEM

This system uses HFC-410A refrigerant which operates at much higher pressures than HCFC-22. The pre-installed liquid line filter drier is approved for use with HFC-410A only. Do not replace it with components designed for use with HCFC-22. This unit is NOT approved for use with coils which use capillary tubes as a refrigerant metering device.

SETTING UP TO CHECK CHARGE

- Close manifold gauge set valves. Connect the center manifold hose to an upright cylinder of HFC-410A.
- Connect the manifold gauge set to the unit's service ports as illustrated in Figure 3.
 - low pressure gauge to *vapor service port*
 - high pressure gauge to *liquid service port*

COOLING MODE INDOOR AIRFLOW CHECK

Check airflow using the Delta-T (DT) process using the illustration in Figure 30.

HEATING MODE INDOOR AIRFLOW CHECK

Blower airflow (CFM) may be calculated by energizing electric heat and measuring:

- Temperature rise between the return air and supply air temperatures at the indoor coil blower unit,
- Measuring voltage supplied to the unit,
- Measuring amperage being drawn by the heat unit(s).


Then, apply the measurements taken in following formula to determine CFM:

$$CFM = \frac{\text{Amps} \times \text{Volts} \times 3.41}{1.08 \times \text{Temperature rise (F)}}$$

CALCULATING CHARGE

If the system is void of refrigerant, first, locate and repair any leaks and then weigh in the refrigerant charge into the unit. To calculate the total refrigerant charge:

Amount specified on nameplate	Adjust amount. for variation in line set length listed on Table in Figure 31.	Additional charge specified per indoor unit match-up listed in Tables 4 through 7.	Total charge			
_____	+	_____	+	_____	=	_____



1. Determine the desired DT—Measure entering air temperature using dry bulb (A) and wet bulb (B). DT is the intersecting value of A and B in the Table (see triangle).

2. Find temperature drop across coil—Measure the coil's dry bulb entering and leaving air temperatures (A and C). Temperature Drop Formula: $(T_{Drop}) = A$ minus C .

3. Determine if fan needs adjustment—If the difference between the measured T_{Drop} and the desired DT ($T_{Drop} - DT$) is within $\pm 3^\circ$, no adjustment is needed. See examples: Assume DT = 15 and A temp. = 72°, these C temperatures would necessitate stated actions:

C°	T _{Drop}	-	DT	=	°F	ACTION
53°	19	-	15	=	4	Increase the airflow
58°	14	-	15	=	-1	(within $\pm 3^\circ$ range) no change
62°	10	-	15	=	-5	Decrease the airflow

4. Adjust the fan speed—See indoor unit instructions to increase/decrease fan speed.

Changing air flow affects all temperatures; recheck temperatures to confirm that the temperature drop and DT are within $\pm 3^\circ$.


Figure 30. Checking Indoor Airflow over Evaporator Coil using Delta-T Chart

WEIGH IN

Refrigerant Charge per Line Set Length

Liquid Line Set Diameter	Ounces per 5 feet (g per 1.5 m) adjust from 15 feet (4.6 m) line set*
3/8" (9.5 mm)	3 ounce per 5' (85 g per 1.5 m)

NOTE - *If line length is greater than 15 ft. (4.6 m), add this amount. If line length is less than 15 ft. (4.6 m), subtract this amount.



1. Check Liquid and suction line pressures
2. Compare unit pressures with Table 8, *Normal Operating Pressures*.
3. Conduct leak check; evacuate as previously outlined.
4. Weigh in the unit nameplate charge plus any charge required for line set differences over feet.




This nameplate is for illustration purposes only. Go to actual nameplate on outdoor unit for charge information.



Figure 31. Using Weigh In Method

SUBCOOLING



SAT° _____
 LIQ° - _____
 SC° = _____

1. Check the airflow as illustrated in Figure 30 to be sure the indoor airflow is as required. (Make any air flow adjustments before continuing with the following procedure.)

2. Measure outdoor ambient temperature; determine whether to use **cooling mode** or **heating mode** to check charge.

3. Connect gauge set.

4. Check liquid and vapor line pressures. Compare pressures with either cooling or heating mode normal operating pressures in Table 8 (second stage - high capacity).

NOTE - The reference table is a general guide. Expect minor pressure variations. Significant differences may mean improper charge or other system problem.)

5. Set thermostat for heat/cool demand, depending on mode being used:

Using cooling mode—When the outdoor ambient temperature is 60°F (15°C) and above. Target subcooling values (second stage - high capacity) in Table 8 are based on 70 to 80°F (21-27°C) indoor return air temperature; if necessary, operate heating to reach that temperature range; then set thermostat to cooling mode setpoint to 68°F (20°C) which should call for second stage (high capacity) cooling. When pressures have stabilized, continue with step 6.

Using heating mode—When the outdoor ambient temperature is below 60°F (15°C). Target subcooling values (second stage - high capacity) in Table 8 are based on 65-75°F (18-24°C) indoor return air temperature; if necessary, operate cooling to reach that temperature range; then set thermostat to heating mode setpoint to 77°F (25°C) which should call for second stage (high capacity) heating. When pressures have stabilized, continue with step 6.

6. Read the liquid line temperature; record in the LIQ° space.

7. Read the liquid line pressure; then find its corresponding temperature in the temperature/pressure chart listed in Table 9 and record it in the SAT° space.

8. Subtract LIQ° temp. from SAT° temp. to determine subcooling; record it in SC° space.

9. Compare SC° results with tables below, being sure to note any additional charge for line set and/or match-up.

10. If subcooling value is greater than shown in Tables 4 through 7 for the applicable unit, remove refrigerant; if less than shown, add refrigerant.

11. If refrigerant is added or removed, repeat steps 4 through 10 to verify charge.

Figure 32. Using Subcooling Method — Second Stage (High Capacity)

** Amount of charge required in additional to charge shown on unit nameplate. Remember to consider line set length difference.

Table 4 — XP19-024

INDOOR MATCH-UP	HEAT PUMP	Target Heating (±5°F)	Subcooling Cooling (±1°F)	**Add charge	
				lb	oz
C33-31		12	7	0	1
C33-38 SN# before SN#6007K		31	7	0	6
C33-38 SN#6007K and after		10	8	0	6
CBX27UH-030-230		10	6	0	6
CB30U-31		12	7	0	1
CB30U-41		10	6	0	6
CB31MV-41		10	6	0	6
CBX32M-030-230		12	7	0	1
CBX32M-036-230		10	6	0	6
CBX32MV-024/030-230		12	8	0	0
CBX32MV-036-230		10	6	0	6
CBX40UHV-024, -030		12	8	0	0
CBX40UHV-036		10	6	0	6
CH33-44/48, -48C		8	7	1	0
CR33-48		6	6	1	3
CR33-50/60		8	6	1	0
CR33-60		8	6	1	0
CX34-31		12	7	0	1
CX34-38 SN# before SN#6007K		31	7	0	6
CX34-38 SN#6007K and after		10	8	0	6

Table 5 — XP19-036

INDOOR MATCH-UP	HEAT PUMP	Target Heating (±5°F)	Subcooling Cooling (±1°F)	**Add charge	
				lb	oz
C33-38 SN# before SN#6007K		31	7	0	0
C33-38 SN#6007K and after		10	8	0	0
C33-44, -48		14	6	0	7
C33-49		6	6	1	5
C33-50/60C		12	5	0	13
C33-60D		8	5	0	15
C33-62D		6	6	1	5
CH23-51		14	6	0	5
CH23-65		12	5	0	13
CBX27UH-036-230		14	6	0	7
CBX27UH-042-230		6	6	1	5
CB29M-51		6	6	1	5
CB30M-41, -46		14	6	0	7
CB30M-51		6	6	1	5
CB30U-51		6	6	1	5
CB31MV-41		14	6	0	7
CB31MV-51		6	6	1	5
CBX32M-036-230		14	6	0	7
CBX32M-042-230		14	6	0	7
CBX32M-048-230		6	6	1	5
CBX32MV-036-230		14	6	0	5
CBX32MV-048-230		6	6	1	5
CBX40UHV-036		14	6	0	5
CBX40UHV-042, -048		6	6	1	5
CH33-44/48B		12	5	0	13
CH33-48		12	5	0	13
CR33-48		30	5	0	0
CR33-50/60, -60		15	4	1	5

Table 8 — XP19-036 (Continued)

INDOOR MATCH-UP	HEAT PUMP	Target Subcooling Heating Cooling (±5°F) (±1°F)		**Add charge	
CX34-48 SN# before SN#6007K		31	7	0	0
CX34-48 SN#6007K and after		10	8	0	0
CX34-44/48		30	5	0	0
CX34-49		6	6	1	5
CX34-50/60C		12	5	0	13
CX34-60D		8	5	0	15
CX34-62D		6	6	1	5

Table 6 — XP19-048

INDOOR MATCH-UP	HEAT PUMP	Target Heating (±5°F)	Subcooling Cooling (±1°F)	**Add charge	
				lb	oz
C33-49		13	5	0	5
C33-60D		20	4	0	0
C33-62C, -62D		12	5	0	8
CBX27UH-048-230		13	5	0	5
CBX27UH-060-230		13	5	0	5
CB30M-51, -65		13	5	0	5
CB30U-51, -65		13	5	0	5
CB31MV-51, -65		13	5	0	5
CBX32M-048-230		13	5	0	5
CBX32M-060-230		13	5	0	5
CBX32MV-048-230		13	5	0	5
CBX32MV-060-230		13	6	0	5
CBX32MV-068-230		10	6	0	13
CBX40UHV-048		13	5	0	5
CBX40UHV-060		13	6	0	5
CH23-68		12	7	0	13
CH33-50/60C		20	7	0	5
CH33-62D		13	5	0	5
CR33-50/60, -60		20	4	0	5
CX34-49		13	5	0	5
CX34-60D		20	4	0	0
CX34-62C, -62D		12	5	0	8

Table 7 — XP19-060

INDOOR MATCH-UP	HEAT PUMP	Target Heating (±5°F)	Subcooling Cooling (±1°F)	**Add charge	
				lb	oz
C33-49		16	5	1	0
C33-60D		24	5	0	0
C33-62C, -62D		13	5	0	11
CBX27UH-060-230		16	5	1	0
CB30M-51, -65		16	5	1	0
CB30U-41, -65		16	5	1	0
CB31MV-51, -65		16	5	1	0
CBX32M-048-230		16	5	1	0
CBX32M-060-230		16	5	1	0
CBX32MV-048-230		16	5	1	0
CBX32MV-060-230		16	6	1	0
CBX32MV-068-230		14	4	1	0
CBX40UHV-048		16	5	1	0
CBX40UHV-060		16	6	1	0
CH23-68		14	4	1	0
CH33-62D		18	4	1	0
CR33-50/60, -60		24	5	0	0
CX34-49		16	5	1	0
CX34-60D		24	5	0	0
CX34-62C, -62D		13	5	0	11

Table 8. Normal Operating Pressure - Liquid ± 10 and Vapor ± 5 PSIG*

! IMPORTANT

Minor variations in these pressures may be expected due to differences in installations. Significant differences could mean that the system is not properly charged or that a problem exists with some component in the system.

°F (°C)**	XP19-024		XP19-036		XP19-048		XP19-060	
	Liq	Vap	Liq	Vap	Liq	Vap	Liq	Vap
First Stage (Low Capacity)								
40 (4.4)	314	100	316	99	350	98	365	96
50 (10)	334	120	334	117	367	111	388	112
Second Stage (High Capacity)								
20 (-7.0)	304	68	294	64	314	60	346	60
30 (-1.0)	323	82	313	77	331	72	362	72
40 (4.4)	342	98	329	89	358	85	382	85
50 (10)	364	116	344	109	384	107	409	106
First Stage (Low Capacity)								
65 (18.3)	226	152	230	148	210	136	234	135
75 (23.9)	262	151	267	150	242	138	274	137
85 (29.4)	304	152	309	153	286	140	314	142
95 (35.0)	351	155	355	155	328	142	361	147
105 (40.6)	400	158	404	157	374	144	413	147
115 (49.0)	454	161	460	159	426	146	470	149
Second Stage (High Capacity)								
65 (18.3)	228	146	236	144	227	114	237	131
75 (23.9)	267	148	275	145	265	123	276	133
85 (29.4)	309	149	318	148	306	132	320	135
95 (35.0)	358	151	365	150	348	138	369	138
105 (40.6)	410	152	416	153	397	141	423	140
115 (49.0)	465	154	473	155	453	143	482	144

*These are most-popular-match-up pressures. Indoor match up, indoor air quality, and indoor load cause pressures to vary.

**Temperature of the air entering the outside coil.

Table 9. HFC-410A Temperature (°F) - Pressure (Psig)

°F	Psig	°F	Psig	°F	Psig	°F	Psig
32	100.8	63	178.5	94	290.8	125	445.9
33	102.9	64	181.6	95	295.1	126	451.8
34	105.0	65	184.3	96	299.4	127	457.6
35	107.1	66	187.7	97	303.8	128	463.5
36	109.2	67	190.9	98	308.2	129	469.5
37	111.4	68	194.1	99	312.7	130	475.6
38	113.6	69	197.3	100	317.2	131	481.6
39	115.8	70	200.6	101	321.8	132	487.8
40	118.0	71	203.9	102	326.4	133	494.0
41	120.3	72	207.2	103	331.0	134	500.2
42	122.6	73	210.6	104	335.7	135	506.5
43	125.0	74	214.0	105	340.5	136	512.9
44	127.3	75	217.4	106	345.3	137	519.3
45	129.7	76	220.9	107	350.1	138	525.8
46	132.2	77	224.4	108	355.0	139	532.4
47	134.6	78	228.0	109	360.0	140	539.0
48	137.1	79	231.6	110	365.0	141	545.6
49	139.6	80	235.3	111	370.0	142	552.3
50	142.2	81	239.0	112	375.1	143	559.1
51	144.8	82	242.7	113	380.2	144	565.9
52	147.4	83	246.5	114	385.4	145	572.8
53	150.1	84	250.3	115	390.7	146	579.8
54	152.8	85	254.1	116	396.0	147	586.8
55	155.5	86	258.0	117	401.3	148	593.8
56	158.2	87	262.0	118	406.7	149	601.0
57	161.0	88	266.0	119	412.2	150	608.1
58	163.9	89	270.0	120	417.7	151	615.4
59	166.7	90	274.1	121	423.2	152	622.7
60	169.6	91	278.2	122	428.8	153	630.1
61	172.6	92	282.3	123	434.5	154	637.5
62	175.4	93	286.5	124	440.2	155	645.0

INSTALLING SERVICE VALVE CAPS

Disconnect gauge set and re-install all service valve caps.




Figure 33. Installing Service Valve Port Caps

System Operations19

The outdoor unit and indoor blower cycle on demand from the room thermostat. When the thermostat blower switch is in the **ON** position, the indoor blower operates continuously.

THERMOSTAT OPERATION

Some indoor thermostats incorporate isolating contacts and an emergency heat function (which includes an amber indicating light). The thermostat is not included with the unit and must be purchased separately.

EMERGENCY HEAT (AMBER LIGHT)

An emergency heat function is designed into some room thermostats. This feature is applicable when isolation of the outdoor unit is required, or when auxiliary electric heat is staged by outdoor thermostats. When the room thermostat is placed in the emergency heat position, the outdoor unit control circuit is isolated from power and field-provided relays bypass the outdoor thermostats. An amber indicating light simultaneously comes on to remind the homeowner that the unit is operating in the emergency heat mode.

Emergency heat is usually used during an outdoor unit shutdown, but it should also be used following a power outage if power has been off for over an hour and the outdoor temperature is below 50°F (10°C). The system should be left in the emergency heat mode at least six hours to allow the crankcase heater sufficient time to prevent compressor slugging.

FILTER DRIER

The unit is equipped with a large-capacity biflow filter drier which keeps the system clean and dry. If replacement is necessary, order another of like design and capacity.

Lennox System Operation Monitor (LSOM) (100034-1)20

The diagnostic indicator detects the most common fault conditions in the air conditioning system. When an abnormal condition is detected, the module communicates the specific condition through its ALERT and TRIP lights. The module is capable of detecting both mechanical and electrical system problems.

IMPORTANT

This monitor does not provide safety protection. The is a monitoring device only and cannot control or shut down other devices.

LSOM—LED FUNCTIONS

The LSOM LED functions are described as follows:

Table 10. LED Functions

Label	LED Color	Function
Power	Green	Indicates voltage within the range of 19-28VAC is present at the system monitor power connection.
Alert	Yellow	Communicates an abnormal system condition through a unique flash code. The alert LED flashes a number of times consecutively; then pauses; then repeats the process. This consecutive flashing correlates to a particular abnormal condition.
Trip	Red	Indicates there is a demand signal from the thermostat but no current to the compressor is detected by the module.

Refer to Table 12 for the complete explanation of troubleshooting codes.

RESETTING ALERT CODES

Alert codes can be reset manually or automatically:

Manual Reset

Cycle the 24VAC power to LSOM off and on. After power up, existing code will display for 60 seconds and then clear. Manual reset can be achieved by any of the following methods:

- Disconnecting **R** wire from the LSOM's **R** terminal.
- Turning the indoor unit off and on again

Automatic Reset

After an alert is detected, the LSOM continues to monitor the compressor and system. When/if conditions return to normal, the alert code is turned off automatically.

Table 11. LSOM Module LED Troubleshooting Codes

Status LED Condition	Mis-wired Module Indication	Status LED Troubleshooting Information
Green LED ON	Module not powering up.	Determine/verify that both R and C module terminals are connected and voltage is present at both terminals.
Green LED Intermittent	Module powers up only when compressor runs.	Determine if R and Y terminals are wired in reverse. Verify module's R and C terminals have a constant source.
Red LED ON	LED is on but system and compressor check OK.	¹ Verify Y terminal is connected to 24VAC at contactor coil. ² Verify voltage at contactor coil falls below 0.5VAC when off. ³ Verify 24VAC is present across Y and C when thermostat demand signal is present; if not present, R and C wires are reversed.
Red and Yellow LED	Simultaneous flashing.	Indicates that the control circuit voltage is too low for operation. Verify R and C terminals are supplied with 19-28VAC.

Table 12. LSOM System LED Troubleshooting Codes

Status LED Condition	Status LED Description	Status LED Troubleshooting Information
Red LED ON	Thermostat demand signal Y1 is present, but compressor not running	¹ Compressor protector is open. <ul style="list-style-type: none"> • Check for high head pressure • Check compressor supply voltage ² Outdoor unit power disconnect is open. ³ Compressor circuit breaker or fuse(s) is open. ⁴ Broken wire or connector is not making contact. ⁵ Low or high pressure switch open if present in the system. ⁶ Compressor contactor has failed to close.
Yellow Flash Code 1	Long Run Time - Compressor is running extremely long run cycles.	¹ Low refrigerant charge. ² Evaporator blower is not running. <ul style="list-style-type: none"> • Check blower relay coil and contacts • Check blower motor capacitor • Check blower motor for failure or blockage • Check evaporator blower wiring and connectors • Check indoor blower control board • Check thermostat wiring for open circuit ³ Evaporator coil is frozen. <ul style="list-style-type: none"> • Check for low suction pressure • Check for excessively low thermostat setting • Check evaporator airflow (coil blockages or return air filter) • Check ductwork or registers for blockage. ⁴ Faulty metering device. <ul style="list-style-type: none"> • Check TXV bulb installation (size, location and contact) • Check if TXV/fixed orifice is stuck closed or defective ⁵ Condenser coil is dirty ⁶ Liquid line restriction (filter drier blocked if present) ⁷ Thermostat is malfunctioning: <ul style="list-style-type: none"> • Check thermostat sub-base or wiring for short circuit • Check thermostat installation (location and level)
Yellow Flash Code 2	System Pressure Trip - Discharge or suction pressure out of limits or compressor overloaded	¹ High head pressure. <ul style="list-style-type: none"> • Check high pressure switch if present in system • Check if system is overcharged with refrigerant • Check for non-condensable in system ² Condenser coil poor air circulation (dirty, blocked, damaged). ³ Condenser fan is not running. <ul style="list-style-type: none"> • Check fan capacitor • Check fan wiring and connectors • Check fan motor for failure or blockage ⁴ Return air duct has substantial leakage.
Yellow Flash Code 3	Short Cycling - Compressor is running only briefly	¹ Thermostat demand signal is intermittent. ² Time delay relay or control board is defective. ³ If high pressure switch is present, see Flash Code 2 information.

Status LED Condition	Status LED Description	Status LED Troubleshooting Information
Yellow Flash Code 4	Locked Rotor	<ol style="list-style-type: none"> ¹ Run capacitor has failed. ² Low line voltage (contact utility if voltage at disconnect is low). <ul style="list-style-type: none"> • Check wiring connections ³ Excessive liquid refrigerant in the compressor. ⁴ Compressor bearings are seized.
Yellow Flash Code 5	Open Circuit	<ol style="list-style-type: none"> ¹ Outdoor unit power disconnect is open. ² Unit circuit breaker or fuse(s) is open. ³ Unit contactor has failed to close. <ul style="list-style-type: none"> • Check compressor contactor wiring and connectors • Check for compressor contactor failure (burned, pitted or open) • Check wiring and connectors between supply and compressor • Check for low pilot voltage at compressor contactor coil ⁴ High pressure switch is open and requires manual reset. ⁵ Open circuit in compressor supply wiring or connections. ⁶ Unusually long compressor protector reset time due to extreme ambient temperature. ⁷ Compressor windings are damaged. <ul style="list-style-type: none"> • Check compressor motor winding resistance
Yellow Flash Code 6	Open Start Circuit - Current only in run circuit	<ol style="list-style-type: none"> ¹ Run capacitor has failed. ² Open circuit in compressor start wiring or connections. <ul style="list-style-type: none"> • Check wiring and connectors between supply and the compressor S terminal ³ Compressor start winding is damaged. <ul style="list-style-type: none"> • Check compressor motor winding resistance
Yellow Flash Code 7	Open Run Circuit - Current only in start circuit	<ol style="list-style-type: none"> ¹ Open circuit in compressor start wiring or connections. <ul style="list-style-type: none"> • Check wiring and connectors between supply and the compressor R terminal ² Compressor start winding is damaged. <ul style="list-style-type: none"> • Check compressor motor winding resistance
Yellow Flash Code 8	Welded Contactor - Compressor always runs	<ol style="list-style-type: none"> ¹ Compressor contactor failed to open. ² Thermostat demand signal not connected to module.
Yellow Flash Code 9	Low Voltage - Control circuit <17VAC	<ol style="list-style-type: none"> ¹ Control circuit transformer is overloaded. ² Low line voltage (contact utility if voltage at disconnect is low). <ul style="list-style-type: none"> • Check wiring connections

NOTE - Last code will display for 1 minute when power is cycled to module. Power must be on to module for a minimum of 1 minute for code to clear.

NOTE - Upon Y2 signal detection and after 5 seconds, the LSOM module will send 24 VAC to the solenoid. Once the solenoid is fully energized, the LSOM module reduces voltage to between 4 to 18 VDC . Every 15 minutes the solenoid voltage will be increase to 24 volts for a few seconds to ensure solenoid valve is engaged until Y2 signal is no longer present.

Defrost System21

DEFROST SYSTEM DESCRIPTION

The defrost control board (DCB) measures differential temperatures to detect when the system is performing poorly because of ice build-up on the outdoor coil. The controller self-calibrates when the defrost system starts and after each system defrost cycle. The DCB components are illustrated on page 22.

The DCB monitors ambient temperature, outdoor coil temperature, and total run time to determine when a defrost cycle is required. The coil temperature probe is designed with a spring clip to allow mounting to the outside coil tubing. The location of the coil sensor is important for proper defrost operation.

NOTE — The DCB accurately measures the performance of the system as frost accumulates on the outdoor coil. This typically will translate into longer running time between defrost cycles as more frost accumulates on the outdoor coil before the board initiates defrost cycles.

DIAGNOSTIC LEDS

The state (Off, On, Flashing) of two LEDs on the DCB (DS1 [Red] and DS2 [Green]) indicate diagnostics conditions that are described in Table 15.

DCB PRESSURE SWITCH CONNECTIONS

The unit's automatic reset pressure switches (LO PS - S87 and HI PS - S4) are factory-wired into the DCB on the LO-PS and HI-PS terminals, respectively.

Low Pressure Switch (LO-PS)—When the low pressure switch trips, the DCB will cycle off the compressor, and the strike counter in the board will count one strike. The low pressure switch is ignored under the following conditions:

- during the defrost cycle and 90 seconds after the termination of defrost
- when the average ambient sensor temperature is below 15° F (-9°C)
- for 90 seconds following the start up of the compressor
- during TEST mode

High Pressure Switch (HI-PS)—When the high pressure switch trips, the DCB will cycle off the compressor, and the strike counter in the board will count one strike.

DCB PRESSURE SWITCH EVENT SETTINGS

The following pressures are the auto reset event values for low and high pressure thresholds:

High Pressure (auto reset) - trip at 590 psig; reset at 418.

Low Pressure (auto reset) - trip at 25 psig; reset at 40.

FIVE-STRIKE LOCKOUT SAFETY FUNCTION

The five-strike lockout safety function is designed to protect the unit's compressor from damage. The DCB looks for 24VAC on it's Y1 terminal. When the Y1 input is see 24VAC, then internal control logic of the DCB will do the following:

- Count any HI-PS and LO-PS pressure switch trips (open and close). Individual HI-PS and LO-PS trips

are added together for the total number of trips counted by the DCB.

- Up to four pressure switch trips are allowed in a single thermostat demand without locking out the DCB. If the thermostat demand satisfies before a fifth pressure switch trip, the DCB will reset the five-strike counter to zero.
- If either pressure switch opens for a fifth time during the current Y1 input state, the DCB will enter a lockout condition.

The system will require servicing to determine the cause of the pressure switch condition. Once the condition has been rectified, use the following procedure to reset the DCB.

Low Ambient Thermostat Pins - P3 provides selecting of the Y2 compressor lock-in temperature.

DEFROST SYSTEM SENSORS

Sensors connect to the DCB through a field-replaceable harness assembly that plugs into the board. Through the sensors, the DCB detects outdoor ambient, coil, and discharge temperature fault conditions. As the detected temperature changes, the resistance across the sensor changes. Figure 34 shows how the resistance varies as the temperature changes for both type of sensors. Sensor resistance values can be checked by ohming across pins shown in Table 34.




Figure 34. Temperature/Resistance Chart

Table 13. Sensor Temperature / Resistance Range

Sensor	Temperature Range °F (°C)	Resistance values range (ohms)	Pins/Wire Color
Outdoor (Ambient)	-35 (-37) to 120 (48)	280,000 to 3750	3 and 4 (Black)
Coil	-35 (-37) to 120 (48)	280,000 to 3750	5 and 6 (Brown)
Discharge (if applicable)	24 (-4) to 350 (176)	41,000 to 103	1 and 2 (Yellow)

NOTE — Sensor resistance decreases as sensed temperature increases (see Figure 34).

NOTE — When checking the ohms across a sensor, be aware that a sensor showing a resistance value that is not within the range shown in Table 13, may be performing as designed. However, if a shorted or open circuit is detected, then the sensor may be faulty and the sensor harness will need to be replaced.

Defrost Coil Sensor (RT21) — This sensor (shown in Figure 35, Detail A) considers outdoor temperatures below -35°F (-37°C) or above 120°F (48°C) as a fault. If the defrost coil sensor is detected as being open, shorted or out of the temperature range of the sensor, the board will not perform demand or time/temperature defrost operation and will display the appropriate fault code. Heating and cooling operation will be allowed in this fault condition.

Discharge Line Sensor (RT28) — If this sensor exceeds a temperature of 300°F (148°C) during compressor operation, the board will de-energize the compressor contactor output (and the defrost output, if active). The compressor will remain off until the discharge temperature has dropped below 225°F (107°C) and the 5-minute anti-short cycle delay has been satisfied. This sensor has two fault and lockout codes:

1. If the board recognizes five high discharge line temperature faults during a single (Y1) compressor demand, it reverts to a lockout mode and displays the appropriate code. This code detects shorted sensor or high discharge temperatures. Code on board is *Discharge Line Temperature Fault and Lockout*.
2. If the board recognizes five temperature sensor range faults during a single (Y1) compressor demand, it reverts to a lockout mode and displays the appropriate code. The board detects open sensor or out-of-temperature sensor range. This fault is detected by allowing the unit to run for 90 seconds before checking sensor resistance. If the sensor resistance is not within range after 90 seconds, the board will count one fault. After five faults, the board will lockout. Code on board is *Discharge Sensor Fault and Lockout*.

The discharge line sensor (see Figure 35), which covers a range of 150°F (65°C) to 350°F (176°C), is designed to mount on a ½" refrigerant discharge line.

Ambient Sensor (RT13) — The ambient sensor (shown in Figure 35, Detail B) considers outdoor temperatures below -35°F (-37°C) or above 120°F (48°C) as a fault. If the ambient sensor is detected as being open, shorted or out of the temperature range of the sensor, the board will not perform demand defrost operation. The board will revert to time/temperature defrost operation and will display the appropriate fault code. Heating and cooling operation will be allowed in this fault condition.

NOTE — Within a single room thermostat demand, if 5-strikes occur, the board will lockout the unit. DCB 24 volt power **R** must be cycled OFF or the TEST pins on board must be shorted between 1 to 2 seconds to reset the board.




Figure 35. Sensor Locations

Second-Stage Operation — If the board receives a call for second-stage compressor operation **Y2** in heating or cooling mode and the first-stage compressor output is active, the second-stage compressor solenoid output will be energized by the LSOM.

NOTE — Figure 29 illustrates the correct Y2 field wiring configuration.

NOTE — The LSOM has a five second delay between Y2 being powered and the solenoid energizing.

If first-stage compressor output is active in heating mode and the outdoor ambient temperature is below the selected compressor lock-in temperature, the second-stage compressor solenoid output will be energized without the **Y2** room thermostat input.

If the jumper is not connected to one of the temperature selection pins on P3 (40, 45, 50, 55°F), the default lock-in temperature of 40°F (4.5°C) will be used.

The board de-energizes the second-stage compressor solenoid output immediately when the **Y2** signal is removed or the outdoor ambient temperature is 5°F above the selected compressor lock-in temperature, or the first-stage compressor output is de-energized for any reason.

Defrost Temperature Termination Jumper Pins — The DCB selections are: 50, 70, 90, and 100°F (10, 21, 32 and 38°C). The jumper termination pin is factory set at 50°F (10°C). If the temperature jumper is not installed, the default termination temperature is 90°F (32°C).

DELAY MODE

The DCB has a field-selectable function to reduce occasional sounds that may occur while the unit is cycling in and out of the defrost mode. When a jumper is installed on the DELAY pins, the compressor will be cycled off for 30 seconds going in and out of the defrost mode. Units are shipped with jumper installed on DELAY pins.

NOTE — The 30 second off cycle is NOT functional when jumpering the TEST pins.

OPERATIONAL DESCRIPTION

The defrost control board has three basic operational modes: normal, calibration, and defrost.

Normal Mode — The demand DCB monitors the O line, to determine the system operating mode (heat/cool), outdoor ambient temperature, coil temperature (outdoor coil) and compressor run time to determine when a defrost cycle is required.

Calibration Mode — The board is considered uncalibrated when power is applied to the board, after cool mode operation, or if the coil temperature exceeds the termination temperature when it is in heat mode.

Calibration of the board occurs after a defrost cycle to ensure that there is no ice on the coil. During calibration, the temperature of both the coil and the ambient sensor are measured to establish the temperature differential which is required to allow a defrost cycle.

Defrost Mode — The following paragraphs provide a detailed description of the defrost system operation.

DETAILED DEFROST SYSTEM OPERATION

Defrost Cycles — The demand defrost control board initiates a defrost cycle based on either frost detection or time.

- **Frost Detection** — If the compressor runs longer than 30 minutes and the actual difference between the clear coil and frosted coil temperatures exceeds the maximum difference allowed by the control, a defrost cycle will be initiated.

IMPORTANT - The demand defrost control board will allow a greater accumulation of frost and will initiate fewer defrost cycles than a time/temperature defrost system.

- **Time** — If six hours of heating mode compressor run time has elapsed since the last defrost cycle while the coil temperature remains below 35°F (2°C), the demand defrost control will initiate a defrost cycle.

Actuation of Defrost Cycle — The defrost cycle starts when the following occurs:

- Reversing valve is de-energized
- Y1 circuit is energized
- Coil temperature is below 35°F (2°C),
- DCB starts logging the compressor run time.

Calibration success depends on stable system temperatures during the 20-minute calibration period. If the board fails to calibrate, another defrost cycle will be initiated after 45 minutes of heating mode compressor run time. Once the DCB is calibrated, it initiates a demand defrost cycle when the difference between the clear coil and frosted coil temperatures exceeds the maximum difference allowed by the control OR after 6 hours of heating mode compressor run time has been logged since the last defrost cycle.

NOTE - If ambient or coil fault is detected, the board will not execute the TEST mode.

Termination — The defrost cycle ends when the coil temperature exceeds the termination temperature or after 14 minutes of defrost operation. If the defrost is terminated by the 14-minute timer, another defrost cycle will be initiated after 30 minutes of run time.

Test Mode — When Y1 is energized and 24V power is being applied to the board, a test cycle can be initiated by placing the termination temperature jumper across the TEST pins for 2 to 5 seconds. If the jumper remains across the TEST pins longer than 5 seconds, the control will ignore the test pins and revert to normal operation. The jumper will initiate one cycle per test.

NOTE — Coil sensor temperature must be below 35°F before the DCB will initiate a TEST defrost

Each test pin shorting will result in one test event. For each TEST the jumper must be removed for at least 1 second and reapplied. Refer to flow chart (Figure 36) for TEST operation.

NOTE — The Y1 input must be active (ON) and the O room thermostat terminal into board must be inactive.



TEST

Placing the jumper on the test pins allows the technician to:

- Clear short cycle lockout
- Clear five-strike fault lockout
- Cycle the unit in and out of defrost mode
- Place the unit in defrost mode to clear the coil

When Y1 is energized and 24V power is being applied to the Demand Defrost Control, a test cycle can be initiated by placing a jumper on the Demand Defrost Control's TEST pins for 2 to 5 seconds. If the jumper remains on the TEST pins for longer than five seconds, the Demand Defrost Control will ignore the jumpered TEST pins and revert to normal operation.

The control will initiate one test event each time a jumper is placed on the TEST pins. For each TEST the jumper must be removed for at least one second and then reapplied.




NOTE — Placing a jumper on the TEST pins will not bring the unit out of inactive mode. The only way manually activate the heat pump from an inactive mode is to cycle the 24VAC power to the Demand Defrost Control.

Figure 36. Test Mode

DEMAND DEFROST CONTROL BOARD — A10822

NOTE — Component locations may vary by board manufacturer.



DIAGNOSTIC LEDs

Diagnostic LED descriptions are listed in Table 15.

Table 14. Demand Defrost Control — A108 Inputs/Outputs and Jumper Settings

ID	Description	
O OUT	24VAC output connection for reversing valve.	
LO-PS	Connection for low-pressure switch	
W-OUT	24VAC output for second-stage (gas heat) furnace connection	
Y1	24VAC common output, switched to enable compressor contactor.	
H1-PS	Connection for high-pressure switch.	
FAN	240 VAC line voltage connection for condenser fan.	
P1	50	Defrost Termination Settings: Seven position square pin header. The defrost termination temperature is measured by the defrost coil sensor. The jumper termination pin is factory set at 50°F (10°C). If the temperature jumper is not installed, the default termination temperature is 90°F (32°C).
	70	
	90	
	100	
P2	RL	24VAC output for external K229 relay to control blower operation during defrost, heat pump inactive mode, and a call for second-stage (gas heat) furnace operations.
	C	24VAC system common
	W Out	24VAC output to furnace control to begin furnace heating operation.
	R	24VAC system power input
	W In	24VAC thermostat input for second stage (gas heat) furnace operation
	O	24VAC thermostat input for reversing valve operation
Y1	24VAC thermostat input for first-stage compressor operation	
P3	Not used.	
P4	Six position square pin header. P4 provides connections for the temperature sensors.	
	COIL (BROWN)	(PIN 1) Ground connection for outdoor coil temperature sensor. (PIN 2) Connection for outdoor coil temperature sensor.
	AMB (BLACK)	(PIN 3) Ground connection for outdoor ambient temperature sensor. (PIN 4) Connection for outdoor ambient temperature sensor.
	DIS (YELLOW)	(PIN 5 and PIN 6) Harness resistor fault — 10K resistor. 10K resistor built into wiring harness connected to the DIS connector.
P5	For factory test.	
P6	Eight-position header. Provides connections for the factory test.	

DCB DIAGNOSTICS

See Table 15 to determine DCB operational conditions and to diagnose cause and solution to problems.

Table 15. Defrost Control Board Diagnostic LEDs

DS2 Green	DS1 Red	Condition/Code	Possible Cause(s)	Solution
OFF	OFF	Power problem	No power (24V) to board terminals R and C or board failure.	¹ Check control transformer power (24V). ² If power is available to board and LED(s) do not light, replace board.
Simultaneous SLOW Flash		Normal operation	Unit operating normally or in standby mode.	None required.
Alternating SLOW Flash		5-minute anti-short cycle delay	Initial power up, safety trip, end of room thermostat demand.	None required (Jumper TEST pins to override)
Simultaneous FAST Flash		Ambient Sensor Problem	Sensor being detected open or shorted or out of temperature range. Board will revert to time/temperature defrost operation. (System will still heat or cool).	
Alternating FAST Flash		Coil Sensor Problem	Sensor being detected open or shorted or out of temperature range. Board will not perform demand or time/temperature defrost operation. (System will still heat or cool).	
ON	ON	Circuit Board Failure	Indicates that board has internal component failure. Cycle 24 volt power to board. If code does not clear, replace board.	

FAULT and LOCKOUT CODES (Each fault adds 1 strike to that code's counter; 5 strikes per code = LOCKOUT)

OFF	SLOW Flash	Low Pressure Fault	¹ Restricted air flow over indoor or outdoor coil. ² Improper refrigerant charge in system. ³ Improper metering device installed or incorrect operation of metering device. ⁴ Incorrect or improper sensor location or connection to system.	¹ Remove any blockages or restrictions from coils and/or fans. Check indoor and outdoor fan motor for proper current draws. ² Check system charge using approach and subcooling temperatures. ³ Check system operating pressures and compare to unit charging charts. ⁴ Make sure all pressure switches and sensors have secure connections to system to prevent refrigerant leaks or errors in pressure and temperature measurements.
OFF	ON	Low Pressure Discharge Sensor Lockout		
SLOW Flash	OFF	High Pressure Fault		
ON	OFF	High Pressure Discharge Sensor Lockout		
SLOW Flash	ON	Discharge Line Temperature Fault	This code detects shorted sensor or high discharge temperatures. If the discharge line temperature exceeds a temperature of 300°F (148°C) during compressor operation, the board will de-energize the compressor contactor output (and the defrost output if active). The compressor will remain off until the discharge temperature has dropped below 225°F (107°C).	
FAST Flash	ON	Discharge Line Temperature Discharge Sensor Lockout		
OFF	Fast Flash	Discharge Sensor Fault	The board detects open sensor or out of temperature sensor range. This fault is detected by allowing the unit to run for 90 seconds before checking sensor resistance. If the sensor resistance is not within range after 90 seconds, the board will count one fault. After 5 faults, the board will lockout.	
Fast Flash	OFF	Discharge Sensor Discharge Sensor Lockout		

Maintenance23

WARNING



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

Before the start of each heating and cooling season, the following service checks should be performed by a qualified service technician. First, turn off electrical power to the unit prior to performing unit maintenance.

- Inspect and clean the outdoor and indoor coils. The outdoor coil may be flushed with a water hose.

NOTE — It may be necessary to flush the outdoor coil more frequently if it is exposed to substances which are corrosive or which block airflow across the coil (e.g., pet urine, cottonwood seeds, etc.)

- Visually inspect the refrigerant lines and coils for leaks.
- Check wiring for loose connections.
- Check voltage at the indoor and outdoor units (with units operating).
- Check the amperage draw at the outdoor fan motor, compressor, and indoor blower motor. Values should be compared with those given on unit nameplate.
- Check, clean (or replace) indoor unit filters.
- Check the refrigerant charge and gauge the system pressures.
- Check the condensate drain line for free and unobstructed flow; clean, if necessary.

- Outdoor unit fan motor is prelubricated and sealed. No further lubrication is needed.

NOTE — If owner reports insufficient cooling, the unit should be gauged and refrigerant charge checked. Refer to section on refrigerant charging in this instruction.

Two-Stage Modulation Compressors²⁴

⚠ IMPORTANT

This performance check is ONLY valid on systems that have clean indoor and outdoor coils, proper airflow over coils, and correct system refrigerant charge. All components in the system must be functioning proper to correctly perform compressor modulation operational check. (Accurate measurements are critical to this test as indoor system loading and outdoor ambient can affect variations between low and high capacity readings).

Use this check-out procedure to verify part- and full-load capacity operation of two-stage modulation compressors.

TOOLS REQUIRED

- Refrigeration gauge set
- Digital volt/amp meter
- Electronic temperature thermometer
- On-off toggle switch

PROCEDURE

1. Turn main power OFF to outdoor unit.
2. Adjust room thermostat set point 5°F above (heating operation) or 5°F below (cooling operation) the room temperature.
3. Remove control access panel. Install refrigeration gauges on unit. Attach the amp meter to the common (black wire) wire of the compressor harness. Attach thermometer to discharge line as close as possible to the compressor.
4. Turn toggle switch OFF. Install switch in series with Y2 wire from room thermostat (see note ** in the *Field Operational Checklist* on page 26).
5. Cycle main power ON.
6. Allow pressures and temperatures to stabilize before taking any measured reading (may take up to 10 minutes).
7. Record all of the readings for the Y1 demand.
8. Close switch to energize Y2 demand. Verify power is going to compressor solenoid (see note ** in the *Field Operational Checklist* on page 26).
9. Allow pressures and temperatures to stabilize before taking any measured reading (this may take up to 10 minutes).
10. Record all of the readings with the Y1 and Y2 demand.
11. If temperatures and pressures change in the direction noted in chart, the compressor is properly modulating from low to high capacity. (If no amperage, pressures or temperature readings change when this test is

performed, the compressor is not modulating between low and high capacity and replacement is necessary).

12. After testing is complete, return unit to original set up.

Homeowner Information - Maintenance²⁵

In order to ensure peak performance, your system must be properly maintained. Clogged filters and blocked airflow prevent your unit from operating at its most efficient level.

1. **Air Filter** — Ask your Lennox dealer to show you where your indoor unit's filter is located. It will be either at the indoor unit (installed internal or external to the cabinet) or behind a return air grille in the wall or ceiling. Check the filter monthly and clean or replace it as needed.
2. **Disposable Filter** — Disposable filters should be replaced with a filter of the same type and size.

NOTE - If you are unsure about the filter required for your system, call your Lennox dealer for assistance.

⚠ IMPORTANT

Turn off electrical power to the unit at the disconnect switch before performing any maintenance. The unit may have multiple power supplies.

3. **Reusable Filter** — Many indoor units are equipped with reusable foam filters. Clean foam filters with a mild soap and water solution; rinse thoroughly; allow filter to dry completely before returning it to the unit or grille.

NOTE — The filter and all access panels must be in place any time the unit is in operation.

4. **Electronic Air Cleaner** — Some systems are equipped with an electronic air cleaner, designed to remove airborne particles from the air passing through the cleaner. If your system is so equipped, ask your dealer for maintenance instructions.
5. **Indoor Unit** — The indoor unit's evaporator coil is equipped with a drain pan to collect condensate formed as your system removes humidity from the inside air. Have your dealer show you the location of the drain line and how to check for obstructions. (This would also apply to an auxiliary drain, if installed.)

⚠ IMPORTANT

Sprinklers and soaker hoses should not be installed where they could cause prolonged exposure to the outdoor unit by treated water. Prolonged exposure of the unit to treated water (i.e., sprinkler systems, soakers, waste water, etc.) will corrode the surface of steel and aluminum parts and diminish performance and longevity of the unit.

6. **Outdoor Unit** — Make sure no obstructions restrict airflow to the outdoor unit. Leaves, trash or shrubs crowding the unit cause the outdoor unit to work harder and use more energy. Keep shrubbery trimmed away from the unit and periodically check for debris which collects around the unit.

When removing debris from around the unit, be aware of metal edges on parts and screws. Although special care has been taken to keep exposed edges to a minimum, physical contact with metal edges and corners while applying excessive force or rapid motion can result in personal injury.

Cleaning of the outdoor unit's coil should be performed by a trained service technician. Contact your dealer and set up a schedule (preferably twice a year, but at least once a year) to inspect and service your heat pump system.

HEAT PUMP OPERATION

Your new Lennox heat pump has several characteristics that you should be aware of:

- Heat pumps satisfy heating demand by delivering large amounts of *warm* air into the living space. This is quite different from gas- or oil-fired furnaces or an electric furnace which deliver lower volumes of considerably *hotter* air to heat the space.
- Do not be alarmed if you notice frost on the outdoor coil in the winter months. Frost develops on the outdoor coil during the heating cycle when temperatures are below 45°F (7°C). An electronic control activates a defrost cycle lasting 5 to 15 minutes at preset intervals to clear the outdoor coil of the frost.
- During the defrost cycle, you may notice steam rising from the outdoor unit. This is a normal occurrence. The thermostat may engage auxiliary heat during the defrost cycle to satisfy a heating demand; however, the unit will return to normal operation at the conclusion of the defrost cycle.

EXTENDED POWER OUTAGE

The heat pump is equipped with a compressor crankcase heater which protects the compressor from refrigerant *slugging* during cold weather operation.

If power to your unit has been interrupted for several hours or more, set the room thermostat selector to the EMERGENCY HEAT setting to obtain temporary heat without the risk of serious damage to the heat pump.

In EMERGENCY HEAT mode, all heating demand is satisfied by auxiliary heat; heat pump operation is locked out. After a six-hour compressor crankcase warm-up period, the thermostat can be switched to the HEAT setting and normal heat pump operation may resume.

THERMOSTAT OPERATION

Though your thermostat may vary somewhat from the description below, its operation will be similar.

Temperature Setting Levers

Most heat pump thermostats have two temperature selector levers: one for heating and one for cooling. Set the levers or dials to the desired temperature setpoints for both heating and cooling. Avoid frequent temperature adjustment; turning the unit off and back on before pressures equalize puts stress on the unit compressor.

Fan Switch

In AUTO or INT (intermittent) mode, the blower operates only when the thermostat calls for heating or cooling. This mode is generally preferred when humidity control is a priority. The ON or CONT mode provides continuous indoor blower operation, regardless of whether the compressor or auxiliary heat are operating. This mode is required when constant air circulation or filtering is desired.

System Switch

Set the system switch for heating, cooling or auto operation. The auto mode allows the heat pump to automatically switch from heating mode to cooling mode to maintain predetermined comfort settings. Many heat pump thermostats are also equipped with an emergency heat mode which locks out heat pump operation and provides temporary heat supplied by the auxiliary heat.

Indicating Light

Most heat pump thermostats have an amber light which indicates when the heat pump is operating in the emergency heat mode.

Temperature Indicator

The temperature indicator displays the actual room temperature.

PROGRAMMABLE THERMOSTATS

Your Lennox system may be controlled by a programmable thermostat. These thermostats provide the added feature of programmable time-of-day setpoints for both heating and cooling. Refer to the user's information manual provided with your particular thermostat for operation details.

PRESERVICE CHECK

If your system fails to operate, check the following before calling for service:

- Check to see that all electrical disconnect switches are ON.
- Make sure the room thermostat Temperature Selector and System Switch (Heat, Cool, Auto) are properly set.
- Check for any blown fuses or tripped circuit breakers.
- Make sure unit access panels are in place.
- Make sure air filter is clean.
- If service is needed, locate and write down the unit model number and have it handy before calling.

OPTIONAL ACCESSORIES

Optional accessories for the XP19 include the following (see the XP19 Engineering Handbook for more details):

- Timed-off control
- Low ambient kit
- Top cap snow cover
- Snow Guard (X8782)
- Snow Shield Kit (44W14)

XP19 Field Operational Checklist26

Unit Readings	Cooling***			Heating***		
	Y1 - 1st-Stage	Expected results during Y2 demand (Toggle switch On)	Y2 - 2nd-Stage	Y1 - 1st-Stage	Expected results during Y2 demand (Toggle switch On)	Y2 - 2nd-Stage
Compressor						
Voltage		Same			Same	
Amperage		Higher			Higher	
Condenser Fan motor						
Amperage		Same or Higher			Same or Higher	
Temperature						
Ambient		Same			Same	
Outdoor Coil Discharge Air		Higher			Lower	
Compressor Discharge Line		Higher			Higher	
Indoor Return Air		Same			Same	
Indoor Coil Discharge Air		Lower			Higher	
Pressures						
Suction (Vapor)		Lower			Down	
Liquid		Higher			Higher	

Note - Heat pump may have a low ambient control or DCB that locks in second stage below its set point. It may be necessary to remove a wire from the control when performing this check out.

** On the XP19 units, the Lennox System Operational Module controls the 2nd stage solenoid coil in compressor.

*** Cooling Mode Operation - Block outdoor coil to maintain a minimum of 375 psig during testing.
 Heating Mode Operation - Block indoor coil to maintain a minimum of 375 psig during testing.

XP19 Start-Up and Performance Checklist27

Customer _____ Address _____
 Indoor Unit Model _____ Serial _____
 Outdoor Unit Model _____ Serial _____
 Notes: _____

START-UP CHECKS
 Refrigerant Type: ____
 Rated Load Amps ____ Actual Amps _____ Rated Volts _____ Actual Volts _____
 Condenser Fan Full Load Amps _____ Actual Amps: _____

COOLING MODE
 Vapor Pressure: ____ Liquid Pressure: _____
 Supply Air Temperature: _____ Ambient Temperature: _____ Return Air Temperature: _____

HEATING MODE
 Vapor Pressure: ____ Liquid Pressure: _____
 Supply Air Temperature: _____ Ambient Temperature: _____ Return Air Temperature: _____

System Refrigerant Charge (Refer to manufacturer's information on unit or installation instructions for required subcooling and approach temperatures.)

Subcooling:	A	B	SUBCOOLING
Saturated Condensing Temperature (A) minus Liquid Line Temperature (B)	—	=	
Approach:	A	B	APPROACH
Liquid Line Temperature (A) minus Outdoor Air Temperature (B)	—	=	
Indoor Coil Temp. Drop (18 to 22°F)	A	B	COIL TEMP DROP
Return Air Temperature (A) minus Supply Air Temperature (B)	—	=	