





















NOTES:

- (A) Circulator Switch Relay-Typical Controller
- B An aquastat (Honeywell L6006 or equivalent) can be used to switch on the Fan Coil's Fan. Typically set to 140 °F (60 °C).
- Example B Notes: Due to the many variables of furnace manufacturers, heating systems, and air handlers, control wiring and set-up needs to be installed by a qualified HVAC professional.

This is only a **concept** drawing. Final design, installation and code compliance details are the responsibility of the designer/installer of the system.