

**Installation Instructions**

**Single Stage Condensing Furnaces**



**\*SC Upflow/Horizontal Model**



**\*SL Downflow Model**

**⚠ WARNING:**

- **PROPOSITION 65 WARNING:** This product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.
- **This furnace is not approved for installation in mobile homes. Installing this furnace in a mobile home could cause fire, property damage, and/or personal injury.**

**ATTENTION INSTALLERS:**

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation/service personnel for this type of equipment. Please read all instructions carefully before starting the installation. Return these instructions to the customer's package for future reference.

**⚠ WARNING:**

**FIRE OR EXPLOSION HAZARD**

- **Failure to follow safety warnings exactly could result in serious injury or property damage.**
- **Installation and service must be performed by a qualified installer, service agency or the gas supplier.**
- **Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.**

**WHAT TO DO IF YOU SMELL GAS**

- **Do not try to light any appliance.**
- **Do not touch any electrical switch; do not use any phone in your building.**
- **Leave the building immediately.**
- **Immediately call your gas supplier from a neighbors phone. Follow the gas suppliers instructions.**
- **If you cannot reach your gas supplier, call the fire department.**

**DO NOT DESTROY.**

**KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.**

## TABLE OF CONTENTS

<b>SAFETY INFORMATION</b> .....	<b>FURNACE INSTALLATION</b> .....
<b>5</b>	<b>14</b>
<b>REQUIREMENTS AND CODES</b> .....	General Requirements .....
<b>5</b>	14
<b>GENERAL INSTRUCTIONS</b> .....	Vent and Inducer Assembly Options .....
<b>6</b>	14
Combustion Air Quality .....	Inducer Assembly Rotation .....
6	14
Operation of Furnace During Construction.....	Pressure Switch Relocation .....
6	15
Installation in a Garage.....	Special Instructions for SC038-23A
7	Furnaces .....
Heating Load.....	15
7	Condensate Drain Lines.....
Clearances to Combustible Materials.....	16
7	Direct Vent (2 - Pipe) Applications .....
<b>COMBUSTION AIR REQUIREMENTS</b> .....	16
<b>7</b>	Upflow Installation.....
General Information.....	16
7	Side Return Air Inlet .....
Conventional Furnaces - Confined Spaces .....	16
8	Bottom Return Air Inlet .....
Outdoor Air Using Vertical Ducts .....	16
8	Horizontal Installation .....
Outdoor Air Using Horizontal Ducts.....	16
8	Bottom Panel Removal .....
Outdoor Air from a Crawl Space or	17
Vented Attic.....	Downflow Installation .....
8	17
Air Directly Through an Exterior Wall .....	Installation on a Concrete Slab.....
8	18
Alternate Method of Providing air from	<b>CIRCULATING AIR REQUIREMENTS</b> .....
Outside .....	<b>18</b>
9	Plenums and Air Ducts .....
Air From Inside.....	18
9	Supply Air Connections .....
Conventional Furnaces - Unconfined Spaces .....	19
10	Upflow/Horizontal Furnaces .....
Direct Vent Furnaces .....	19
10	Downflow Furnaces.....
<b>VENTING REQUIREMENTS</b> .....	19
<b>11</b>	Return Air Connections .....
Vent Pipe Material .....	19
11	Upflow/Horizontal Furnaces .....
Vent Pipe Length and Diameter.....	19
11	Side Return Installations .....
Vent Pipe Installation .....	19
12	Bottom Return Installations .....
Outdoor Terminations - Horizontal Venting .....	19
12	Downflow Furnaces.....
Outdoor Terminations - Vertical Venting.....	19
12	Acoustical Treatments.....
Vent Freezing Protection .....	19
13	<b>GAS SUPPLY AND PIPING</b> .....
Condensate Disposal .....	<b>20</b>
13	Leak Check .....
Existing Installations.....	20
14	High-Altitude Application.....
	20
	Conversion to LP/Propane .....
	21

<b>ELECTRICAL WIRING.....</b>	<b>22</b>	Electrical Information .....	33
Low Voltage Wiring .....	22	Table 6 - Wire length and Voltage Specs.....	33
Line Voltage Wiring .....	22	Table 7 - Control Board Fault Codes .....	33
Grounding .....	23	Figure 24 - Wiring Diagram .....	34
Twinning.....	23	Gas Information .....	35
<b>START-UP &amp; ADJUSTMENTS.....</b>	<b>23</b>	Table 8 - Gas Flow Rates .....	35
Pre-Start Checklist.....	23	Table 9 - Gas Pipe Capacities .....	35
Start-Up Procedures .....	23	Table 10 - High Altitude Deration Chart for Propane Gas .....	36
Verifying and Adjusting Input Rate.....	23	Table 11 - Natural Gas Heating Values .....	36
Verifying and Adjusting Temperature Rise .....	24	Table 12 - High Altitude Deration Chart for Nat. Gas - High Heating Values.....	37
Verifying Burner Operation .....	24	Table 13 - High Altitude Deration Chart for Nat. Gas - Low Heating Values.....	37
Verifying Operation of the supply Air Limit Switch.....	24	Venting Information .....	38
<b>OPERATING SEQUENCE .....</b>	<b>25</b>	Table 14 - Vent Termination Clearances.....	38
Heating Cycle .....	25	Figure 25 - Upflow Options.....	39
Cooling Cycle.....	25	Figure 26 - Horizontal Options - 1 Pipe Furnaces.....	40
Fan Mode.....	25	Figure 27 - Horizontal Options - 2-pipe Furnaces.....	41
<b>MAINTENANCE .....</b>	<b>25</b>	Figure 28 - Downflow Options .....	42
Air Filters.....	25	Figure 29 - Horizontal and Vertical Venting .....	43
Blower Compartment.....	25	Figure 30 - Optional PVC Pipe Installation.....	44
Cleaning of Burners .....	26	Table 15 - Vent Pipe Lengths .....	44
Heat Exchanger and Burner Maintenance.....	26	Accessories .....	45
Lubrication .....	26	Figure 31 - Finish Flanges.....	45
Vent System.....	26	Figure 32 - Rubber Grommets.....	45
<b>TROUBLESHOOTING .....</b>	<b>26</b>	Figure 33 - PVC TEE, Reducer & Hose Barb.....	45
<b>DESCRIPTION OF COMPONENTS .....</b>	<b>27</b>	Location of Furnace Components.....	46
<b>FIGURES AND TABLES .....</b>	<b>27</b>	Figure 34 - Upflow/Horizontal Gas Furnace Components.....	46
Table 3 - Minimum Clearances to Combustible Materials.....	27	Figure 35 - Downflow Gas Furnace Components.....	46
Furnace Dimensions.....	28	<b>INSTALLATION/PERFORMANCE CHECKLIST .....</b>	<b>48</b>
Figure 22 - Upflow/Horizontal Furnaces .....	28		
Figure 23 - Downflow Furnaces.....	29		
Airflow Data.....	30		
Table 4 - Upflow/Horizontal Models .....	30		
Table 5 - Downflow Models .....	32		



## SAFETY INFORMATION

Safety markings are used frequently throughout this manual to designate a degree or level of seriousness and should not be ignored. **WARNING** indicates a potentially hazardous situation that if not avoided, could result in personal injury or death. **CAUTION** indicates a potentially hazardous situation that if not avoided, may result in minor or moderate injury or property damage.

---

 **WARNING:**

---

**The safety information listed below must be followed during the installation, service, and operation of this furnace. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.**

---

- Use only with type of gas approved for this furnace. Refer to the furnace rating plate.
- Install this furnace only in a location and position as specified in Table 3 (page 27).
- Provide adequate combustion and ventilation air to the furnace space as specified on pages 7 - 10.
- Provide adequate clearances around the vent air intake terminal as specified in Figures 6 - 9 (page 13).
- Combustion products must be discharged outdoors. Connect this furnace to an approved vent system only, as specified on Pages 11 - 14.
- Never test for gas leaks with an open flame. Use a commercially available soap solution to check all connections (page 19).
- This furnace is designed to operate with a maximum external pressure rise of 0.5 inches of water column. Consult Tables 4 and 5 (pages 30 & 32), and the rating plate for the proper circulating air flow and temperature rise. It is important that the duct system be designed to provide the correct flow rates and external pressure rise. An improperly designed duct system can result in nuisance shutdowns, and comfort or noise issues.
- When supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating in the conditioned space.
- A gas-fired furnace for installation in a residential garage must be installed as specified on Page 7.
- This furnace may be used for temporary heating of buildings or structures under construction. See the guidelines listed on page 6.

## REQUIREMENTS and CODES

**This furnace must be installed in accordance with these instructions, all applicable local building codes and the current revision of the National Fuel Gas Code (NFPA54/ANSI Z223.1) or the Natural Gas and Propane Installation Code, CAN/CGA B149.1.**

Additional codes listed below are for reference purposes only and do not necessarily have jurisdiction over local or state codes. Always consult with local authorities before installing any gas appliance.

### Combustion and Ventilation Air

- US: National Fuel Gas Code (NFGC), Air for Combustion and Ventilation
- CANADA: Natural Gas and Propane Installation Codes (NSCNGPIC), Venting Systems and Air Supply for Appliances

### Duct Systems

- US and CANADA: Air Conditioning Contractors Association (ACCA) Manual D, Sheet Metal and Air Conditioning Contractors National Association (SMACNA), or American Society of Heating, Refrigeration, and Air Conditioning Engineers (ASHRAE) Fundamentals Handbook

### Electrical Connections

- US: National Electrical Code (NEC) ANSI/NFPA 70
- CANADA: Canadian Electrical Code CSA C22.1

### Gas Piping and Gas Pipe Pressure Testing

- US: NFGC and National Plumbing Codes
- CANADA: NSCNGPIC

### General Installation

- US: Current edition of the NFGC and the NFPA 90B. For copies, contact the National Fire Protection Association Inc., Batterymarch Park, Quincy, MA 02269; or American Gas Association, 400 N. Capitol, N.W., Washington DC 20001 or [www.NFPA.org](http://www.NFPA.org)
- CANADA: NSCNGPIC. For a copy, contact Standard Sales, CSA International, 178 Rexdale Boulevard, Etobicoke (Toronto), Ontario, M9W 1R3 Canada

### Safety

- US: (NFGC) NFPA 54–1999/ANSI Z223.1 and the Installation Standards, Warm Air Heating and Air Conditioning Systems ANSI/NFPA 90B.
- CANADA: CAN/CGA-B149.1 and .2–M00 National Standard of Canada. (NSCNGPIC)

## GENERAL INSTRUCTIONS

### Combustion Air Quality

---

#### CAUTION:

**Combustion air must not be drawn from a corrosive atmosphere.**

---

To maximize heat exchanger life, the combustion air must be free of chemicals that can form corrosive acidic compounds in the combustion gases. The recommended source of combustion air is to use outdoor air. However, the use of indoor air in most applications is acceptable except as listed:

- If the furnace is installed as a single pipe installation in a confined space, it is required that the necessary combustion air come from the outdoors by way of attic, crawl space, air duct, or direct opening. For installations in confined spaces see pages 8 - 9 for combustion air requirements.
- Installations in these locations may require outdoor air for combustion, due to chemical exposures:
  - Commercial buildings
  - Buildings with indoor pools
  - Furnaces installed in laundry rooms
  - Furnaces installed in hobby or craft rooms
  - Furnaces installed near chemical storage areas
- Exposure to the following substances in the combustion air supply may require outdoor air for combustion:
  - Permanent wave solutions
  - Chlorinated waxes and cleaners
  - Chlorine based swimming pool chemicals
  - Water softening chemicals
  - De-icing salts or chemicals
  - Carbon Tetrachloride
  - Halogen type refrigerants
  - Cleaning solvents (perchloroethylene)
  - Printing inks, paint removers, varnishes, etc.
  - Hydrochloric Acid
  - Cements and glues
  - Antistatic fabric softeners
  - Masonry acid washing materials

### Operation of Furnace During Construction

---

#### CAUTION:

**Failure to follow these instructions will void the factory warranty and may significantly reduce the life or the performance of the furnace, and/or result in other unsafe conditions. It is the responsibility of the installing contractor to insure these provisions are met.**

---

Operating gas furnaces in construction environments can cause a variety of problems with the furnace. Proper use of commercial portable space heating equipment during construction is recommended. This gas furnace may be used during construction if it is not in violation of any applicable codes and the following criteria are met:

- The installation must meet all applicable codes. The furnace must be permanently installed according to the instructions supplied with the furnace including electrical supply, gas supply, duct work and venting. The furnace must be controlled by a thermostat properly installed according to the instructions supplied with the furnace and thermostat. The installation must include a properly installed filter in the return air system with no by-pass air. The filter must be inspected frequently and replaced when necessary.
- Combustion air must be supplied from outside the structure and located such that dust and gases from construction activity are not introduced into the combustion system.
- Provisions must be made to insure that condensate does not freeze in the furnace or condensate drain lines during operation and during idle times; for example, overnight if turned off. (Condensing furnaces only)
- Before occupying the structure: The filter must be replaced or cleaned, the duct work must be inspected and cleaned of any construction debris, and the furnace must be cleaned and/or repaired if found to be dirty, damaged, or malfunctioning in any way by a qualified HVAC technician. The furnace shall be inspected and approved by applicable local authority even if this requires redundant inspections.
- Serial numbers for furnaces used during construction must be submitted in writing (fax and email also acceptable). This information will be used to track the long-term affects of the use during construction on furnaces. Proof of this submittal shall be available for the final inspection of the furnace prior to occupancy.
- This furnace is designed to operate with return air temperatures in ranges normally found in occupied residences, including setbacks. Minimum continuous return temperature must not be below 60° F (15° C). Occasionally a temporary return temperature of 55° F (12° C) is acceptable. However, operation with a return temperature below 55° F (12° C) is not allowed.

## Installation in a Garage

---

### **WARNING:**

**Do not place combustible material on or against the furnace cabinet or within 6 inches of the vent pipe. Do not place combustible materials, including gasoline or any other flammable vapors and liquids, in the vicinity of the furnace.**

---

This Gas-fired furnace may be installed in a residential garage with the provision that the burners and igniter are located no less than 18 inches (457mm) above the floor. The furnace must be located or protected to prevent physical damage by vehicles.

#### Heating Load

This furnace should be sized to provide the design heating load requirement. Heating load estimates can be made using approved methods available from Air Conditioning Contractors of America (Manual J); American Society of Heating, Refrigerating, and Air Conditioning Engineers; or other approved engineering methods. **Excessive oversizing of the furnace could cause the furnace and/or vent to fail prematurely.** In addition, the ductwork should be appropriately sized to the capacity of the furnace to ensure its proper airflow rating. For installations above 2,000 ft., the furnace should have a sea level input rating large enough that it will meet the heating load after deration for altitude.

#### Clearances to Combustible Materials

This furnace is Design Certified in the U.S. and Canada by CSA International for the minimum clearances to combustible material listed in Table 3 (page 27). To obtain model number and specific clearance information, refer to the furnace rating plate, located inside of the furnace cabinet.

Access for positioning and servicing the unit must be considered when locating unit. The minimum required clearance from the front of the unit for servicing is 24 inches. The minimum required clearance for positioning is 30 inches from the front of the unit. **The recommended clearance from the front of the unit is 36 inches.** The need to provide clearance for access to panels or doors may require clearance distances over and above the requirements.

## COMBUSTION AIR REQUIREMENTS

### General Information

---

### **WARNING:**

**Furnace installation using methods other than those described in the following sections must comply with the National Fuel Gas Code (NFGC) and all applicable local codes.**

---

- Instructions for determining the adequacy of an installation can be found in the current revision of the NFGC (ANSI Z223.1 / NFPA54). **Consult local codes for special requirements.** These requirements are for US installations as found in the NFGC.
- The requirements in Canada (B149.1) are structured differently. Consult with B149.1 and local code officials for Canadian installations.
- Additional reference information for US and Canadian installations can be found in the Combustion and Ventilation Air section (page 5).

This condensing furnace is certified for installation either as a Direct Vent (2-pipe) or Conventional (1-pipe) appliance. Direct Vent appliances draw combustion air from the outdoors and vent combustion products back outside. Installation with air taken from around the furnace is often referred to as Conventional installation - i.e. only the vent (exhaust) pipe is provided.

Provisions must be made during the installation of this furnace that provide an adequate supply of air for combustion. The combustion air from the outside needs to be clear of chemicals that can cause corrosion. The inlet pipe should not be placed near corrosive chemicals such as those listed on page 6.

Another important consideration when selecting one or two pipe installation is the quality of the Indoor air which can sometimes be contaminated with various household chemicals. These chemicals can cause severe corrosion in the furnace combustion system. A 2-pipe installation has the additional advantage that it isolates the system from the effects of negative pressure in the house.

**NOTE:** Air openings on top of the furnace and openings in closet doors or walls must never be restricted. If the furnace is operated without adequate air for combustion, the flame roll-out switch will open, turning off the gas supply to the burners. This safety device is a manually reset switch. **DO NOT install jumper wires across these switches to defeat their function or reset a switch without identifying and correcting the fault condition.** If a switch must be replaced, use only the correct sized part specified in the Replacement Parts List provided online.

**⚠ CAUTION:**

Exhaust fans, clothes dryers, fireplaces and other appliances that force air from the house to the outdoors can create a negative pressure inside the house, resulting in improper furnace operation or unsafe conditions such as flame roll out. It is imperative that sufficient air exchange with the outdoors is provided to prevent depressurization. Additional information about how to test for negative pressure problems can be found in the NFGC.

**Conventional Furnaces - Confined Spaces**

A confined space is an area with volume less than 50 cubic feet per 1,000 Btuh of the combined input rates of all appliances drawing combustion air from that space. Furnace closets, small equipment rooms and garages are confined spaces. Furnaces installed in a confined space which supply heated air to areas outside the space must draw return air from outside the space and must have the return air ducts tightly sealed to the furnace.

The required sizing of these openings is determined by whether inside or outside air is used to support combustion, the method by which the air is brought to the space, and by the total input rate of all appliances in the space. In all cases, the minimum dimension of any combustion air opening is 3 inches.

Outdoor Air Using Vertical Ducts

If combustion air is taken from outdoors through vertical ducts, the openings and ducts must have a minimum free area of one square inch per 4,000 Btuh of total appliance input (Figure 1).


Outdoor Air Using Horizontal Ducts

If combustion air is taken from outdoors through horizontal ducts, the openings and ducts must have a minimum free area of one square inch per 2,000 Btuh of total appliance input (Figure 2). Ducts must have cross-sectional area at least as large as the free area of their respective openings to the furnace space.


Ducts must have cross-sectional area at least as large as the free area of their respective openings to the furnace space. Attics or crawl spaces must connect freely with the outdoors if they are the source of air for combustion and ventilation.

Outdoor Air from a Crawl Space or Vented Attic

When the openings can freely exchange air with the outdoors, each opening shall have a minimum free area of 1 square inch per 4,000 Btuh of total appliance input. The openings shall exchange directly, or by ducts, with the outdoor spaces (crawl or attic) that freely exchange with the outdoors (Figure 3, page 9).



**Figure 1. Combustion Air Drawn from Outside Through Vertical Ducts**



**Figure 2. Combustion Air Drawn from Outside Through Horizontal Ducts**

Air Directly Through An Exterior Wall

If combustion air is provided directly through an exterior wall, the two openings must each have free area of at least one square inch per 4,000 Btuh of total appliance input (Figure 4, page 9).




Alternate Method of Providing Air from Outside:

If acceptable under local Codes, it is permitted to provide outside air using one opening (See NFGC).


Generally, confined spaces must have two openings in the space for combustion air. One opening must be within 12 inches of the ceiling, and the other must be within 12 inches of the floor. However, an alternative method recently adopted by the NFGC uses one opening within 12 inches of the top of the space. This method may be used if it is acceptable to the local codes.

**The following conditions must be met:**

1. The opening must start within 12" of the top of the structure and connect with the out of doors through vertical or horizontal ducts or be ducted to a crawl or attic space that connects with the out of doors.
2. The opening must have a minimum free area of 1 sq. in. per 3,000 Btu per hour of the total input rating of all equipment located in the enclosure.
3. The free area must not be less than the sum of all the areas of the vent connectors in the enclosure.




**Figure 4. Combustion Air Drawn from Outside Through an Exterior Wall**



**Figure 3. Combustion Air Drawn from a Crawl Space or Vented Attic**

Air From Inside

If combustion air is taken from the heated space, the two openings must each have a free area of at least one square inch per 1,000 Btuh of total input of all appliances in the confined space, but **not less than** 100 square inches of free area (Figure 5). For example, if the combined input rate of all appliances is less than or equal to 100,000 Btuh, each opening must have a free area of at least 100 square inches. If the combined input rate of all appliances is 120,000 Btuh, each opening must have a free area of at least 120 square inches.



**Figure 5. Combustion Air Drawn from Inside**

### Conventional Furnaces - Unconfined Spaces

An unconfined space is an area including all rooms not separated by doors with a volume greater than 50 cubic feet per 1,000 Btuh of the combined input rates of all appliances which draw combustion air from that space.

In general, a furnace installed in an unconfined space will not require outside air for combustion. However, in homes built for energy efficiency (low air change rates), it may be necessary to provide outside air to ensure adequate combustion and venting, even though the furnace is located in an unconfined space.

#### Example:

A space with a water heater rated at 45,000 Btuh input and a furnace rated at 75,000 Btuh requires a volume of 6,000 cubic feet [ $50 \times (45 + 75) = 6,000$ ] to be considered unconfined. If the space has an 8 foot ceiling, the floor area of the space must be 750 square feet ( $6,000 / 8 = 750$ ).

### Direct Vent Furnaces

Direct Vent (2-pipe) furnaces draw combustion air directly from the outdoors and then vent the combustion products back outside, isolating the entire system from the indoor space. It is important to make sure that the whole system is sealed and clearances to combustibles are maintained regardless of the installation being in a confined or unconfined space.

## WARNING:

### CARBON MONOXIDE POISONING HAZARD

Failure to follow the steps outlined below for each appliance connected to the venting system being placed into operation could result in carbon monoxide poisoning or death.

The following steps shall be followed with each individual appliance connected to the venting system being placed in operation, while all other appliances connected to the venting system are not in operation:

1. Seal any unused openings in the venting system.
2. Inspect the venting system for proper size and horizontal pitch, as required in the *National Fuel Gas Code, ANSI Z223.1/NFPA 54* or the *CSA B149.1, Natural Gas and Propane Installation Codes* and these instructions. Determine that there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.
3. As far as practical, close all building doors and windows and all doors between the space in which the appliance(s) connected to the venting system are located and other spaces of the building.
4. Close fireplace dampers.
5. Turn on clothes dryers and any appliance not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they are operating at maximum speed. Do not operate a summer exhaust fan.
6. Follow the lighting instructions. Place the appliance being inspected into operation. Adjust the thermostat so appliance is operating continuously.
7. Test for spillage from draft hood equipped appliances at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.
8. If improper venting is observed during any of the above tests, the venting system must be corrected in accordance with the *National Fuel Gas Code, ANSI Z223.1/NFPA 54* and/or *CSA B149.1, Natural Gas and Propane Installation Codes*.
9. After it has been determined that each appliance connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-fired burning appliance to their previous conditions of use.

## VENTING REQUIREMENTS

---

 **WARNING:**

---

**This furnace must not be vented with other appliances, even if that appliance is of the condensing type. Common venting can result in severe corrosion of other appliances or their venting and can allow combustion gases to escape through such appliances or vents. Do not vent the furnace to a fireplace chimney or building chase.**

---

This furnace is classified as a “Category IV” appliance, which requires special venting materials and installation procedures.

- This furnace must be vented in compliance with the current revision of the National Fuel Gas Code (ANSI-Z223.1/NFPA54) and the instructions provided below. **Consult local codes for special requirements.**
- In Canada, venting shall conform to the requirements of the current (CAN/CGA B149.1 or .2) installation codes. **Consult local codes for special requirements.**
- Additional reference information for US and Canadian installations can be found in the Combustion and Ventilation Air section (page 5).

This section specifies installation requirements for Conventional (1-pipe) and Direct Vent (2-pipe) piping. For 1-pipe installations, install vent piping per this section and provide air for combustion and ventilation per the previous section. Table 15 (page 44) contains the length of vent and combustion air piping for either type of installation.

Category IV appliances operate with positive vent pressure and therefore require vent systems which are thoroughly sealed. They also produce liquid condensate, which is slightly acidic and can cause severe corrosion of ordinary venting materials. Furnace operation can be adversely affected by restrictive vent and combustion air piping.

The inducer assembly on this furnace can be rotated to vent the flue products out of the top, left or right side. This increases the flexibility of which direction the vent pipe can exit the furnace.

---

 **WARNING:**

---

**Upon completion of the furnace installation, carefully inspect the entire flue system both inside and outside the furnace to assure it is properly sealed. Leaks in the flue system can result in serious personal injury or death due to exposure of flue products, including carbon monoxide.**

---

## Vent Pipe Material

Vent and combustion air pipe and fittings must be one of the following materials and must conform to the indicated ANSI/ASTM standards. In Canada, all plastic vent pipes and fittings including any cement, cleaners, or primers must be certified as a system to ULC S636.

<u>Material</u>	<u>Standard</u>
Schedule 40PVC	D1785
PVC-DWV	D2665
SDR-21 & SDR-26	D2241
ABS-DWV	D2661
Schedule 40 ABS	F628
Foam/Cellular Core PVC	F891

Cement and primer must conform to ATSM Standard D2564 for PVC and Standard D2235 for ABS. When joining PVC piping to ABS, use PVC solvent cement. (See procedure specified in ASTM Standard D3138).

## Vent Pipe Length and Diameter

In order for the furnace to operate properly, the combustion air and vent piping must not be excessively restrictive.

- The venting system should be designed to have the minimum number of elbows or turns.
- All horizontal runs must slope upwards from the furnace at 1/4 inch minimum per running foot of vent.
- Transition to the final vent diameter should be done as close to the furnace outlet as practical.
- Always use the same size or a larger pipe for combustion air that is used for the exhaust vent.

Table 15 indicates the maximum allowable pipe length for a furnace of known input rate, when installed with piping of selected diameter and number of elbows. To use the table, the furnace input rate, the centerline length and the number of elbows on each pipe must be known.

When estimating the length of vent runs, consideration must be made to the effect of elbows and other fittings. This is conveniently handled using the idea of “equivalent length”. This means the fittings are assigned a linear length that accounts for the pressure drop they will cause. For example: a 2” diameter, long radius elbow is worth the equivalent of 2.5 feet of linear run. A 90 degree tee is worth 7 ft.

Using Table 15, measure the linear length of your vent run and then add in the equivalent length of each fitting. The total length, including the equivalent fitting lengths, must be less than the maximum length in Table 15.

Condensing furnace combustion products have very little buoyancy, so Table 15 is to be used without consideration of any vertical rise in the piping.

## Vent Pipe Installation



---

**Combustion air must not be drawn from a corrosive atmosphere.**

---

This furnace has been certified for installation with zero clearance between vent piping and combustible surfaces. However, it is good practice to allow space for convenience in installation and service.

- The quality of outdoor air must also be considered. Be sure that the combustion air intake is not located near a source of solvent fumes or other chemicals which can cause corrosion of the furnace combustion system. (See list of substances on page 6).
- Route piping as direct as possible between the furnace and the outdoors. Longer vent runs require larger diameters.
- If a Direct Vent (2-pipe) system is used, the combustion air intake and the vent exhaust must be located in the same atmospheric pressure zone. This means both pipes must exit the building through the same portion of exterior wall or roof as shown in Figure 29, page 43. Vent piping must be sloped upwards 1/4" per foot in the direction from the furnace to the terminal. This is to ensure that any condensate flows back to the condensate disposal system.
- Piping must be mechanically supported so that its weight does not bear on the furnace. Pipe supports must be installed a minimum of every five feet along the vent run to ensure no displacement after installation. Supports may be at shorter intervals if necessary to ensure that there are no sagging sections that can trap condensate. It is recommended to install couplings along the vent pipe, on either side of the exterior wall (Figure 29). These couplings may be required by local code.
- If breakable connections are required in the combustion air inlet pipe (if present) and exhaust vent piping, then straight neoprene couplings for 2" or 3" piping with hose clamps can be used. These couplings can be ordered through your local furnace distributor. To install a coupling:
  1. Slide the rubber coupling over the end of the pipe that is attached to the furnace and secure it with one of the hose clamps.
  2. Slide the other end of the rubber coupling onto the other pipe from the vent.
  3. Secure the coupling with the second hose clamp, ensuring that the connection is tight and leak free.

## Outdoor Terminations - Horizontal Venting


Vent and combustion air intake terminations shall be installed as shown in Figures 6 & 7 (page 13) and in accordance with these instructions:

- Vent termination clearances must be consistent with the NFGC, ANSI 2223.1/NFPA 54 and/or the CSA B149.1, Natural Gas and Propane Installation Code.
- All minimum clearances must be maintained to protect building materials from degradation by flue gases as shown in Figure 7.
- Vent and combustion air intake terminations must be located to ensure proper furnace operation and conformance to applicable codes. Table 14 (page 38) lists the necessary distances from the vent termination to windows and building air intakes. In Canada, CSA B149.1 takes precedence over these instructions.
- For optimal performance, vent the furnace through a wall that experiences the least exposure to winter winds.
- The vent termination shall be located at least 3 ft. horizontally from any electric meter, gas meter, regulator and any relief equipment. These distances apply **ONLY** to U.S. installations. In Canada, CSA B149.1 takes precedence over these instructions.
- Do not install the vent terminal such that exhaust is directed into window wells, stairwells, under decks or into alcoves or similar recessed areas, and do not terminate above any public walkways.
- If venting horizontally, a side wall vent kit is available according to the pipe diameter size of the installation. For 2 inch pipe use side wall vent kit #904617, and for 3 inch pipe use kit #904349. **Please follow the instructions provided with the kit.**
- Concentric vent termination kits are available for use with these furnaces. For 2 Inch pipe use kit #904177 and for 3 inch pipe use kit # 904176. **Please follow the instructions provided with the kit.**
- When the vent pipe must exit an exterior wall close to the grade or expected snow level where it is not possible to obtain clearances shown in Figure 6, a riser may be provided as shown in Figure 8 (page 13). Insulation is required to prevent freezing of this section of pipe. See Table 1 (page 13) for vent freezing protection.


## Outdoor Terminations - Vertical Venting

Termination spacing requirements from the roof and from each other are shown in Figure 9 (page 13). The roof penetration must be properly flashed and waterproofed with a plumbing roof boot or equivalent flashing. Vent and combustion air piping may be installed in an existing chimney which is not in use provided that:


- Both the exhaust vent and air intake run the length of the chimney.
- The top of the chimney is sealed and weatherproofed.
- The termination clearances shown in Figure 9 are maintained.
- No other gas fired or fuel-burning equipment is vented through the chimney.




**Figure 6. Exhaust and Combustion Air Pipe Clearances**



**Figure 9. Vertical Vent Termination**



**Figure 7 Vent Locations**



**Figure 8. Alternate Horizontal Vent Installation**

### Vent Freezing Protection

When the vent pipe is exposed to temperatures below freezing (i.e., when it passes through unheated spaces, chimneys, etc.) the pipe must be insulated with 1/2 inch thick sponge rubber insulation, Armaflex-type insulation or equivalent. Insulating pipe is important to avoid condensate icing.

Table 1 lists the maximum length of flue pipe that can travel through an unconditioned space or an exterior space. The total vent length must not exceed the lengths noted in Table 15 (page 44). For Canadian installations please refer to the Canadian Installation Code (CAN/CGA-B149.1 or 2) and/or local codes.

Winter Design Temperature	Maximum Flue Pipe Length in Unconditioned and Exterior Spaces	
	Without Insulation (feet)	With Insulation (feet)*
20	45	70
0	20	70
-20	10	60

\* = Insulation thickness greater than 3/8 inch, based on an R value of 3.5 (ft x F x hr) / (BTU x in.)

**Table 1. Vent Protection**

### Condensate Disposal

The method for disposing of condensate varies according to local codes. Consult your local code or authority having jurisdiction. Neutralizer kit P/N 902377 is available for use with this furnace. **Please follow the instructions provided with the kit.**

This furnace has multiple options for positioning the vent pipe as described in the section, Vent and Inducer Assembly Options. Each of the condensate drain lines must be J-trapped using field supplied parts. After the condensate lines are J-trapped, they may be combined together when routed to the drain.

## Existing Installations

When an existing furnace is removed from a vent system serving other appliances, the existing vent system may not be sized properly to vent the remaining appliances (For example: water heater). An improperly sized venting system can result in the formation of condensate, leakage, or spillage. The existing vent system should be checked to make sure it is in compliance with NFGC and must be brought into compliance before installing the furnace.

**NOTE:** If replacing an existing furnace, it is possible you will encounter an existing plastic venting system that is subject to a Consumer Product Safety Commission recall. The pipes involved in the recall are High Temperature Plastic Vent (HTPV). **If your venting system contains these pipes DO NOT reuse this venting system!** This recall does not apply to other plastic vent pipes, such as white PVC or CPVC. Check for details on the CPSC website or call their toll-free number (800) 758-3688.

## FURNACE INSTALLATION

### General Requirements

\*SC series gas furnaces are shipped ready for installation in the upflow or horizontal right or left positions. Only the \*SL series gas furnace may be used for downflow operation.

- The furnace must be leveled at installation and attached to a properly installed duct system. See Table 3 (page 27) for the required clearances needed to move the furnace to its installation point (hallways, doorways, stairs, etc).
- The furnace must be installed so that all electrical components are protected from water.
- The furnace must be installed upstream from a refrigeration system.
- The cabinet plug must always be used to close the hole in the side of the furnace when rotating the inducer.
- Additional reference information for US and Canadian installations can be found in the General Installation section (page 5).

### Vent and Inducer Assembly Options

\*SC series gas furnaces offer a wide range of installation options, including installation in the upflow or horizontal positions with either right, left, or upflow return air. The \*SL series gas furnaces may only be installed as a down flow application.

To increase installation flexibility, the inducer assembly can be rotated up to 3 different positions. Each variation has slightly different requirements with regard to condensate disposal and, in some cases, the need to seal the furnace cabinet. **IMPORTANT NOTE: The Inducer Assembly must never be positioned to vent downwards on horizontal installs.**

Before using Table 2, the number of pipes (1-pipe or 2-pipe) connected to the furnace must be known. Find the proper furnace style (upflow, horizontal, or downflow) and then the side that the pipes will exit from the furnace. Finally select the option that properly matches your installation type from Figures 25-28 (pages 39-42).

Conventional (1 Pipe)				
Vent	Upflow	Horizontal Right	Horizontal Left	Downflow
Up	Option 1	Option 7	Option 10	Option 15
Right	Option 2	Option 8	N/A	Option 16
Left	Option 3	N/A	Option 9	Option 17
Direct Vent (2-pipe)				
Vent	Upflow	Horizontal Right	Horizontal Left	Downflow
Up	Option 4	Option 12*	Option 14*	Option 18
Right	Option 5*	Option 11	N/A	Option 19*
Left	Option 6*	N/A	Option 13	Option 20*

\* Requires a 2 inch PVC endcap.

**Table 2. Vent and Inducer Blower Options**


### Inducer Assembly Rotation



## WARNING:

**Inducer rotation must be completed before the furnace is connected to gas and electric. If both utilities have been connected, follow the shutdown procedures printed on the furnace label and disconnect the electrical supply.**

1. Disconnect the electrical harness (1) from the inducer assembly (2) as shown in Figure 10 (page 15).
2. Remove the inducer assembly ground wire (3) from the blower deck (4) or door.
3. Remove three screws (5) securing the inducer assembly (2) to the header box (6).
4. Rotate the inducer assembly (2) to its new position.
5. Secure the inducer assembly (2) to the header box (6) by reinstalling the three screws (5). If the inducer assembly is rotated to the left or right side of the furnace, use the extra screw provided in the parts package.
6. Remove the cabinet plug (7) from side of furnace and reinstall in hole on opposite side of cabinet.
7. Install in-line drain assembly and tubing.
8. If applicable, install the condensate drain lines as shown in (Figures 25-28).
9. Reconnect the electrical harness (1) to the inducer assembly (2).
10. Reconnect the inducer assembly ground wire (3) to the blower deck (4) or door.
11. Verify operation as detailed on the furnace label.




**Figure 10. Inducer Assembly Rotation**

### Pressure Switch Relocation

In some inducer orientations, the inducer pressure switch may interfere with gas pipe installation. Determine the side of the cabinet the gas pipe will enter and see if the inducer pressure switch needs to be moved. If the pressure switch interferes with the gas pipe, please follow these instructions for relocating it to the alternate location:


1. Shut off any electrical power to the furnace.
2. Label and disconnect the tubing and wires from the pressure switch (Figure 11).
3. Remove two screws securing the pressure switch to the inducer housing.
4. Remove the pressure switch from the mounts on the inducer housing and relocate it to the other set of mounts 90° from previous location.
5. Secure the pressure switch with two screws.
6. Reconnect the tubes and wires to the pressure switch.



**Figure 11. Alternate Pressure Switch Location**

### Special Instructions for SC038-23A Furnaces

If furnace is to be installed horizontally with airflow going from left to right, the pressure switch will need to be moved to the side of the furnace that is not facing the ground (Figure 12). Moving the switch will make it easier to replace in the future.



**Figure 12. SC038-23A Pressure Switch**

1. Shut off any electrical power to the furnace.
2. Label and disconnect the tubing and wires from the pressure switch (1).
3. Remove two screws (2) securing the pressure switch (1) to the side of the furnace.
4. Remove two 1/4" black plugs (3) on the opposite side of the cabinet that the pressure switch will be relocated to.
5. Position the pressure switch (1) in its new location and secure it in place using the same screws (2) removed in step 2.
6. Insert the plugs (3) into the holes on the side that the pressure switch (1) was removed from.
7. Reconnect the tubing and wiring to the pressure switch (1) being careful that they will not fall into the burner box.

### **CAUTION:**

**It is extremely important that all wires and tubes be correctly reattached to the pressure switch(s). Failure to do so will result in malfunction or compromised safety functions of the furnace.**

8. Check the furnace for proper operation as directed in Startup and Adjustments section. If the furnace shuts down during the pre-purge, the switch that measures pressure in the header needs to be checked for correct tubing connections.

### Condensate Drain Lines

The methods for draining condensate out of the system depend on the configuration selected. See Figures 25-28 (pages 39-42) for your particular application.

Four general principles apply:

- Each condensate drain line must be separately trapped using a J-Trap or field supplied loop.
- There must always be a drain attached to the collector at the outlet of the secondary heat exchanger.
- There must always be a drain at the outlet of the inducer assembly.
- There must always be a drain at the lowest point of the venting system.

Exceptions and clarifications to the general rules:

- In some cases, the lowest point in the vent system is where it connects to the inducer (Options 8, 10, 12, & 14). In this case one drain at this location is sufficient.
- If the vent exits the furnace horizontally, the vent may be turned vertically with a tee. The drip leg formed by the tee must include a drain (Options 2,3,5,6,8,9,12,13,16,17,19, & 20).
- In certain cases, it is permitted to drain the inducer back into the top drain of the collector (Options 2, 7, 11, 15 & 16). Take care that this drain does not sag in the middle.

### Direct Vent (2-Pipe) Applications

It is important that Direct Vent (2-pipe) systems maintain an airtight flow path from the air inlet to the flue gas outlet. The furnace ships from the factory with two holes in the cabinet for the air inlet and flue gas outlet. In certain configurations, it is necessary to remove and relocate a plastic cap in the furnace cabinet. If changing the position of the air inlet and flue gas outlet, it is required that the previous hole be closed off with the plastic cap to maintain air tightness in the furnace. The hole locations for \*SC series upflow/horizontal furnaces are indicated in Figure 22 (page 28). For \*SL downflow installations, the hole locations are shown in Figure 23 (page 29).

### Upflow Installation

**! WARNING:**

**The furnace must not be installed directly on carpeting, tile, or any combustible material other than wood flooring.**

The \*SC series gas furnace may be installed directly on combustible wood flooring or supports. For venting guidelines and specifications, see Venting Requirements section (page 11).

### Side Return Air Inlet

\*SC series gas furnaces are shipped with the bottom panel installed (Figure 22). If the furnace is installed using

both side return air inlets, the bottom panel must not be removed. If the bottom of the furnace is not being used as a return, leave the bottom panel in place.

### Bottom Return Air Inlet

If the \*SC series gas furnace is installed using the bottom as a return air inlet and 1 side return, the bottom panel (Figure 22) must be removed. (See Bottom Panel Removal).

### Horizontal Installation

**! WARNING:**

**The furnace must not be installed directly on carpeting, tile, or any combustible material other than wood flooring.**

The \*SC series gas furnace can be installed horizontally in an attic, basement, crawl space or alcove (Figure 13). It can also be suspended from a ceiling in a basement or utility room in either a right to left airflow or left to right airflow as shown in Figure 14.




Figure 13. \*SC Horizontal installation on a Platform




Figure 14. \*SC Horizontally Suspended in Attic or Crawl Space



\*SC series furnaces are shipped with the bottom panel installed. If the furnace is installed horizontally, remove the bottom panel from the furnace before attaching the duct system. See Bottom Panel Removal.

If the furnace is to be suspended from the ceiling, it will be necessary to use steel straps around each end of the furnace. The straps should be attached to the furnace with sheet metal screws and to the rafters with bolts. The furnace could also be suspended by an angle iron frame bolted to the rafters (Figure 8, page 9). Access for positioning and servicing must be considered when locating the unit. See Table 3 (page 27) for clearance specifications.

If the furnace is to be installed in an attic, it is required that a drip pan be placed under the furnace. If the installation is on a combustible platform (Figure 14), it is recommended that the drip pan extend at least 12 inches past the top and front of the furnace.

#### Bottom Panel Removal

To remove the bottom panel (Figure 15) from the upflow furnace, perform the following steps:

1. Remove the blower door (1) from bottom of furnace.
2. Disconnect the wiring harness (2) from the connector.
3. Remove two screws (3) securing the blower assembly (4) to the furnace.
4. Carefully pull the blower assembly (4) out thru the front of the furnace.
5. Remove all screws (5) securing bottom panel (6) to bottom of furnace and front brace (7).
6. Lift up and slide bottom panel (6) out through front of furnace.
7. Reinstall the blower assembly (4) in reverse order it was removed.

#### Downflow Installation


### **WARNING:**

**The furnace must not be installed directly on carpeting, tile, or any combustible material other than wood flooring.**

The \*SL series gas furnace is certified for installation on combustible flooring. **This furnace must not be installed directly on carpeting, tile, or any combustible material other than wood flooring.** For venting guidelines and specifications, see Venting Requirements on page 11.

### **WARNING:**

**Failure to install the downflow sub-base kit may result in fire, property damage or personal injury.**



**Figure 15. Removal of Bottom Panel**

To install the furnace on combustible flooring, a special sub-base is required. Downflow sub-base kits are factory supplied accessories and are listed according to the cabinet letter of the furnace. For 'A' size cabinets use Sub-Base kit #902974 only. For 'B', 'C', and 'D' size cabinets use Kit #904911. **Please follow the instructions provided with the kit.**

A downflow sub-base kit is not necessary if the furnace is installed on a factory or site-built cased air conditioning coil. However, the plenum attached to the coil casing must be installed so that its surfaces are at least 1" from combustible construction.

Installation on a concrete slab.

1. Create an opening in the floor according to the dimensions in Figure 16.
2. Position the plenum and the furnace as shown in Figure 17.




Figure 16. Cutout Dimensions




Figure 17. Furnace on a Concrete Slab

**CIRCULATING AIR REQUIREMENTS**

**! WARNING:**

**Do not allow combustion products to enter the circulating air supply. Failure to prevent the circulation of combustion products into the living space can create potentially hazardous conditions including carbon monoxide poisoning that could result in personal injury or death.**

**All return ductwork must be secured to the furnace with sheet metal screws. For installations in confined spaces, all return ductwork must be adequately sealed. When return air is provided through the bottom of the furnace, the joint between the furnace and the return air plenum must be air tight.**

**The surface that the furnace is mounted on must provide sound physical support of the furnace with no gaps, cracks or sagging between the furnace and the floor or platform.**

**Return air and circulating air ductwork must not be connected to any other heat producing device such as a fireplace insert, stove, etc. This may result in fire, explosion, carbon monoxide poisoning, personal injury, or property damage.**

**Plenums and Air Ducts**

- Plenums and air ducts must be installed in accordance with the Standard for the Installation of Air Conditioning and Ventilating Systems (NFPA No. 90A) or the Standard for the Installation of Warm Air Heating and Air Conditioning Systems (NFPA No. 90B). Additional reference information for US and Canadian installations can be found in the Duct Systems section (page 5).
- Tables 4 and 5 (pages 30-32) contain the airflow and temperature rise data. If the maximum airflow is 1,600 CFM or more, it is recommended that two openings be used for return air on upflow furnaces. Downflow furnaces can only use one return opening.
- It is recommended that the outlet duct contain a removable access panel. The opening should be accessible when the furnace is installed in service and shall be of a size that smoke or reflected light may be observed inside the casing to indicate the presence of leaks in the heat exchanger. The cover for the opening shall be attached in such a manner as to prevent leaks.
- If outside air is used as return air to the furnace for ventilation or to improve indoor air quality, the system must be designed so that the return air is not less than

60° F (15° C) during operation. If a combination of indoor and outdoor air is used, the ducts and damper system must be designed so that the return air supply to the furnace is equal to the return air supply under normal, indoor return air applications.

- When a cooling system is installed which uses the furnace blower to provide airflow over the indoor coil, the coil must be installed downstream (on the outlet side) of the furnace or in parallel with the furnace.
- If a cooling system is installed in parallel with the furnace, a damper must be installed to prevent chilled air from entering the furnace and condensing on the heat exchanger. If a manually operated damper is installed, it must be designed so that operation of the furnace is prevented when the damper is in the cooling position and operation of the cooling system is prevented when the damper is in the heating position.

### Supply Air Connections

The supply air must be delivered to the heated space by duct(s) secured to the furnace casing, running full size and without interruption. It is good practice to seal all connections and joints with industrial grade sealing tape or liquid sealant. Requirements for sealing ductwork vary from region to region. Consult with local codes for requirements specific to your area.

#### Upflow and Horizontal Furnaces

To attach the supply air duct to the furnace, bend the furnace flanges (Figure 22, page 28) upward 90° with a pair of wide duct pliers. Position the duct on top of the furnace and secure together with sheet metal screws. The screws must penetrate the sheet metal casing and furnace flange. Tape or seal all seams if required by local code.

#### Downflow Furnaces

To attach the supply air duct to the downflow furnace, position the furnace over the duct and secure together with sheet metal screws. The screws must penetrate the duct and furnace cabinet.

### Return Air Connections

In applications where the supply ducts carry heated air to areas outside the space where the furnace is installed, the return air must be delivered to the furnace by duct(s) secured to the furnace casing, running full size and without interruption. It is good practice to seal all connections and joints with industrial grade sealing tape or liquid sealant. Requirements for sealing ductwork vary from region to region. Consult with local codes for requirements specific to your area.

#### Upflow Horizontal Furnaces

For upflow installations, the return air ductwork may be connected to the left side, right side, or bottom. The bottom panel (Figure 22) must be installed for left or right return air. **NOTE: Do not use the back of the furnace for return air.**

### Side Return Installations

To attach the return air duct to the left or right side of the furnace, punch out the four knockouts (Figure 22) from the preferred side of the furnace. Using sharp metal cutters, cut an opening between all four knockouts to expose the blower assembly. Position the return air duct over the opening in the side and secure together with sheet metal screws. The screws must penetrate the duct and furnace cabinet.



## WARNING:

---

**The solid base of the furnace must be in position when the furnace is installed with side return air ducts. Removal of all or part of the base could cause circulation of combustible products into the living space and create potentially hazardous conditions, including carbon monoxide poisoning that could result in personal injury or death.**

---

### Bottom Return Installations

The bottom panel (Figure 22) must be removed from the furnace for bottom return air. If bottom panel is installed, go to page 16 for removal instructions. Position the furnace over the return air duct and secure together with sheet metal screws. The screws must penetrate the duct and furnace cabinet.

#### Downflow Furnaces

To attach the return air duct to the furnace, bend the furnace flanges (Figure 23, page 29) upward 90° with a pair of wide duct pliers. Position the duct on top of the furnace and secure together with sheet metal screws. The screws must penetrate the sheet metal cabinet and furnace flange. Tape or seal all seams if required by local code.

### Acoustical Treatments

Damping ducts, flexible vibration isolators, or pleated media-style filters on the return air inlet of the furnace may be used to reduce the transmission of equipment noise emanating from the furnace. These treatments can produce a quieter installation, particularly in the heated space. However, they can increase the pressure drop in the duct system. Care must be taken to maintain the proper maximum pressure rise across the furnace, temperature rise and flow rate. This may mean increasing the duct size and/or reducing the blower speed. These treatments must be constructed and installed in accordance with NFPA and SMACNA construction standards. Consult with local codes for special requirements. For best sound performance, install all the needed gaskets and grommets around penetrations into the furnace, such as for electrical wiring.

## GAS SUPPLY AND PIPING

All gas piping must be installed in compliance with local codes and utility regulations.

In the absence of local codes the gas line installation must comply with the latest edition of the National Fuel Gas Code (ANSI Z223.1) or (CAN/CGA B149.1 or .2) Installation Codes. Additional reference information for US and Canadian installations can be found in the Gas Piping and Gas Pipe Pressure Testing section (page 5).

### IMPORTANT NOTES:

- Some local regulations require the installation of a manual main shut-off valve and ground joint union external to the furnace as depicted in Figure 18 (page 20). The shut-off valve should be readily accessible for service and/or emergency use. Consult the local utility or gas supplier for additional requirements regarding placement of the manual main gas shut-off.
- Gas piping must never run in or through air ducts, chimneys, gas vents, or elevator shafts.
- Compounds used on threaded joints of gas piping must be resistant to the actions of liquefied petroleum gases.
- The main gas valve and main power disconnect to the furnace must be properly labeled by the installer in case emergency shutdown is required.
- Flexible gas connectors are not recommended for this type of furnace but may be used if allowed by local jurisdiction. Only new flexible connectors may be used.
- **Do not reuse old flexible gas connectors.**
- A drip leg should be installed in the vertical pipe run to the unit (Figure 18).

Table 9 (page 35) lists gas flow capacities for standard pipe sizes as a function of length in typical applications based on nominal pressure drop in the line.

The furnace may be installed for either left or right side gas entry. When connecting the gas supply, provide clearance between the gas supply line and the entry hole in the furnace casing to avoid unwanted noise and/or damage to the furnace. A typical gas service hookup is shown in Figure 18.


### Leak Check



## WARNING:

### FIRE OR EXPLOSION HAZARD

**Never test for gas leaks with an open flame. Check all connections using a commercially available soap solution. A fire or explosion may result causing property damage, personal injury or loss of life. Failure to follow the safety warnings exactly could result in serious injury, death or property damage.**



**Figure 18. Typical Gas Connection**

After the gas piping to the furnace is complete, all connections must be tested for gas leaks. This includes pipe connections at the main gas valve, emergency shutoff valve and flexible gas connectors (if applicable). The soap and water solution can be applied on each joint or union using a small paintbrush. If any bubbling is observed, the connection is not sealed adequately and must be retightened. Repeat the tightening and soap check process until bubbling ceases.

**IMPORTANT NOTE: When pressure testing gas supply lines at pressures greater than 1/2 psig (14 inch W.C.), the gas supply piping system must be disconnected from the furnace to prevent damage to the gas control valve. If the test pressure is less than or equal to 1/2 psig (14 inch W.C.), close the manual shut-off valve.**

### High Altitude Application

High altitude conversion with this furnace depends on the installation altitude and the heating value of the gas. The installation of this furnace at altitudes above 2,000 feet must meet the requirements of the National Fuel Gas Code or local jurisdiction. In Canada, the requirements for high altitude are different and governed by CGA B149.1. Please consult your local code authority.

---

 **WARNING:**

---

**The reduction of input rating necessary for high altitude installation may only be accomplished with factory supplied orifices. Do not attempt to drill out orifices in the field. Improperly drilled orifices may cause fire, explosion, carbon monoxide poisoning, personal injury or death.**

---

The furnaces are shipped from the factory with orifices and gas regulator settings for natural gas operation at sea level altitudes. At 2000 feet, the NFGC requires that this appliance be derated 4% for each 1000 feet of altitude. For example, the input needs to be reduced 8% at 2,000 feet, 12% at 3,000 feet and etc. This deration is in reference to the input rate and gas heating value at sea level.

To derate the furnace requires knowing the heating value of the gas at the installation site. Heating values at particular job sites vary for two reasons:

1. The chemical mixture of the gas varies from region to region and is expressed as the “sea level heating value”.
2. The heating value varies by altitude. For this reason, especially in high altitude areas, the local gas utility specifies the heating value at the residence’s gas meter as the “local value”.

For added flexibility, two tables have been provided for natural gas installations with high or low heating values at sea level. Tables 12 and 13 (page 37) contain the manifold pressure and orifice sizes to use at various altitudes. Table 12 (HIGH) is for natural gas installations with a heating value of more than 1,000 Btu per cubic foot and Table 13 (LOW) is for less than 1,000 Btu per cubic foot. To determine which table to use:

1. Consult the local utility for the local heating value at your installation site.
2. From Table 11 (page 36), find your local heating value as supplied by the utility company. Follow down the column and stop at your altitude level.
3. If your sea level heating value is HIGH, use Table 12 or if it’s LOW, use Table 13. (See example below.)

**INSTALLATION EXAMPLE**

**Elevation:** .....5,000 feet  
**Type of Gas:** ..... Natural Gas  
**Local Heating Value of Gas:** ..... 750

Determine which natural gas table to use. From Table 11, find 750 and follow down the column, stop at the 5,000 feet row. The heating value listed is LOW. Table 13 will be used to determine orifice size and manifold pressure.

After changing the regulator pressure or the orifices, it is required that you measure the gas input rate. This may be accomplished in the usual way, by clocking the gas meter and using the local gas heating value. See Verifying and Adjusting the Input Rate section (page 23).

**IMPORTANT NOTE: Observe the action of the burners to make sure there is no yellowing, lifting or flashback of the flame.**

**Conversion to LP/Propane**

---

 **WARNING:**

---

**The furnace was shipped from the factory equipped to operate on natural gas. Conversion to LP/propane gas must be performed by qualified service personnel using a factory supplied conversion kit. Failure to use the proper conversion kit can cause fire, explosion, property damage, carbon monoxide poisoning, personal injury, or death.**

---

Conversion to LP/propane is detailed in the installation instructions provided with the conversion kit. Generally, this will require the replacement of the burner orifices and the spring found under the cap screw on the pressure regulator.

In the U.S. if installation is above 2,000 ft., refer to Table 10 (page 36) to determine the correct orifice size and regulator pressure. When conversion is complete, verify the manifold pressure and input rate are correct as listed in the tables. Approved conversion kits are listed below:

- The United States LP/Propane Gas Sea Level and High Altitude Conversion Kit (P/N 904914) is for LP/propane conversion in the United States at altitudes between 2,000 ft. and 10,000 ft. above sea level. **Please follow the instructions provided with the kit.**
- The Canadian LP/Propane Gas Sea Level and High Altitude Conversion Kit (P/N 904915) is for LP/propane conversions in Canada at altitudes between zero and 4,500 ft. above sea level. **Please follow the instructions provided with the kit.**

## ELECTRICAL WIRING

### **WARNING:**


To avoid electric shock, personal injury, or death, turn off the electric power at the disconnect or the main service panel before making any electrical connections.

- Electrical connections must be in compliance with all applicable local codes with the current revision of the National Electric Code (ANSI/NFPA 70).
- For Canadian installations the electrical connections and grounding shall comply with the current Canadian Electrical Code (CSA C22.1 and/or local codes).
- Additional reference information for US and Canadian installations can be found in the Electrical Connections section (page 5).

**IMPORTANT NOTE:** If replacing any of the original wires supplied with the furnace, the replacement wire must be copper wiring and have a temperature rating of at least 105°F (40°C). For electrical requirements, refer to the furnace nameplate or Table 6 (page 33).

### Low Voltage Wiring

The thermostat must be installed according to the instructions supplied by the thermostat manufacturer. Low voltage connections (24 VAC) from the thermostat are wired to the terminal strip on the integrated control in the furnace. Figure 19 contains the proper connections for heating only (two-wire) and heating/cooling (four-wire) applications. Recommended minimum wire gauge for thermostat wiring is shown in Table 6.



**Figure 19. Low Voltage Field, Four-wire Heating/Cooling Applications**

The thermostat must not be installed on an outside wall or any other location where its operation may be adversely affected by radiant heat from fireplaces, sunlight, or lighting fixtures, and convective heat from warm air registers or electrical appliances.

**IMPORTANT NOTE:** Set the heat anticipator according to the instructions supplied by the thermostat manufacturer.

To determine the heat anticipator setting:

1. Add the current draw of the system components; or
2. Measure the current flow on the thermostat **R-W** circuit after the circulating blower motor has started.

The six pin terminal marked “Expansion Port” is not used in the single stage furnace as shipped from the factory. It is used for the furnace control board to communicate to a fixed speed or variable speed high efficiency motor that may be optionally installed. Please contact your distributor for the proper upgrade motor kit.


### Line Voltage Wiring

It is recommended that the line voltage (115 VAC) to the furnace be supplied from a dedicated branch circuit containing the correct fuse or circuit breaker for the furnace as listed in Table 6.

**IMPORTANT NOTE:** An electrical disconnect must be installed readily accessible from and located within sight of the furnace. See Figure 20 or the wiring diagram label inside of the control door. Any other wiring methods must be acceptable to authority having jurisdiction.

### **CAUTION:**

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.



**Figure 20. Line Voltage Field Wiring**

**IMPORTANT NOTE: Proper line voltage polarity must be maintained in order for the control system to operate correctly. Verify the incoming neutral line is connected to the white wire and the incoming “hot” line is connected to the black wire. The furnace will not operate unless the polarity and ground are properly connected as shown in Figure 20 (page 22).**

## Grounding

### **WARNING:**

**To minimize personal injury, the furnace cabinet must have an uninterrupted or unbroken electrical ground. The controls used in this furnace require an earth ground to operate properly. Acceptable methods include electrical wire or conduit approved for ground service. Do not use gas piping as an electrical ground!**

## Twinning

Single stage G7 furnaces are not supplied with a built-in twinning capability. Other valuable features and enhancements were made to the new control that made it necessary to remove the twinning capability. All standard two-stage furnaces equipped with the fixed speed iSEER™ motor include a twinning terminal on the blower control board.

However, if both Single stage G7 furnaces are upgraded to the fixed speed iSEER™ blower, the twin terminal on the blower control boards may be used. Alternately, off-the-shelf furnace twinning kits such as Johnson Controls (P/N 2TC03700124) may be used. Using this control also provides the additional feature of two-stage operation by individually controlling the heat section of each furnace. Contact your furnace distributor for technical details.

**IMPORTANT NOTE: G7 furnaces equipped with variable speed iSEER™ motors may not be twinned under any circumstances.**

## START-UP AND ADJUSTMENTS

### Pre-Start Check List

- √ verify the polarity of the connections are correct, the line voltage power leads are securely connected and the furnace is properly grounded.
- √ verify the thermostat wires (**R**, **W**, **Y**, and **G**) are securely connected to the correct leads on the terminal strip of the circuit board.
- √ verify the gas line service pressure does not exceed 10.0 inches of W.C., and is not less than 4.5 inches W.C. for natural gas. For LP gas the line service pressure must not exceed 14 in. W.C., and must not be less than 11.0 in. W.C.
- √ verify the roll-out and manual reset switch is closed.

If necessary, press the red button to reset a switch.

**Note: DO NOT install a jumper wire across a switch to defeat its function.** If a switch reopens on startup, DO NOT reset the switch without identifying and correcting the fault condition.

- √ verify the blower door is in place, closing the door switch in the line voltage circuit.
- √ verify the gas line has been purged and all connections are leak free.

## Start-up Procedures

Do not perform these steps until all of the checks in the previous steps have been completed:

1. Set the thermostat to the lowest setting.
2. Turn off all electrical power to the furnace.
3. Follow the Operating Instructions on the label attached to the furnace.
4. Set the thermostat above room temperature and verify the Operating Sequence (page 25).
5. After 5 minutes of operation, set the thermostat below room temperature and verify steps 9-10 of the Operating Sequence (page 25).

## Verifying and Adjusting Input Rate

**IMPORTANT NOTE: The input rate must not exceed the rate shown on the furnace rating plate. At altitudes above 2,000 feet, it must not exceed that on the rating plate less 4% for each 1,000 feet.**

The input rate must be verified for each installation to prevent over-firing of the furnace. To determine the exact input rate, perform the following procedures:

1. Shut off all other gas fired appliances.
2. Start the furnace and run it for at least 3 minutes.
3. Measure the time (in seconds) required for the gas meter to complete one revolution.
4. Convert the time per revolution to cubic feet of gas per hour using Table 8 (page 35).
5. Multiply the gas flow rate in cubic ft per hr by the heating value of the gas in Btu per cubic ft to obtain the input rate in Btuh or see the example.

### Example:

- Time for 1 revolution of a gas meter with a 1 cubic ft dial = 40 seconds.
- From Table 8 read 90 cubic ft gas per hr.
- Local heating value of the gas (obtained from gas supplier) = 1,040 Btu per cubic ft.
- Input rate = 1,040 x 90 = 93,600 Btuh.

6. The manifold pressure must be set to the appropriate value for each installation by a qualified installer, service agency or the gas supplier.

---


**! WARNING:**

---

**Do not attempt to drill the gas orifices. Use only factory supplied orifices. Improperly drilled orifices may cause fire, explosion, carbon monoxide poisoning, personal injury or death.**

---

- a.) Obtain the manifold pressure setting required for this installation by referring to Table 10 for Propane or Tables 12 or 13 for Natural Gas (pages 36-37).
- b.) Remove the regulator capscrew (Figure 21) from the INLET side of the regulator.
- c.) Slowly turn the adjustment screw inside the regulator to obtain the appropriate manifold pressure. **IMPORTANT NOTE: Turning the screw clockwise increases the pressure and turning the screw counter-clockwise decreases the pressure. To prevent backing the screw all the way out from the valve, turn the screw slowly.**
- d.) Replace and tighten the regulator capscrew over the adjustment screw.



**Figure 21. Regulator Capscrew**

#### **Verifying and Adjusting Temperature Rise**

Confirm the temperature rise through the furnace is within the limits specified on the furnace rating plate. Any temperature rise outside the specified limits could result in premature failure of the heat exchanger.

1. Place thermometers in the return and supply air stream as close to the furnace as possible. The thermometer on the supply air side must be shielded from direct radiation from the heat exchanger to avoid false readings.
2. Adjust all registers and duct dampers to the desired position and run the furnace for 10 to 15 minutes before taking any temperature readings. The temperature rise is the difference between the supply and return air temperatures.

For typical duct systems, the temperature rise will fall within the limits specified on the rating plate with the blower speed at the factory recommended setting. If the measured temperature rise is outside the specified limits, it may be necessary to change the speed of the blower.

**NOTE:** Lowering the blower speed will increase the temperature rise and a higher blower speed will decrease the temperature rise.

The furnace is equipped with a multi-speed motor. Heating and cooling speed selection is made by moving the switch on the integrated control located in the furnace.

#### **Verifying Burner Operation**

---

**! CAUTION:**

---

**The door over the burners may only be open for inspection purposes only. The door must be installed during unattended operation.**

---

1. Remove the burner compartment door.
2. Set the thermostat above room temperature and observe the ignition sequence. **NOTE:** The burner flame should carry over immediately between all burners without lifting off, curling, or floating. The flames should be blue, without yellow tips.
3. After validating the flame, change thermostat setting to below room temperature.
4. Verify the burner flame is completely extinguished.
5. Replace the burner compartment door.

#### **Verifying Operation of the Supply Air Limit Switch**

**Note:** A properly functioning limit switch should turn off the gas valve when the return is blocked (time depends on how well the return air is blocked). The circulating air and combustion blowers should continue to run when the limit switch opens.

1. Verify the blower door is securely mounted in place and that there is power to the furnace.
2. Block the return airflow to the furnace by installing a close-off plate in place of or upstream of the filter(s).
3. Set the thermostat above room temperature and observe the Operating Sequence (page 25).
4. Remove the close-off immediately after the limit switch opens. If the furnace continues to operate with no return air, set the thermostat below room temperature, shut off the power to the furnace, and replace the limit switch.



## OPERATING SEQUENCE

The operating sequences for the heating, cooling, and fan modes are described below. Refer to the field and furnace wiring diagrams: (Figure 19 page 22), (Figure 20, page 22) and (Figure 24, page 34).

### Heating Cycle

1. The thermostat calls for heat by energizing the **W** terminal with 24VAC.
2. The control verifies the pressure switch is open.
3. If the pressure switch is open, the control energizes the inducer and waits for the pressure switch to close. The pressure switch must close within 10 seconds.
4. The control runs the inducer for a 30 second pre-purge.
5. The control energizes the Hot Surface Igniter (HSI) output for the appropriate warm-up time limit.
6. The control energizes the main gas valve for 3 seconds.
7. If the flame proved and ignites the gas, the control de-energizes the HSI. The gas valve and inducer remains energized. The control goes to blower on delay.
8. If flame is present, the control energizes the blower on the selected HEAT speed 30 seconds after the gas valve opened. The gas valve and inducer remain energized.
9. When the thermostat demand for heat is satisfied, the control de-energizes the gas valve. The Inducer output remains on for a 30 second post-purge period.
10. Blower off timing begins when the thermostat is satisfied. The control will operate at the selected HEAT speed of 60, 90, 120, or 180 seconds. If the blower off delay jumper is not present, the fan should still operate for 120 seconds at the selected HEAT speed. The Indoor blower motor is de-energized after a blower off delay as selected by the movable jumper.

### Cooling Cycle

1. The thermostat calls for cooling by energizing the **Y** terminal with 24VAC.
2. The control energizes the blower in cooling speed and sends 24VAC to the contactor in the condensing unit
3. When the thermostat removes the call for cooling, the contactor in the outdoor condensing unit is de-energized and the control continues to run the fan for a period of 60 seconds.

### Fan Mode

- When the thermostat energizes the **G** terminal for continuous fan (without calling for heat or cooling), the indoor fan is energized on the selected FAN speed.
- If a call for cooling occurs during continuous fan, the blower will switch over to the selected COOL speed.

- If the **W** terminal receives a call for heat during continuous fan, the blower will de-energize.
- A call for fan is ignored while in lockout.

## MAINTENANCE



### WARNING:

**These maintenance instructions are primarily intended to assist qualified technicians experienced in the proper maintenance and operation of this appliance.**

Proper maintenance is most important to achieve the best performance from a furnace. Follow these instructions for years of safe, trouble free operation.

- Always replace the doors on the furnace after servicing or cleaning/changing the filters. **Do not operate the furnace without all doors and covers in place.**
- Verify the thermostat is properly installed and will not be affected by drafts or heat from lamps or other appliances.
- To achieve the best performance and minimize equipment failure it is recommended that a yearly maintenance checkup be performed. At a minimum, this check should include the following items:

### Air Filter(s)



### WARNING:

**Never operate the furnace without a filter in place. Dust and lint can build up on internal components, resulting in loss of efficiency, equipment damage, and possible fire.**

**NOTE:** Air filter(s) are not supplied with the furnace as shipped from the factory. The installer must provide a high velocity filter and rack for a filter in the return air duct adjacent to the furnace, or in a return air grill to the furnace. It is recommended that filters be cleaned or replaced monthly. New or newly renovated homes may require more frequent changing until the construction dust has minimized.

Filters designed to remove smaller particles such as pollen, may require additional maintenance. Filters for side return and bottom return applications are available from most local distributors.

### Blower Compartment

Dirt and lint can create excessive loads on the motor resulting in higher than normal operating temperatures and shortened service life. It is recommended that the blower compartment be cleaned of dirt or lint that may have accumulated in the compartment or on the blower and motor as part of the annual inspection.

## Cleaning of Burners

If the burners must be cleaned, follow steps 1-12. See Figure 34 or 35 (page 46) for component location and identification.

1. Shut off gas supply to the furnace at the meter or at a manual valve in the supply piping.
2. Turn off all power to the furnace and set the thermostat to it's lowest setting.
3. Remove the burner door from the furnace.
4. Turn the gas control switch to the OFF position.
5. Disconnect the wires from the gas valve, igniter, flame sensor, and flame rollout switch.
6. Using two wrenches, separate the ground-joint union in the gas supply piping at the furnace.
7. Remove the piping between the Gas Valve and the ground-joint union. (If applicable).
8. Remove all screws securing the Manifold Assembly to the Burner Box.
9. Carefully remove the burner assembly from the furnace. **DO NOT DAMAGE THE IGNITER WHILE REMOVING THE BURNER ASSEMBLY.**
10. Inspect the burners for accumulated dust or debris. If necessary carefully clean them with a soft wire brush and a vacuum cleaner. **DO NOT DAMAGE THE IGNITER WHILE CLEANING THE BURNER.**
11. Replace all the parts in reverse order from which they were removed.
12. Follow the lighting instructions found on the furnace door to return the furnace to operation. Verify proper operation after servicing.

## Heat Exchanger and Burner Maintenance

The furnace should operate for many years without soot buildup in the flue passageways, however, the flue, vent system, and burners should be inspected and cleaned (if required) by a qualified service technician annually to ensure continued safe operation. Pay attention to any deterioration from corrosion or other sources.

## Lubrication

The bearings in the blower motor and inducer blower used in these furnaces are pre-lubricated and sealed by the manufacturer. No further oiling of the bearings is required for the life of the motor.

## Vent System

Check the inlet pipe (if applicable) and outlet pipe to ensure they are not blocked by debris. Any damaged section of vent pipe must be replaced, and any obstruction or blockage must be removed prior to operating the furnace.



## WARNING:

---

**Holes in the vent pipe or heat exchanger can cause combustion products to enter the home. Replace the vent pipe or heat exchanger if leaks are found. Failure to prevent the circulation of combustion products into the living space can create potentially hazardous conditions including carbon monoxide poisoning that could result in personal injury or death.**

---

---

## TROUBLESHOOTING

**If the furnace fails to operate check the following:**

- Is the thermostat operating properly?
- Are the blower compartment door(s) in place?
- Is the furnace disconnect closed?
- Has the circuit breaker tripped or the control board fuse burned open?
- Is the gas turned on?
- Are any manual reset switches open?
- Is the filter dirty or plugged?
- Is the flame sensor coated? (Remove and clean with steel wool. **(Do not use emery cloth or sandpaper!)**)
- Is there blockage in the condensate drain switch? Also verify that there is no double trapping of condensate.
- Is the secondary heat exchanger free of debris and clogs?
- Is evaporator coil clean and free of debris (If applicable).

- Are all the LED's on the furnace control board constantly ON? If not, refer to Table 7 (page 33) or the wiring diagram (Figure 24, page 34) to determine fault condition.

**IMPORTANT NOTE: The furnace will lock out after 5 failed attempts for ignition and will try again every hour if the call for heat remains.**

- If the Inducer Blower is operating, and items above have been verified, check the Blower Limit Switch and reset if necessary. See Figure 34 or 35 (page 46) for component location.
- If the furnace operates when the Blower Limit Switch is reset, contact a qualified service technician to identify and repair the problem.
- If the furnace still doesn't operate, check the Flame Roll-out Switches (Figure 34 or 35) and reset if necessary.
- If the furnace operates when the Flame Rollout Switch is reset, contact a qualified service technician to identify and repair the problem.

**DESCRIPTION OF COMPONENTS**

The descriptions below are various functional components that affect the operation and shutting down of this furnace. Some of these components and their locations are shown in Figures 34 and 35. If any component of the furnace must be replaced, use only factory authorized replacement parts specified in the Replacement Parts List provided online.

**Blower Limit Switch**

The Blower switch prevents furnace operation when blower is not operational.

**Condensate Drain Switch**

The Condensate Drain Switch will shut down the furnace if the condensate drain from the Collector Pan becomes clogged.

**Flame Sensor**

The flame sensor verifies when a flame has carried over from the igniter to the opposite end burner. If no flame is detected, the furnace will shut down within 4 seconds.

**Flame Roll-Out Switch**

The flame roll-out switch verifies that the burner flames are drawn into the heat exchanger tubes. If the burner

flames are not properly drawn into the heat exchanger, the flame roll-out switch will close the gas valve and initiate the shutdown cycle.

**Gas Valve**

The gas valve controls the flow of gas to the burners. When the gas valve is energized it automatically opens and regulates the gas pressure in the manifold.

**Inducer Assembly**

The inducer assembly vents products of combustion to the outside.




**Pressure Switch**

The pressure switch verifies that the inducer is drawing the combustion gases through the heat exchanger. If the flame is not properly drawn into the heat exchanger tube, the rollout switch or the flame sensor will shut the furnace down.

**Supply Air Limit Switch**

The supply air limit switch prevents the air temperature leaving the furnace from exceeding the maximum allowable outlet air temperature.

**FIGURES AND TABLES**

UPFLOW, DOWNFLOW & HORIZONTAL INSTALLATION CLEARANCES*		
Left Side		0 In.
Right Side		0 In.
Vent		1 In.
Back		0 In.
Top		1 In.
Front		4 In.**
* These are the listed clearances to combustible materials.		
** Allow 24 in. minimum clearance for servicing. Recommended clearance is 36 in.		
The furnace is listed for installation on combustible or non-combustible flooring. However, wood is the only combustible flooring allowed for installation. Downflow models must use the appropriate subbase kit when installing over a wood floor.		
<b>UPFLOW APPLICATION</b> 	<b>HORIZONTAL APPLICATION</b> 	<b>DOWNFLOW APPLICATION</b> 

**Table 3. Minimum Clearances to Combustible Material**

# FURNACE DIMENSIONS

*SC Model #'s	Dimension "A"	Dimension "B"	Dimension "C"
038D-23A	14 1/4	12 5/8	12 7/8
054D-24B	17 1/2	15 7/8	16 1/8
072D-24B			
072D-35C	21	19 3/8	19 5/8
090D-35C	24 1/2	22 7/8	23 1/8
108D-45D			
120D-45D			

**NOTES:**  
Dimensions shown in inches.






Figure 22. \*SC 92.1% High Efficiency Upflow/Horizontal Furnaces

SL Model #'s	Dimension "A"	Dimension "B"	Dimension "C"
054D-24B	17 1/2	15 7/8	16 1/8
072D-24B	21	19 3/8	19 5/8
120D-45D	24 1/2	22 7/8	23 1/8

**NOTES:**  
Dimensions shown in inches.






Figure 23. \*SL 92.1% High Efficiency Downflow Furnaces

## AIRFLOW DATA

UPFLOW / HORIZONTAL GAS FURNACES																		
Model Numbers	Heating Input (Btuh)	Motor Speed	External Static Pressure (Inches Water Column)															
			0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
			CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise
SC038D-23A Bottom Return	38,000	High*	1,245	26	1,200	27	1,150	28	1,100	29	1,050	31	985	33	920	35	865	37
		Med-High	1,115	29	1,075	30	1,030	31	990	33	935	35	880	37	815	40	740	44
		Med-Low**	785	41	770	42	745	43	720	45	680	48	640	51	595	54	530	61
		Low	645	50	630	51	610	53	580	56	555	58	525	62	480	67	420	77
SC038D-23A Side Return	38,000	High*	1,330	24	1,285	25	1,230	26	1,175	28	1,125	29	1,055	31	985	33	925	35
		Med-High	1,195	27	1,150	28	1,100	29	1,060	31	1,000	32	940	34	875	37	790	41
		Med-Low**	840	39	825	39	800	40	770	42	730	44	685	47	640	51	560	58
		Low	680	48	675	48	655	49	620	52	600	54	560	58	515	63	450	72
SC054D-24B Bottom Return	54,000	High*	1,550	30	1,520	30	1,485	31	1,450	32	1,410	33	1,360	34	1,300	35	1,255	37
		Med-High	1,250	37	1,220	38	1,200	38	1,170	39	1,140	40	1,105	42	1,065	43	1,010	46
		Med-Low**	935	49	910	51	880	52	850	54	815	56	785	59	735	63	680	68
		Low	720	64	690	67	655	70	620	74	585	79	550	84	520	88	485	95
SC054D-24B Side Return	54,000	High*	1,630	28	1,595	29	1,560	29	1,525	30	1,480	31	1,430	32	1,365	34	1,320	35
		Med-High	1,315	35	1,280	36	1,260	37	1,230	37	1,200	38	1,160	40	1,120	41	1,060	43
		Med-Low**	980	47	955	48	925	50	890	52	855	54	825	56	775	59	715	64
		Low	755	61	725	63	690	67	650	71	615	75	580	79	545	84	510	90
SC072D-24B Bottom Return	72,000	High*	1,590	39	1,550	40	1,525	40	1,475	42	1,425	43	1,380	44	1,325	46	1,240	49
		Med-High**	1,260	49	1,240	49	1,220	50	1,185	52	1,160	53	1,110	55	1,085	57	1,030	60
		Med-Low	1,125	55	1,110	55	1,085	57	1,050	58	1,025	60	990	62	940	65	865	71
		Low	895	69	865	71	830	74	795	77	775	79	750	82	693	89	665	92
SC072D-24B Side Return	72,000	High*	1,670	37	1,630	38	1,600	38	1,550	40	1,495	41	1,450	42	1,390	44	1,300	47
		Med-High**	1,325	46	1,300	47	1,280	48	1,245	49	1,220	50	1,165	53	1,140	54	1,080	57
		Med-Low	1,180	52	1,165	53	1,140	54	1,100	56	1,075	57	1,040	59	985	62	910	67
		Low	940	65	910	67	870	70	935	66	815	75	790	78	730	84	640	96
SC072D-35C Bottom Return	72,000	High*	1,895	32	1,790	34	1,720	36	1,630	38	1,550	40	1,445	42	1,330	46	1,225	50
		Med-High**	1,775	35	1,710	36	1,650	37	1,550	40	1,470	42	1,385	44	1,290	48	1,180	52
		Med-Low	1,255	49	1,200	51	1,155	53	1,105	56	1,050	58	1,000	61	925	66	830	74
		Low	1,140	54	1,100	56	1,065	58	1,025	60	980	63	930	66	870	70	805	76
SC072D-35C Side Return	72,000	High*	1,970	31	1,865	33	1,780	34	1,695	36	1,615	38	1,505	41	1,385	44	1,275	48
		Med-High**	1,845	33	1,780	34	1,715	36	1,615	38	1,530	40	1,440	43	1,340	46	1,230	50
		Med-Low	1,305	47	1,250	49	1,200	51	1,150	53	1,090	56	1,040	59	965	64	865	71
		Low	1,185	52	1,145	54	1,110	55	1,065	58	1,020	60	965	64	905	68	840	73
SC072D-35C Side + Bottom or 2 Sides	72,000	High*	1,990	31	1,880	33	1,805	34	1,710	36	1,630	38	1,510	41	1,400	44	1,285	48
		Med-High**	1,865	33	1,795	34	1,735	35	1,630	38	1,545	40	1,455	42	1,355	45	1,240	49
		Med-Low	1,320	46	1,260	49	1,215	50	1,160	53	1,105	56	1,050	58	970	63	875	70
		Low	1,200	51	1,155	53	1,120	55	1,075	57	1,030	60	975	63	915	67	845	73

**Table 4. \*SC - 92.1% AFUE, Single Stage, Upflow/Horizontal Gas Furnace**

UPFLOW HORIZONTAL / GAS FURNACES																		
Model Number	Heating Input (Btuh)	Motor Speed	External Static Pressure (Inches Water Column)															
			0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
			CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise
SC090D-35C Bottom Return	90,000	High*	2,155	36	2,090	37	2,015	38	1,960	39	1,910	40	1,835	42	1,755	44	1,660	46
		Med-High**	2,015	38	1,960	39	1,920	40	1,860	41	1,805	42	1,755	44	1,695	45	1,615	47
		Med-Low	1,705	45	1,675	46	1,640	47	1,590	48	1,555	49	1,495	51	1,435	53	1,340	57
		Low	1,410	54	1,390	55	1,365	56	1,330	58	1,310	59	1,275	60	1,235	62	1,210	63
SC090D-35C Bottom Return	90,000	High*	2,155	36	2,090	37	2,015	38	1,960	39	1,910	40	1,835	42	1,755	44	1,660	46
		Med-High**	2,015	38	1,960	39	1,920	40	1,860	41	1,805	42	1,755	44	1,695	45	1,615	47
		Med-Low	1,705	45	1,675	46	1,640	47	1,590	48	1,555	49	1,495	51	1,435	53	1,340	57
		Low	1,410	54	1,390	55	1,365	56	1,330	58	1,310	59	1,275	60	1,235	62	1,210	63
SC090-35C Side Return	90,000	High*	2,240	34	2,175	35	2,100	37	2,040	38	1,985	39	1,910	40	1,825	42	1,725	44
		Med-High**	2,095	37	2,040	38	2,000	38	1,935	40	1,875	41	1,825	42	1,765	43	1,680	46
		Med-Low	1,775	43	1,740	44	1,705	45	1,655	46	1,615	47	1,555	49	1,490	51	1,335	57
		Low	1,465	52	1,445	53	1,420	54	1,385	55	1,360	56	1,325	58	1,285	60	1,260	61
SC090-35C Side + Bottom or 2 Sides	90,000	High*	2,265	34	2,195	35	2,115	36	2,060	37	2,005	38	1,930	40	1,845	42	1,745	44
		Med-High**	2,115	36	2,060	37	2,015	38	1,955	39	1,895	40	1,845	42	1,780	43	1,695	45
		Med-Low	1,790	43	1,760	44	1,725	44	1,670	46	1,635	47	1,570	49	1,510	51	1,410	54
		Low	1,480	52	1,460	53	1,435	53	1,400	55	1,375	56	1,340	57	1,300	59	1,270	60
SC108-45D Bottom only or 2 openings	108,000	High*	2,135	43	2,095	44	2,040	45	1,975	47	1,910	48	1,840	50	1,735	53	1,675	55
		Med-High**	2,000	46	1,955	47	1,900	48	1,845	50	1,800	51	1,735	53	1,665	55	1,570	59
		Med-Low	1,665	55	1,660	55	1,625	57	1,590	58	1,530	60	1,500	61	1,415	65	1,340	69
		Low	1,385	66	1,360	68	1,310	70	1,300	71	1,275	72	1,250	74	1,200	77	1,150	80
SC108-45D Side Return	108,000	High*	2,115	43	2,075	44	2,020	46	1,955	47	1,890	49	1,822	50	1,720	53	1,660	55
		Med-High**	1,980	46	1,935	48	1,880	49	1,830	50	1,780	52	1,720	53	1,650	56	1,555	59
		Med-Low	1,650	56	1,645	56	1,610	57	1,575	58	1,515	61	1,485	62	1,400	66	1,330	69
		Low	1,370	67	1,345	68	1,300	71	1,290	71	1,260	73	1,240	74	1,190	77	1,140	81
SC120-45D Bottom only or 2 openings	120,000	High*	2,135	48	2,095	49	2,040	50	1,975	52	1,910	54	1,840	56	1,735	59	1,675	61
		Med-High**	2,000	51	1,955	52	1,900	54	1,845	55	1,800	57	1,735	59	1,665	61	1,570	65
		Med-Low	1,665	61	1,660	62	1,625	63	1,590	64	1,530	67	1,500	68	1,415	72	1,340	76
		Low	1,385	74	1,360	75	1,310	78	1,300	79	1,275	80	1,250	82	1,200	85	1,150	89
SC120-45D Side Return	120,000	High*	2,115	48	2,075	49	2,020	51	1,955	52	1,890	54	1,822	56	1,720	59	1,660	62
		Med-High**	1,980	52	1,935	53	1,880	54	1,830	56	1,780	57	1,720	59	1,650	62	1,555	66
		Med-Low	1,650	62	1,645	62	1,610	63	1,575	65	1,515	67	1,485	69	1,400	73	1,330	77
		Low	1,370	75	1,345	76	1,300	79	1,290	79	1,260	81	1,240	82	1,190	86	1,140	90
* Factory Set Cooling Speed ** Factory Set Heating Speed			<b>NOTES:</b> 1. Two openings are recommended for airflows above 1,600 CFM if filter(s) is(are) adjacent to furnace 2. Temperature rises in the table are approximate. Actual temperature rises may vary. 3. Temperature rises shaded in gray are for reference only. These conditions are not recommended															

Table 4. Continued

DOWNFLOW GAS FURNACES																		
Model Number	Heating Input (Btuh)	Motor Speed	External Static Pressure (Inches Water Column)															
			0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
			CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise	CFM	Rise
SL054-24B	54,000	HIGH*	1,580	29	1,550	30	1,520	30	1,485	31	1,460	32	1,425	32	1,375	33	1,320	35
		MED-HIGH	1,240	37	1,230	37	1,210	38	1,185	39	1,165	39	1,135	41	1,100	42	1,045	44
		MED-LOW**	1,145	40	1,120	41	1,100	42	1,080	43	1,055	44	1,030	45	985	47	940	49
		LOW	895	51	870	53	850	54	825	56	800	58	770	60	740	62	715	64
SL072-24B	72,000	HIGH*	1,560	39	1,530	40	1,500	41	1,480	41	1,435	43	1,400	44	1,360	45	1,310	47
		MED-HIGH**	1,245	49	1,225	50	1,205	51	1,180	52	1,150	53	1,125	55	1,090	56	1,045	59
		MED-LOW	1,085	57	1,070	57	1,045	59	1,025	60	1,000	61	970	63	930	66	880	70
		LOW	850	72	830	74	800	77	780	79	760	81	730	84	710	86	685	90
SL090-35C	90,000	HIGH*	1,955	39	1,905	40	1,835	42	1,795	43	1,730	44	1,620	47	1,545	50	1,450	53
		MED-HIGH**	1,845	42	1,790	43	1,750	44	1,680	46	1,515	51	1,540	50	1,475	52	1,410	54
		MED-LOW	1,320	58	1,290	59	1,250	61	1,215	63	1,180	65	1,120	68	1,050	73	970	79
		LOW	1,190	64	1,165	66	1,125	68	1,080	71	1,055	73	1,000	77	945	81	875	88
SL120-45D	120,000	HIGH*	2,215	46	2,150	48	2,075	49	2,035	50	1,970	52	1,905	54	1,800	57	1,745	59
		MED-HIGH**	2,050	50	2,015	51	1,955	52	1,900	54	1,860	55	1,795	57	1,720	59	1,620	63
		MED-LOW	1,720	59	1,690	60	1,655	62	1,640	62	1,610	63	1,560	66	1,505	68	1,465	70
		LOW	1,420	72	1,410	72	1,400	73	1,365	75	1,350	76	1,335	77	1,290	79	1,260	81

**NOTES:**

- \* Factory Set Cooling Speed      1. Temperature rises in the table are approximate. Actual temperature rises may vary.
- \*\* Factory Set Heating Speed      2. Temperature rises shaded in gray are for reference only. These conditions are not recommended.

**Table 5. \*SL - 92.1% AFUE, Single Stage, Downflow Gas Furnace**



## ELECTRICAL INFORMATION

Furnace Model Number *SC/*SL	Furnace Input (Btuh)	Cabinet Width (in.)	Nominal Electrical Supply	Maximum Operating Voltage	Minimum Operating Voltage	Maximum Furnace Amperes	Minimum Wire Gauge	Maximum Fuse or Circuit Breaker Amps**
038D-23A	38,000	14 ¼	115-60-1	127	103	6.6	14	15
054D-24B	54,000	17 ½	115-60-1	127	103	10.0	14	20
072D-24B	72,000	17 ½	115-60-1	127	103	10.0	14	20
072D-35C	72,000	21	115-60-1	127	103	9.3	14	15
090D-35C	90,000	21	115-60-1	127	103	15.6	14	30
108D-45D	108,000	24 ½	115-60-1	127	103	15.6	14	30
120D-45D	120,000	24 ½	115-60-1	127	103	15.6	12	30

\*\* Time-delay fuses or HACR-type circuit breakers are required.

Thermostat Wire Gauge	Recommended Thermostat Wire Length	
	2 - wire (Heating)	4 or 5 wire (Cooling)
24	55 ft.	25 ft.
22	90 ft.	45 ft.
20	140 ft.	70 ft.
18	225 ft.	110 ft.

**Table 6. Wire Length and Voltage Specifications**

Diagnostic Description	Green LED	Red LED
Control Fault (No Power)	Off	Off
L1/Neutral Polarity Fault	Flash	Flash
1 Hour Lockout	Alternating Flash	
Normal Operation	On	On
Pressure Switch Closed Fault	On	Flash
Pressure Switch Open Fault	Flash	On
Open Limit Switch Fault	Flash	Off
Diagnostic Description	Yellow LED	
Low Flame Sensor Signal	Continuous Flash	
Flame Present	On	

**Table 7. Control Board Fault Conditions**

## For 80+ and 90+ Single Stage Furnaces

Refer to the installation instructions provided with the furnace for the proper heating and cooling speeds for your application.

FAULT CONDITIONS			
Diagnostic Description	Green LED	Red LED	
Control Fault (No Power)	Off	Off	
L1 / Neutral Polarity Fault	Flash	Flash	
1 Hour Lockout	Alternating Flash		
Normal Operation	On	On	
Pressure Switch Closed Fault	On	Flash	
Pressure Switch Open Fault	Flash	On	
Open Limit Switch Fault	Flash	Off	
Diagnostic Description			
Low Flame Sensor Signal		Continuous Flash	
Flame Present		On	

If any of the original wire as supplied with the furnace must be replaced, it must be replaced with wiring material having a temperature rating of at least 105° C.

Use copper conductors only.

LEGEND:

FIELD WIRING	---
LOW VOLTAGE	— — —
HIGH VOLTAGE	— — — —

WD#710731-B




Figure 24. Wiring Diagram for Upflow and Downflow Models

## GAS INFORMATION

GAS FLOW RATES (CUBIC FEET PER HOUR)								
TIME FOR ONE REVOLUTION (SECONDS)	CUBIC FEET PER REVOLUTION OF GAS METER				TIME FOR ONE REVOLUTION (SECONDS)	CUBIC FEET PER REVOLUTION OF GAS METER		
	1	5	10			1	5	10
10	360	1,800	3,600		66	55	273	545
12	300	1,500	3,000		68	53	265	529
14	257	1,286	2,571		70	51	257	514
16	225	1,125	2,250		72	50	250	500
18	200	1,000	2,000		74	49	243	486
20	180	900	1,800		76	47	237	474
22	164	818	1,636		78	46	231	462
24	150	750	1,500		80	45	225	450
26	138	692	1,385		82	44	220	439
28	129	643	1,286		84	43	214	429
30	120	600	1,200		86	42	209	419
32	113	563	1,125		88	41	205	409
34	106	529	1,059		90	40	200	400
36	100	500	1,000		92	39	196	391
38	95	474	947		94	38	191	383
40	90	450	900		96	38	188	375
42	86	429	857		98	37	184	367
44	82	409	818		100	36	180	360
46	78	391	783		102	35	176	353
48	75	375	750		104	35	173	346
50	72	360	720		106	34	170	340
52	69	346	692		108	33	167	333
54	67	333	667		110	33	164	327
56	64	321	643		112	32	161	321
58	62	310	621		114	32	158	316
60	60	300	600		116	31	155	310
62	58	290	581		118	31	153	305
64	56	281	563		120	30	150	300

**Table 8. Gas Flow Rates**

CAPACITY OF BLACK IRON GAS PIPE (CU. FT. PER HOUR) FOR NATURAL GAS (SPECIFIC GRAVITY - 0.60)								
NOMINAL BLACK IRON PIPE DIAMETER (IN.)	LENGTH OF PIPE RUN (FT)							
	10	20	30	40	50	60	70	80
½	130	90	75	65	55	50	45	40
¾	280	190	150	130	115	105	95	90
1	520	350	285	245	215	195	180	170
1 ¼	1,050	730	590	500	440	400	370	350
1 ½	1,600	1,100	890	760	670	610		

**NOTES**

The cubic feet per hour listed in the table above must be greater than the cubic feet per hour of gas flow required by the furnace. To determine the cubic feet per hour of gas flow required by the furnace, divide the input rate of the furnace by the heating value (from gas supplier) of the gas.

$$\text{Cubic Feet Per Hour Required} = \frac{\text{Input To Furnace (Btu/hr)}}{\text{Heating Value of Gas (Btu/Cu. Ft.)}}$$

**Table 9. Black Iron Gas Pipe Capacities**

PROPANE GAS							
ALTITUDE ABOVE SEA LEVEL	INPUT (BTU)						
	38,000	54,000	72,000	90,000	108,000	120,000	
0 to 1,999 FT	56	56	56	56	56	56	ORIFICE SIZE
	10.0	10.0	10.0	10.0	10.0	10.0	MANIFOLD PRESSURE
2,000 to 2,999 FT	56	56	56	56	56	55	ORIFICE SIZE
	9.0	9.0	9.0	9.0	9.0	9.0	MANIFOLD PRESSURE
3,000 to 4,999 FT	56	56	56	56	56	55	ORIFICE SIZE
	8.5	8.5	8.5	8.5	8.5	8.5	MANIFOLD PRESSURE
5,000 to 5,999 FT	57	57	57	57	57	56	ORIFICE SIZE
	10.0	10.0	10.0	10.0	10.0	10.0	MANIFOLD PRESSURE
6,000 to 7,999 FT	57	57	57	57	57	56	ORIFICE SIZE
	9.0	9.0	9.0	9.0	9.0	9.0	MANIFOLD PRESSURE
8,000 to 10,000 FT	57	57	57	57	57	56	ORIFICE SIZE
	8.5	8.5	8.5	8.5	8.5	8.5	MANIFOLD PRESSURE

**Table 10. High Altitude Deration Chart for Propane Gas**

ALTITUDE ABOVE SEA LEVEL	LOCAL HEATING VALUE, BTU PER CUBIC FOOT								
	650	700	750	800	850	900	950	1,000	1,050
2,000 FT	LOW	LOW	LOW	LOW	LOW	LOW	HIGH	HIGH	HIGH
3,000 FT	LOW	LOW	LOW	LOW	LOW	LOW	HIGH	HIGH	HIGH
4,000 FT	LOW	LOW	LOW	LOW	LOW	HIGH	HIGH	HIGH	HIGH
5,000 FT	LOW	LOW	LOW	LOW	LOW	HIGH	HIGH	HIGH	HIGH
6,000 FT	LOW	LOW	LOW	LOW	HIGH	HIGH	HIGH	HIGH	HIGH
7,000 FT	LOW	LOW	LOW	LOW	HIGH	HIGH	HIGH	HIGH	HIGH
8,000 FT	LOW	LOW	LOW	HIGH	HIGH	HIGH	HIGH	HIGH	HIGH
9,000 FT	LOW	LOW	LOW	HIGH	HIGH	HIGH	HIGH	HIGH	HIGH
10,000 FT	LOW	LOW	HIGH	HIGH	HIGH	HIGH	HIGH	HIGH	HIGH

**Table 11. Natural Gas Heating Values**


NATURAL GAS - HIGH HEATING VALUE							
ALTITUDE ABOVE SEA LEVEL	INPUT (BTU)						
	38,000	54,000	72,000	90,000	108,000	120,000	
0 to 1,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	3.5	3.5	3.5	3.5	3.5	3.5	MANIFOLD PRESSURE
2,000 to 2,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	3.0	3.2	3.2	3.2	3.2	3.2	MANIFOLD PRESSURE
3,000 to 3,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	2.8	3.0	3.0	3.0	3.0	3.0	MANIFOLD PRESSURE
4,000 to 4,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	2.7	2.8	2.8	2.8	2.8	2.8	MANIFOLD PRESSURE
5,000 to 5,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	2.5	2.7	2.7	2.7	2.7	2.7	MANIFOLD PRESSURE
6,000 to 6,999 FT	49	49	49	49	49	49	ORIFICE SIZE
	3.5	3.5	3.5	3.5	3.5	3.5	MANIFOLD PRESSURE
7,000 to 7,999 FT	49	49	49	49	49	49	ORIFICE SIZE
	3.4	3.3	3.3	3.3	3.3	3.3	MANIFOLD PRESSURE
8,000 to 8,999 FT	49	49	49	49	49	49	ORIFICE SIZE
	3.2	3.0	3.0	3.0	3.0	3.0	MANIFOLD PRESSURE
9,000 to 9,999 FT	49	49	49	49	49	49	ORIFICE SIZE
	3.0	2.8	2.8	2.8	2.8	2.8	MANIFOLD PRESSURE

Table 12. High Altitude Deration Chart for Natural Gas - High Heating Value

NATURAL GAS - LOW HEATING VALUE							
ALTITUDE ABOVE SEA LEVEL	INPUT (BTU)						
	38,000	54,000	72,000	90,000	108,000	120,000	
0 to 1,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	3.5	3.5	3.5	3.5	3.5	3.5	MANIFOLD PRESSURE
2,000 to 2,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	3.5	3.5	3.5	3.5	3.5	3.5	MANIFOLD PRESSURE
3,000 to 3,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	3.1	3.3	3.3	3.3	3.3	3.3	MANIFOLD PRESSURE
4,000 to 4,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	2.9	3.1	3.1	3.1	3.1	3.1	MANIFOLD PRESSURE
5,000 to 5,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	2.8	2.9	2.9	2.9	2.9	2.9	MANIFOLD PRESSURE
6,000 to 6,999 FT	45	47	47	47	47	47	ORIFICE SIZE
	2.6	2.8	2.8	2.8	2.8	2.8	MANIFOLD PRESSURE
7,000 to 7,999 FT	48	49	49	49	49	49	ORIFICE SIZE
	3.3	3.4	3.4	3.4	3.4	3.4	MANIFOLD PRESSURE
8,000 to 8,999 FT	48	49	49	49	49	49	ORIFICE SIZE
	3.0	3.2	3.2	3.2	3.2	3.2	MANIFOLD PRESSURE
9,000 to 9,999 FT	48	49	49	49	49	49	ORIFICE SIZE
	2.8	2.9	2.9	2.9	2.9	2.9	MANIFOLD PRESSURE

Table 13. High Altitude Deration Chart for Natural Gas - Low Heating Value

## VENTING INFORMATION




V VENT TERMINAL     
  AIR SUPPLY INLET     
  AREA WHERE TERMINAL IS NOT PERMITTED

Clearance Location	CANADIAN INSTALLATIONS <sup>a</sup>	US INSTALLATIONS <sup>b</sup>	
	Direct Vent (2-pipe) & Conventional Vent (1-pipe) Furnaces	Direct Vent (2-pipe) Furnaces	Conventional Vent (1-pipe) Furnaces
A = Clearance above grade, veranda, porch, deck, balcony, or maximum expected snow level.	12 inches (30cm)	12 inches (30cm)	12 inches (30cm)
B = Clearance to window or door that may be opened.	6 inches (15cm) for appliances < 10,000 Btuh (3kW)	6 inches (15cm) for appliances < 10,000 Btuh (3kW)	4 ft. (1.2m) below or to side of opening; 1 ft. (300mm) above opening
	12 inches (30cm) for appliances 10,000 Btuh - 100,000 Btuh (30kW)	9 inches (23cm) for appliances 10,000 Btuh - 50,000 Btuh (30kW)	
	36 inches (91cm) for appliances > 100,000 Btuh (30Kw)	12 inches (30cm) for appliances > 50,000 Btuh (30Kw)	
C = Clearance to permanently closed window	*	*	*
D = Vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 2 feet (61cm) from the center line of the terminal.	*	*	*
E = Clearance to unventilated soffit.	*	*	*
F = Clearance to outside corner.	*	*	*
G = Clearance to inside corner.	*	*	*
H = Clearance to each side of center line extended above meter/regulator assembly.	3 feet (91cm) within a height 15 feet above the meter/regulator assembly	*	*
I = Clearance to service regulator vent outlet.	3 feet (1.83m)	*	*
J = Clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other appliance.	6 inches (15cm) for appliances < 10,000 Btuh (3kW)	6 inches (15cm) for appliances < 10,000 Btuh (3kW)	4 ft. (1.2m) below or to side of opening; 1 ft. (300mm) above opening
	12 inches (30cm) for appliances 10,000 Btuh - 100,000 Btuh (30kW)	9 inches (23cm) for appliances 10,000 Btuh - 50,000 Btuh (30kW)	
	36 inches (91cm) for appliances > 100,000 Btuh (30Kw)	12 inches (30cm) for appliances > 50,000 Btuh (30Kw)	
K = Clearance to mechanical air supply inlet.	6 feet (1.83m)	3 feet (91cm) above if within 10 feet (3m) horizontally	3 ft. (91cm) above if within 10 feet (3m) horizontally
L = Clearance above paved sidewalk or driveway located on public property.	7 feet (2.13m) <sup>c</sup>	*	7 ft. (2.13m)
M = Clearance under veranda, porch, deck, or balcony.	12 inches (30cm) <sup>d</sup>	*	*


**NOTES:**

- a In accordance with the current CSA B149.1 Natural Gas and Propane Installation Guide Code
- b In accordance with the current ANSI Z223.1 / NFPA 54 Natural Fuel Gas Code
- c A vent shall not terminate directly above a sidewalk or paved driveway that is located between two single family dwellings and serves both dwellings.
- d Permitted only if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.
- \* For clearances not specified in ANSI Z223.1 / NFPA 54 or CSA B149.1, the following statement shall be included: "Clearance in accordance with local installation codes, and the requirements of the gas supplier and the manufacturers installation instructions"

**Table 14. Vent Termination Clearances**




**Figure 25. Upflow Options**




**Figure 26. Horizontal Options - 1 Pipe Furnaces**






**Figure 27. Horizontal Options - 2-pipe Furnaces**




**Figure 28. Downflow Options**

## HORIZONTAL VENTING (2-Pipe Shown)



## VERTICAL VENTING (2-Pipe Shown)




**Figure 29. Horizontal and Vertical Venting**

## \*\*ATTENTION INSTALLERS\*\*

When running the 2" PVC pipe out through the top of the \*SC upflow furnace, there may be possible clearance issues when transitioning the PVC pipe from 2" to 3":

- If you have to increase the size of the PVC flue from 2" to 3", you may use two, 2" x 45° PVC elbows to achieve the clearances needed between the coil box and the 2x3 coupling (see Figure 30).
- Install the 2x3 coupling in the vertical run only. If the coupling is installed horizontally, it will allow water to build up inside the furnace and cause a lock out condition.
- To avoid the clearance issue, it is recommended that the furnace be vented through the left side or the right side of the cabinet as shown in Figures 25-28 (pages 38-41).



**Figure 30. Optional PVC Pipe Installation**

Furnace Models (BTU)	FURNACE INSTALLATION	SINGLE PIPE LENGTH (FT.) with 1 long radius elbow*		DIRECT VENT, DUAL PIPE LENGTH (FT.) with 1 long radius elbow on each pipe*	
		OUTLET 2" Diameter	OUTLET 3" Diameter	INLET/OUTLET 2" Diameter	INLET/OUTLET 3" Diameter
38,000	Upflow	50	70	60	80
54,000	Upflow	90	90	90	90
	Downflow	90	90	90	90
72,000	Upflow	90	90	90	90
	Downflow	90	90	90	90
90,000	Upflow	90	90	90	90
	Downflow	70	90	70	90
108,000	Upflow	70	90	60	90
120,000	Upflow	N/A	90	N/A	90
	Downflow	N/A	90	N/A	90

**\*NOTES:**

1. The length of 2" pipe needed to go from the inducer to the finish flange is 7 3/4" for upflow models and 15" for downflow models.
2. Subtract 2.5 ft. for each additional 2 inch long radius elbow, 5 ft. for each additional 2 inch short radius elbow, 3.5 ft. for each additional 3 inch long radius elbow, and 7 ft. for each additional 3 inch short radius elbow. Subtract 5ft for each 2" tee and 8ft for each 3" tee.
3. Two 45 degree elbows are equivalent to one 90 degree elbow.
4. This table applies for elevations from sea level to 2,000 ft. For higher elevations, decrease pipe lengths by 8% per 1,000 ft of altitude..

**Table 15. Vent Pipe Lengths**

## ACCESSORIES

The components below are included in the extra parts bag that is supplied with the purchase of your furnace. Depending on your particular installation, some of these components are optional and may not be used. Please refer to the descriptions and accompanying figures when installing these items. **NOTE:** The PVC items shown in Figure 33 are not provided in the extra parts bag.

1. Position a flange gasket (Figure 31) on a finish flange, aligning screw holes in the gasket and flange.
2. Position the flange (with gasket) on the furnace cabinet, aligning holes in gasket, flange and cabinet.
3. Secure flange and gasket to cabinet with three field supplied sheet metal screws.
4. Repeat steps 1-3 for other vent hole.




Figure 31. Finish Flanges

The 2 1/4" rubber grommet (Figure 32) is used to seal the opening between the furnace cabinet and the 2" PVC vent pipe. The rubber grommet should be installed in the 3" hole prior to running the vent pipe out of cabinet. No sealants are required.

The 7/8" rubber grommet (Figure 32) is used to seal the opening between the furnace cabinet and the gas pipe. The rubber grommet should be installed in the 1 5/8" hole prior to running the gas pipe into the cabinet. No sealants are required.




Figure 32. Rubber Grommets

The 2" PVC tee, reducer, and hose barb (Figure 33) are used when the inducer is rotated to vent out thru the left or right side of the furnace cabinet.

The 1/2" x 3/4" hose barb can be used to route the condensate drain to the outside of the cabinet. It must be installed from inside the cabinet with the threaded end inserted thru the 1 1/16" hole. The Condensate drain should be connected to the barbed end. Attach 1" PVC drain line to the threaded end.

**IMPORTANT NOTE:** Before permanently installing these components, it is recommended you dry-fit them first to ensure proper fit and alignment with other vent pipes.

1. Install the 1/2" x 1/2" hose barb on the 2" PVC reducer. Do not over tighten! **NOTE:** Use an adequate amount of Teflon tape on the threads. Do not use liquid sealants.
2. Install the reducer on one end of the PVC tee. Use appropriate primer and cement to permanently bond the reducer and tee together.

3. Install the tee on the 2" vent pipe that is extending out the side of the cabinet. Use appropriate primer and cement to permanently bond the tee to the 2" PVC pipe.
4. Verify all connections and joints for tight fit and proper alignment with other vent pipes.






Figure 33. 2" PVC Tee, Reducer and Hose Barb

## LOCATION OF FURNACE COMPONENTS



**Figure 34. Upflow/Horizontal Gas Furnace Components**



**Figure 35. Downflow Gas Furnace Components**



## INSTALLATION/PERFORMANCE CHECK LIST

<b>INSTALLER NAME:</b>	
CITY _____	STATE _____

<b>INSTALLATION ADDRESS:</b>	
CITY _____	STATE _____

UNIT MODEL # _____
UNIT SERIAL # _____

Minimum clearances per Table 3 (page 27)?	YES	NO
---	-----	----

Has the owner's information been reviewed with the home-owner?	YES	NO
--	-----	----

Has the literature package been left near the furnace?	YES	NO
--	-----	----

ELECTRICAL SYSTEM:		
Electrical connections tight?	YES	NO
Line voltage polarity correct?	YES	NO
Supply Voltage: _____ VOLTS		
Has the thermostat been calibrated?	YES	NO
Is the thermostat level?	YES	NO
Is the heat anticipator setting correct?	YES	NO

GAS SYSTEM:		
Gas Type: (circle one)	Natural Gas	Propane
Gas pipe connections leak tested?	YES	NO
Gas Line Pressure: _____ (in - W.C.)		
Is there adequate fresh air supply for combustion and ventilation?	YES	NO
Installation Altitude: _____ (FT.)		
Deration Percentage: _____ (%)		
Furnace Input: _____ (Btuh)		
Supply Air Temperature: _____ (° F)		
Return Air Temperature: _____ (° F)		
Temperature Rise: _____ (° F)		

VENTING SYSTEM:		
Vent free from restrictions?	YES	NO
Filter(s) secured in place?	YES	NO
Filter(s) clean?	YES	NO
Flue connections tight?	YES	NO
Is there proper draft?	YES	NO



**NORDYNE**  
O'Fallon, MO



**708809D**

**708809D** (Replaces 708809C)

Specifications and illustrations subject to change without notice or incurring obligations.  
Printed in U.S.A. (09/08)