



INSTALLATION INSTRUCTIONS

SEP

100,000 to 400,000 Btuh Series

UNIT HEATERS
Item #: 65245306
10/2008
© 2008

Table Of Contents

| | | | |
|--|---|--|----|
| SEP Unit Dimensions | 1 | Unit Start-Up | 9 |
| Shipping | 2 | To Turn Off Gas to Unit | 12 |
| CSA Requirements in USA | 2 | Heating Sequence of Operation | 12 |
| CSA Requirements in Canada | 2 | Ignition Control LED | 12 |
| Additional Requirements | 2 | High Altitude Adjustment | 12 |
| Unit Heater Installation | 2 | Gas Flow | 14 |
| Combustion and Ventilation Air | 3 | Gas Pressure Adjustment | 14 |
| Rotation of Combustion Air Inducer | 3 | Limit Control Switch | 14 |
| Venting | 4 | Louver Vane Adjustments | 14 |
| Electrical Connections | 8 | Combustion Air Pressure Switch | 14 |
| Typical SEP Wiring Diagram | 8 | Service | 14 |
| Gas Connection | 9 | Start-Up and Performance Checklist | 15 |
| Leak Check | 9 | Template | 17 |

RETAIN THESE INSTRUCTIONS
FOR FUTURE REFERENCE



Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.



⚠ WARNING

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.




WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Extinguish any open flame.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

SEP Unit Dimensions

NOTE — SEP models 100, 115, 145, 175 and 200 have a single fan. SEP models 230, 250, 300, 345 and 400 have two fans.

NOTE — Two spot nuts are furnished on SEP models 100, 115, 145, 175 and 200. Four spot nuts are furnished on SEP models 230, 250, 300, 345 and 400 models.



| Unit | A | | B | | C | | D | | E | | F | | G | | H | |
|----------------------------------|---------|-----|---------|-----|---------|------|---------|-----|---------|------|--------|-----|-------|----|---------|-----|
| | in. | mm | in. | mm | in. | mm | in. | mm | in. | mm | in. | mm | in. | mm | in. | mm |
| SEP-100 SEP-115 SEP-145 | 31-5/16 | 795 | 32-3/16 | 817 | 20-3/16 | 512 | 11-1/2 | 292 | 19-1/16 | 484 | 11-3/4 | 298 | 3-1/4 | 83 | 7-7/8 | 200 |
| SEP-175 SEP-200 | 31-5/16 | 795 | 32-3/16 | 817 | 23-1/8 | 588 | 11-1/2 | 292 | 22-1/16 | 560 | 8-1/2 | 216 | 3-1/4 | 83 | 8-11/16 | 220 |
| SEP-230* SEP-250* SEP-300* | 31-5/16 | 795 | 32-3/16 | 817 | 41-1/8 | 1045 | 3-11/16 | 97 | 40 | 1016 | 17-3/4 | 451 | 3-1/2 | 89 | 8-11/16 | 220 |
| SEP-345* SEP-400* | 31-5/16 | 795 | 32-3/16 | 817 | 41-1/8 | 1045 | 3-11/16 | 97 | 40 | 1016 | 17-1/2 | 445 | 3-1/2 | 89 | 9-13/16 | 248 |

*Unit contains dual fans.

Shipping

The heater is completely assembled and is shipped with installation and operating instructions, warranty certificate and flue transition. Upon receipt, check the unit for shipping damage. The receiving party should contact the last carrier immediately if any damage as a result of shipping is found.

CSA Requirements in USA

Installation of gas unit heaters must conform with local building codes or, in the absence of local codes, with the current edition of ANSI–Z223.1, National Fuel Gas Code.

Installation in aircraft hangers must be in accordance with the current edition of ANSI/NFPA No. 409, Standard for Aircraft Hangers.

Installation in parking structures must be in accordance with the current edition of ANSI/NFPA No. 88A, Standard for Parking Structures.

Installation in repair garages must be in accordance with the current edition of ANSI/NFPA No. 88B, Standard for Repair Garages.

Authorities having jurisdiction should be consulted before installation. Air for combustion and ventilation must conform to the methods outlined in ANSI Z223.1, section 5.3, Air for Combustion and Ventilation, or applicable provisions of local building codes.

ANSI–Z223.1, National Fuel Gas Code is available from:

American National Standard Institute Inc.
11 West 42nd Street
New York, NY 10036

These units are C.S.A. international design certified. These unit heaters are certified for clearances to combustible material as listed in table 1 and on unit rating plate.

Accessibility and service clearances must be observed in addition to fire protection clearances.

All electrical wiring and grounding for unit must be in accordance with the regulations of the current edition of ANSI/NFPA No. 70, National Electric Code.

The National Electric Code is available from:

National Fire Protection Association
1 Batterymarch Park
PO Box 9101
Quincy, MA 02269–9101

CSA Requirements in Canada

The instructions are intended only as a general guide and do not supersede local codes in any way. Authorities having jurisdiction should be consulted before installation. The installation must conform with local building codes or in the absence of local codes the current edition of CSA–B149 installation compliance codes. All electrical wiring and grounding for the unit must also comply with the current edition of CSA C22.1, Canadian Electrical Code.

These unit heaters are CSA–certified for clearances to combustible material listed on the rating plate and table 1. Adequate clearance must be provided around the appliance and around air openings into the combustion chamber. Provision must be made for service accessibility.

NOTE: Fire protection clearances may be exceeded to provide additional space for service and accessibility.

PUBLIC GARAGE

- 1 – In a storage area, clearance from the heater to combustible materials must be such that the combustible material must not attain a temperature above 160°F (71°C) during continuous operation of the unit.
- 2 – Maintain an 8–foot (2.5 m) minimum clearance from the floor to the bottom of the heater. Refer to the current edition of CSA–B149 installation compliance codes.

AIRCRAFT HANGER

- 1 – In an area where aircraft are housed or serviced, a 10–foot (3 m) minimum clearance from the highest surface of the aircraft to bottom of the heater must be maintained.
- 2 – In other areas an 8–foot (2.5 m) minimum clearance from the floor to bottom of heater must be maintained.
- 3 – Heaters should be located so that they are protected from damage from aircraft or other appliances needed for servicing of aircraft. Refer to requirements of the enforcing authorities.

In a confined area, the heater must be installed in accordance with the CSA–B149 installation compliance codes. Be sure to check with local codes and ordinances for additional requirements.

Additional Requirements

The Commonwealth of Massachusetts stipulates the following additional requirements:

- 1 – Gas furnaces shall be installed by a licensed plumber or gas fitter only.
- 2 – The gas cock must be “T handle” type.

Unit Heater Installation

Install the unit in the desired location as governed by clearances, vent connection, air direction, gas supply, electrical supply and service accessibility.

On SEP models 100, 115, 145, 175, and 200, spot nuts are furnished at the balance point (two positions only). On SEP models 230, 250, 300, 345 and 400, spot nuts are furnished at each corner of the unit. Spot nuts will accommodate 3/8" x 16 threaded rods.

- 1 – Cut threaded rods to desired length and slide a 3/8" nut onto the rod.
- 2 – Slide a flat washer onto the threaded rod AFTER the nut (7/16" inside diameter X 1" outside diameter X 1/16" thick washer).
- 3 – Screw the rods (two or four) into the spot nuts on the unit.
- 4 – Tighten nuts to secure unit to rods.

⚠ IMPORTANT

Do not use the gas manifold pipe to lift unit. Any excessive upward or downward force on the manifold pipe and bracket assembly can cause the ignition burner and igniter to become misaligned.

TABLE 3
UNIT CLEARANCES TO COMBUSTIBLE MATERIALS

| Top | | Sides | | Bottom | | Rear | | Flue | |
|-----|-----|-------|-----|--------|----|------|-----|------|-----|
| in | mm | in | mm | in | mm | in | mm | in | mm |
| 6 | 152 | 6 | 152 | 0 | 0 | 18 | 457 | 6 | 152 |

TABLE 4
MAXIMUM MOUNTING HEIGHTS

| Model Number | Feet (Meters) |
|--|---------------|
| SEP-100 and SEP-115 | 16 (4.9) |
| SEP-145, SEP-175, and SEP-200 | 20 (6.1) |
| SEP-230, SEP-250, SEP-300, SEP-345 and SEP-400 | 30 (9.1) |

Combustion and Ventilation Air

Adequate facilities for supplying air for combustion and ventilation must be provided in accordance with the current edition of ANSI Z223.1, section 5.3, and CSA-B149 installation compliance codes, or applicable provisions of local building codes.

All gas-fired appliances require air to be used for the combustion process. In many buildings today, there is a negative indoor air pressure caused by exhaust fans, etc. If sufficient quantities of combustion air are not available, the heater or another appliance will operate in an inefficient manner, resulting in incomplete combustion which can result in the production of excessive carbon monoxide.

⚠ CAUTION

Insufficient combustion air can cause headaches, nausea, dizziness, asphyxiation or death.

If indoor air is to be used for combustion, it must be free of the following substances or the life of the heat exchanger will be adversely affected: chlorine, carbon tetrachloride, cleaning solvent, halogen refrigerants, acids, cements and glues, printing inks, fluorides, paint removers, varnishes, or any other corrosives.

Rotation of Combustion Air Inducer

The combustion air inducer on some units may be rotated to better suit individual applications. The combustion air inducer on SEP models 100, 115 and 145 may be rotated 90° either to the left or right of the original vertical position.

NOTE – It is not permissible to rotate the combustion air inducer on SEP models 175, 200, 230, 250, 300, 345 and 400.

Rotate the induced draft assembly as follows:

- 1 – Remove the unit heater from the carton.
- 2 – Decide unit heater orientation. It may be advantageous to rotate the combustion air inducer. The vent can be installed in one of three discharge positions: up, left, or right. If the inducer is to be rotated, follow the instructions in this section; otherwise, refer to instructions under “Venting” section.
- 3 – Before making an electrical or gas connections, remove the securing screws on the flue box/combustion air inducer. See figure 1.




FIGURE 1

- 4 – Remove the flue box/combustion air inducer assembly ensuring that the gasket is not damaged. Should the gasket become damaged, replace it.

- 5 – Use a 1/4" socket to remove the three screws which secure the combustion air inducer. Remove the inducer and gasket from the flue box ensuring that the gasket is not damaged. Should the gasket become damaged, replace it.
- 6 – Use the template provided in the back of this manual to mark new hole locations. Drill holes in flue box with a 7/32" in drill bit.
- 7 – Rotate both the inducer and the gasket 90° to the desired position. Reinsert and tighten the three inducer securing screws (#8–16 X 1/2" HWHSMS). Place the gasket between the combustion air inducer and the flue box.
- 8 – Position the flue box/combustion air inducer assembly on the vest panel. Place the gasket between the flue box and the vest panel. Fasten the flue box using the flue box securing screws (#10–16 X 5/8" HWHSMS) and a 5/16" driver.
- 9 – The unit heater is now ready for installation as described in the section under Venting.

Venting

NOTE – The vent is a passageway, vertical or nearly so, used to convey flue gases from an appliance, or its vent connector, to the outside atmosphere. The vent connector is the pipe or duct that connects a fuel–gas burning appliance to a vent or chimney.

NOTE – Local codes may supersede any of these provisions.

GENERAL RECOMMENDATION AND REQUIREMENTS

SEP unit heaters must be vented in compliance with all local codes or requirements of the local utility, the current standards of the ANSI Z223.1 or CSA–B149 installation compliance codes, and the following instructions.

A sheet metal flue transition is supplied with this certified unit. It must not be modified or altered and must be installed on the outlet of the combustion air inducer assembly prior to the installation of the vent connector. Failure to comply with this requirement will void the certification of the unit by the approval agencies.

In all cases, a flue transition piece (supplied) is required to fit over the outlet of the combustion air inducer assembly on the appliance.

A single–wall vent must have all seams and joints sealed with pressure–sensitive aluminum tape or silicone rubber sealant. Aluminum tape must meet the provisions of SMACNA AFTS–100–73 Standards. The aluminum tape must have a temperature rating of 400°F (204°C). Silicone rubber sealant must have a temperature rating of 482°F (250°C), i.e., Dow Corning RTV–736 or equivalent. All joints must be secured with at least two corrosion resistant screws. All joints must be checked for gas tightness after installation. Single–wall vent must not pass through any attic, interior wall, concealed space, or floor.

TABLE 5
VENT CONNECTOR DIAMETERS

| Model Number | Connector Diameter |
|---|--------------------|
| SEP–100, SEP–115 SEP–145 | 4" (102mm) |
| SEP–175 SEP–200 SEP–230 SEP–250 SEP–300 | 5" (127mm) |
| SEP–345 SEP–350 SEP–400* | 6" (152mm) |

* On SEP–400 models, a minimum 6" (162mm) straight section must be placed between the flue transition and the first elbow of the vent.

VERTICAL VENTS USING METAL VENT PIPE

All SEP unit heaters are listed as Category 1 appliances for vertical vent installations.

- 1 – All SEP unit heaters are to be used with NFPA– or ANSI– approved chimneys or U.L.–listed type B–1 gas vents where applicable, as well as the modifications and limitations listed in figure 2.
- 2 – Keep the vent connector runs as short as possible with a minimum number of elbows. Refer to ANSI Z223.1 or CSA–B149 installation compliance codes for maximum vent and vent connector lengths. Horizontal run of the vent connector from the combustion air inducer outlet to the chimney/vent pipe cannot exceed the values in table 6. A single 3" (76 mm), 4" (102mm), or 5" (127 mm) elbow is equivalent to 5 feet (1.53 m) of vent pipe. A single 6" (152mm) elbow is equivalent to 9 feet (2.75 m) of vent pipe.
- 3 – When the length of a single wall–vent connector, including elbows, exceeds the length shown in table 3, the vent connector must be insulated along its entire length with a minimum of 1/2" (15mm) thick

foil faced fiberglass 1–1/2 pound density insulation. If a single–wall vent connector is used in an unheated area it must be insulated. Failure to do so will result in condensation of flue gases.

- 4 – All SEP models may be vented vertically as a single appliance, or as a common vent with other gas–fired appliances. In a common venting situation, vent connectors for other appliances must be joined to the vent at least 4" (102 mm) above the connected SEP connection. When common venting with another SEP unit, maintain at least a 4" (102 mm) vertical separation between the vent connectors.
- 5 – Clearance to combustible material is 6" (152mm) for single–wall vent pipe except where a listed clearance thimble is used. Clearance to combustible material for type B–1 vent or factory–built chimney is per manufacturer’s instructions.
- 6 – The vent connector must be supported with hangers no more than three feet (1 m) apart to prevent movement after installation. All horizontal vent connector runs must have a slope up to the vertical vent of at least 1/4" per foot (1mm per 50mm).
- 7 – All vertical vents must be terminated with a listed vent cap or rain shield assembly unless local codes permit otherwise.
- 8 – The vent pipe must extend at least 3 feet (1m) above the highest point where it passes through a roof of a building and at least two feet higher than any part of a building within a horizontal distance of 10 feet (3.05 m) unless otherwise specified by the ANSI Z223.1 or CSA–B149 installation compliance codes. The vent must extend at least 5 feet (1.53 m) above the highest connected equipment flue collar.

HORIZONTAL VENTING

NOTE– Common venting is not allowed when horizontally venting the unit heater.

If the SEP unit heater is to be horizontally vented, a positive pressure may be created in the vent. The SEP unit heater, when installed with horizontal venting, may perform as a category III appliance. Use single–wall vent material installed according to this section or use listed special vent for Category III appliances. Refer to figures 3, 4, and 5. The minimum horizontal vent length is 5 feet (1.53 m). Refer to table 6 for the maximum horizontal vent length and the number of elbows permitted.

TABLE 6
MAXIMUM HORIZONTAL VENT LENGTHS

| No. of Elbows | SEP–100, –115, –145, –175, and –200 | | SEP–230, –250 and –300 | | SEP–345 | | SEP–400 | |
|---------------|-------------------------------------|-----|------------------------|------|---------|-----|---------|-----|
| | ft | m | ft | m | ft | m | ft | m |
| 1 | 25 | 7.6 | 35 | 10.7 | 31 | 9.4 | 21 | 6.4 |
| 2 | 20 | 6.1 | 30 | 9.1 | 22 | 6.7 | 12 | 3.6 |
| 3 | 15 | 4.6 | 25 | 7.6 | 13 | 4.0 | 3 | 0.9 |
| 4 | 10 | 3.0 | 20 | 6.1 | 4 | 1.2 | --- | --- |
| 5 | 5 | 1.5 | 15 | 4.6 | --- | --- | --- | --- |
| 6 | --- | --- | 10 | 3.0 | --- | --- | --- | --- |
| 7 | --- | --- | 5 | 1.5 | --- | --- | --- | --- |




FIGURE 2

- 1 – Select a wall termination point that will maintain 1/4" rise per foot slope of horizontal run of vent pipe. In areas where authorities having jurisdiction permit, a downward slope of maximum 1/4" per foot is also acceptable. In such cases, a single-wall vent pipe must be constructed of no. 24 GSG galvanized steel. Condensate drainage can be collected in a tee pipe section (figure 4) with drain loop similar to one used for upward slope vent, or allowed to drip through the vent termination, if permitted by authorities (figure 5).
- 2 – If possible, do not terminate the horizontal vent through a wall that is exposed to prevailing wind. Exposure to excessive winds can affect unit performance. If such a termination is necessary, use a wind block to protect the vent termination from direct winds.
- 3 – Vent termination must be at least 12" (30.5 cm) above grade level and maximum snow height.
- 4 – Do not terminate vent above a walkway, or any other area where condensate dripping may be

troublesome and may cause some staining. Avoid windows where steam may cause fogging or ice buildup.

- 5 – Horizontal vent termination must be a minimum distance from any door, window, gravity air inlet, or gas or electric meter. Refer to NFPA 54/ANSI Z223.1 or CSA-B149.
- 6 – Vent termination must be a minimum of 4 feet (1.2m) horizontally from any soffit or under-eave vent.
- 7 – Vent must be a minimum of 6 feet (1.83 m) from an inside corner formed by two exterior walls. If possible, leave a 10-foot clearance.
- 8 – Vent termination must be a minimum of 10 feet (3m) from any forced air inlet (includes fresh air inlet for other appliances, such as a dryer).
- 9 – For upward sloped vent, see figure 3, condensate tee and drain must be installed within the first 5 feet (1.53 m) from the unit heater to protect the appliance.
- 10 – Flexible loop trap in condensate line (if used) must be filled with water to prevent combustion products from entering structure.




FIGURE 3




FIGURE 4




FIGURE 5

- 11 – For horizontal venting, the vent pipe must be supported with hangers no more than 3 feet (1m) apart to prevent movement after installation.
- 12 – When termination is routed through an exterior combustible wall the vent must be supported using a listed clearance thimble. Where local authorities permit, a single section of type B-1 vent pipe may be used as an alternative to the thimble. When using a type B-1 vent termination use the clearances specified by the vent manufacturer. Seal the connection between the single-wall and double wall pipes and the annular space of the double wall pipe as shown in figure 2. Inside edge of vent termination

tee or elbow must be at least 12" (305mm) from outside wall.

- 13 – All horizontal vents must terminate with either tee or 90° elbow. Opening end must face downward. Addition of 1/4" (6mm) mesh corrosion resistant material as a bird screen is recommended.
- 14 – In Canada, vent termination must have a minimum 6-foot (2m) horizontal clearance from gas and electric meters and relief devices as specified in the CSA-B149 installation compliance codes. In the United States, vent termination must have a minimum 4 feet (1.2 m) horizontal clearance from gas and electric meters, regulators and relief equipment as specified in ANSI Z223.1.


Electrical Connections

The SEP series unit heaters use a direct spark ignition system. There is no pilot necessary as the spark lights the main burner as the gas valve is turned on. The direct spark ignition control board emits radio noise as the sparking process is under way. The level of energy may be sufficient to disturb a logic circuit in a microprocessor controlled thermostat. It is recommended that an isolation relay be used when connecting the SEP series unit heaters to a microprocessor-controlled thermostat. Install the thermostat according to instructions provided by the manufacturer. Install a separate fused disconnect switch, fused according to blower motor size. Connect wiring through knockout on the junction box located on the side

of the unit heater. Refer to heater wiring diagram for connection information. Use 18 gauge wire or larger for thermostat connections.

NOTE – Electrically ground unit in accordance with local codes or, in the absence of local codes, in accordance with the current National Electrical Code (ANSI/NFPA No. 70) in the U.S.A., and in Canada with the current Canadian Electrical Code, Part 1 (CSA C22.1).

NOTE – Uninsulated ground wires must be wrapped in electrical tape to avoid damage to the electrical system. Connect field wiring as shown on wiring diagram on unit. Also refer to typical diagram in this manual. An additional thermostat wire must be run to terminal “G” on heater when continuous blower is desired.



Gas Connection

When connecting gas supply, the length of the run from the meter must be considered in determining the pipe size to avoid excessive pressure drop. A line pressure of 7" w.c. (178 mm w.c.) for natural gas should be maintained when sizing piping. For correct sizing of piping, consult the utility having jurisdiction.

A drip leg should be installed in the vertical pipe run to the unit. In some localities, codes may require that a manual main shutoff valve and union (furnished by installer) be installed external to the unit. Union must be of the ground joint type. See figure 6.

A 1/8" NPT plugged tap must be installed immediately upstream of the gas supply connection to the heater.

NOTE – Compounds used on threaded joints of gas piping must be resistant to the actions of liquefied petroleum gases.




FIGURE 6

Leak Check

After gas piping is completed, carefully check all piping connections, (field and factory), for gas leaks. Use a soap solution or other preferred means.

⚠ CAUTION

DO NOT use matches, candles, flame or other sources of ignition to check for gas leaks.

⚠ IMPORTANT

The appliance must be isolated from the gas supply piping system by closing its individual manual gas shutoff valve during any pressure testing of the gas supply system at test pressures equal to or less than 1/2 psig (3.45kPa). See figure 7.

The appliance must be isolated from the gas supply piping system by closing its individual manual gas shutoff valve during any pressure testing of the gas supply system at test pressures equal to or less than 1/2 psig (3.45 kPa). See figure 7.

NOTE – In case emergency shutdown is required, shut down main gas valve and disconnect main power to unit. These devices should be properly labeled by the installer.




FIGURE 7

Unit Start-Up

FOR YOUR SAFETY READ BEFORE LIGHTING

⚠ WARNING



Electric shock hazard. Can cause injury or death. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the furnace and to replace any part of the control system and any gas control which has been under water.

⚠ WARNING



Danger of explosion. Can cause injury or product or property damage. If overheating occurs or if gas supply fails to shut off, shut off the manual gas valve to the appliance before shutting off electrical supply.

⚠ WARNING



Electric shock hazard. Can cause injury or death. Before attempting to perform any service or maintenance, turn the electrical power to unit OFF at disconnect switch(es). Unit may have multiple power supplies.

⚠ WARNING



Danger of explosion and fire. Can cause injury or product or property damage. You must follow these instructions exactly.

BEFORE LIGHTING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, do not try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.

SEP unit heaters are equipped with an automatic spark ignition system. There is no pilot. In case of a safety shutdown, move thermostat switch to OFF, then return the thermostat switch to HEAT position.

GAS VALVE OPERATION FOR HONEYWELL VR8205/VR8305 SERIES GAS VALVE (FIGURE 8)

- 1 – STOP! Read the safety information at the beginning of this section.
- 2 – Set thermostat to lowest setting.
- 3 – Turn off all electrical power to appliance.
- 4 – This appliance is equipped with an ignition device which automatically lights burners. DO NOT attempt to light the burners manually.
- 5 – Turn the manual knob on gas valve clockwise to OFF. Do not force.

- 6 – Wait five minutes to clear out any gas. If you then smell gas, STOP! Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. If you do not smell gas, go to next step.
- 7 – Turn manual knob on gas valve counterclockwise to ON.
- 8 – Turn on all electric power to unit.
- 9 – Set thermostat to desired setting.
- 10 – The combustion air inducer will start. The burners will light within 40 seconds.
- 11 – If unit does not light first time (gas line not fully purged) it will attempt up to two more ignitions before locking out.
- 12 – If lockout occurs, repeat steps 1 through 8.
- 13 – If appliance still will not operate, follow the instructions "To Turn Off Gas to Unit " and call your service technician or gas supplier.




FIGURE 8

**GAS VALVE OPERATION FOR WHITE RODGERS
36E SERIES VALVE (FIGURE 9)**

- 1 – Set thermostat to lowest setting.
- 2 – Turn off all electrical power to appliance.
- 3 – This appliance is equipped with an ignition device which automatically lights burner. DO NOT attempt to light the burners manually.




FIGURE 9

- 4 – Turn knob on gas valve 180° either way to OFF.
- 5 – Wait five minutes to clear out any gas. If you then smell gas, STOP! Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions. If you do not smell gas go to next step.
- 6 – Turn knob on gas valve 180° either way to ON.
- 7 – Turn on electrical power to unit.
- 8 – Set thermostat to desired setting.
- 9 – The combustion air inducer will start. The burners will light within 40 seconds.
- 10 – If unit does not light on the first attempt (gas line not fully purged), the unit will attempt up to two more ignitions before locking out.
- 11 – If lockout occurs, repeat steps 1 through 8.
- 12 – If appliance still will not operate, follow the instructions "To Turn Off Gas to Unit " and call your service technician or gas supplier.

**GAS VALVE OPERATION FOR WHITE RODGERS
36C SERIES VALVE (FIGURE 10)**

- 1 – STOP! Read the safety information at the beginning of this section.

- 2 – Set thermostat to the lowest setting.
- 3 – Turn off all electrical power to appliance.
- 4 – This appliance is equipped with an ignition device which automatically lights burner. DO NOT attempt to light the burners manually.










FIGURE 10

- 5 – Turn knob on gas valve(s) clockwise  until it stops. Push knob and turn clockwise  to OFF.
- 6 – Wait five minutes to clear out any gas. If you then smell gas, STOP! Immediately call your gas supplier from your neighbor's phone. Follow the gas supplier's instructions. If you don't smell gas go to next step.
- 7 – Turn knob on gas valve counterclockwise  until it stops. Allow knob to pop up and continue counterclockwise to ON position.
- 8 – Turn on electrical power to unit.
- 9 – Set thermostat to desired setting.
- 10 – The combustion air inducer(s) will start. The burners will light within 40 seconds.
- 11 – If unit does not light on the first attempt (gas line not fully purged), the unit will attempt up to two more ignitions before locking out.
- 12 – If lockout occurs, repeat steps 1 through 8.
- 13 – If the appliance will not operate, follow the instructions "To Turn Off Gas To Unit " and call your service technician or gas supplier.

To Turn Off Gas to Unit

- 1 – Set thermostat to lowest level.
- 2 – Turn off all electrical power to unit if service is to be performed.
- 3 – Use one of the following applicable procedures to turn off gas to a unit:
 - * Honeywell VR8205 and VR8305 series valves: turn knob on gas valve 90° clockwise  to OFF.
 - * White Rodgers 36C series valves: turn knob on gas valve clockwise  until it stops. Push knob and turn clockwise  to OFF.
 - * White Rodgers 36E series valves : turn knob on gas valve 180° either way to OFF .

Heating Sequence of Operation

- 1 – When the thermostat calls for heat, the combustion air inducer starts immediately.
- 2 – Combustion air pressure switch proves inducer operation before allowing power to the ignition controller. This switch is factory–set and no adjustment is necessary.
- 3 – After prepurge of approximately 30 seconds, the spark ignition is energized and the solenoid valves open in the gas valve. SEP models 230, 250, 300, 345 and 400 are equipped with a step opening valve. During ignition phase of start–up a pressure of approximately 25% of full rate allows even ignition of all burners for several seconds before full rate pressure is established.
- 4 – The spark then ignites the gas, the ignition sensor proves the flame and the combustion process continues.
- 5 – In the event that the flame is not detected after the first 10–second trial for ignition, the controller will repeat steps 3 and 4 an additional two times before locking out the gas valve. Ignition control will then automatically repeat steps 3, 4, and 5 after 60 minutes.

NOTE: To interrupt the 60–minute lockout period, move thermostat from “Heat” to “OFF” then back to “Heat.” Heating sequence then restarts at step 1.

- 6 – The burners must light without noticeable crossover delay. There must be no flame lifting from the burner heads, flashback or burning within the burner. The flames must be predominantly blue in color and must be approximately centered in the tubes with no apparent impingement taking place.
- 7 – The ignition control will energize the fan(s) approximately 45 seconds after ignition is established.

- 8 – After the thermostat demand is satisfied, the gas valve is closed; five seconds after the demand is satisfied, the combustion air inducer is shut off.
- 9 – The ignition control must shut off the system fan approximately 150 seconds after the gas valve is de-energized.

Ignition Control LED

The ignition control board contains a green LED which indicates the following:

TABLE 7
IGNITION CONTROL LED

| LED | UNIT OPERATION |
|-------------|---|
| Slow Flash* | Normal Operation – No call for heat |
| Fast Flash | Normal Operation – Call for heat |
| 2 Flashes | System lockout – failed to detect or sustain flame |
| 3 Flashes | Pressure switch failed closed before CAI is energized or failed open after CAI is energized |
| 4 Flashes | High limit or rollout switch open |
| 5 Flashes | Flame sensed and gas valve not energized |
| Steady Off | Loss of power |
| Steady On | Ignition control failure |

*When thermostat is placed in continuous fan mode, LED will slowly flash.

High Altitude Adjustment

In Canada, certification for installation at altitudes over 4500 feet (1372m) above sea level is the jurisdiction of the local authorities.

Unit may be fired at full input up to 2000 feet (610m) above sea level. Above 2000 feet (610m), manifold pressure must be adjusted on some units. Adjust pressure regulator to pressure shown in table 8 for natural gas and table 9 for LP/propane gas.

NOTE – A natural to LP/propane gas changeover kit is required to convert the unit in the field. Refer to the installation instructions supplied with the changeover kit for conversion procedure.

If unit is installed at an altitude greater than 7500 feet (2286m), unit must be derated by four percent for each additional 1000 feet (305m) above 7500 feet (2286m).

The combustion air inducer proving switch is factory set and no adjustment is necessary.

TABLE 8
NATURAL GAS MANIFOLD PRESSURES – in. w.g. (kPa)

| SEP UNIT | ALTITUDE – FEET (METERS) | | | | | | |
|--|--------------------------|-------------------------|-------------------------|----------------------------|----------------------------|----------------------------|----------------------------|
| | 0–2000 (0–610) | 2000– 2500 (610–762) | 2500–3500 (762–1067) | 3500 – 4500 (1067–1372) | 4500 – 5500 (1372–1676) | 5500 – 6500 (1676–1981) | 6500 – 7500 (1981–2286) |
| SEP–100 SEP–115 SEP–300 | 3.5 (0.87) | 3.5 (0.87) | 3.5 (0.87) | 3.5 (0.87) | 3.4 (0.84) | 3.3 (0.82) | 3.2 (0.79) |
| SEP–145 | 3.5 (0.87) | 3.4 (0.84) | 3.3 (0.82) | 3.2 (0.79) | 3.1 (0.77) | 3.0 (0.74) | 2.9 (0.72) |
| SEP–175* SEP–230 | 3.5 (0.87) | 3.5 (0.87) | 3.5 (0.87) | 3.5 (0.87)* | 3.5 (0.87)* | 3.5 (0.87)* | 3.5 (0.87)* |
| SEP–200 SEP–250 SEP–345 SEP–400 | 3.5 (0.87) | 3.5 (0.87) | 3.5 (0.87) | 3.4 (0.84) | 3.3 (0.82) | 3.2 (0.79) | 3.1 (0.77) |

* The SEP–175 unit requires kit 10K73 when installed at elevations above 2500 feet (762m) to 7500feet (2286m). No adjustment to switch is required.

TABLE 9
LP/PROPANE GAS MANIFOLD PRESSURES – in. w.g. (kPa)

| SEP UNIT | ALTITUDE – FEET (METERS) | | | | | | |
|-------------------------------|--------------------------|-------------------------|-------------------------|----------------------------|----------------------------|----------------------------|----------------------------|
| | 0–2000 (0–610) | 2000– 2500 (610–762) | 2500–3500 (762–1067) | 3500 – 4500 (1067–1372) | 4500 – 5500 (1372–1676) | 5500 – 6500 (1676–1981) | 6500 – 7500 (1981–2286) |
| SEP–100 SEP–115 SEP–300 | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 8.7 (2.16) | 8.4 (2.09) | 8.1 (2.01) |
| SEP–145 | 9.0 (2.24) | 8.7 (2.16) | 8.4 (2.09) | 8.1 (2.01) | 7.8 (1.94) | 7.5 (1.86) | 7.2 (1.79) |
| SEP–175* SEP–230 | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) |
| SEP–250 | 9.0 (2.24) | 9.0 (2.24) | 9.0 (2.24) | 8.7 (2.16) | 8.4 (2.08) | 8.1 (2.01) | 7.8 (1.94) |
| SEP–200 SEP–345 SEP–400 | 9.5 (2.37) | 9.5 (2.37) | 9.5 (2.37) | 9.2 (2.28) | 8.9 (2.21) | 8.6 (2.13) | 8.3 (2.06) |

* The SEP–175 unit requires kit 10K73 when installed at elevations above 2500 feet (762m) to 7500 feet (2286m). No adjustment to switch is required.

Gas Flow

To check for proper gas flow to the combustion chamber, determine the Btu input from the appliance rating plate. Divide this input rating by the Btu per cubic feet of available gas. Result is the required number of cubic feet per hour. Determine the flow of gas through the gas meter for two minutes and multiply by 30 to get the hourly flow of gas.

Gas Pressure Adjustment

- 1 – Check gas line pressure with unit firing at maximum rate. A minimum of 5" (127mm) w.c. for natural gas or 11" (279mm) w.c. for LP/propane gas should be maintained for proper unit operation.
- 2 – After line pressure has been checked and adjusted, check regulator pressure. Adjust manifold pressure to values specified on the unit rating plate. See figures 8, 9, and 10 for gas pressure adjustment screw location. A natural gas to LP/propane gas changeover kit is required to convert unit in the field. Refer to installation instructions provided with changeover kit for conversion procedure.

Limit Control Switch

The limit control switch(es) are factory set and are not field adjustable.

Louver Vane Adjustment

The SEP series unit heaters are provided with adjustable louver vanes. Air flow from the unit can be directed down, straight, out, up, or any combination of these.

WARNING



DO NOT CLOSE the bottom three louvers on SEP. Premature failure to the heat exchanger can occur.

Combustion Air Pressure Switch

This pressure switch checks for proper combustion air inducer operation before allowing an ignition trial. The switch is factory-set; no field adjustment is necessary.

Service

CAUTION

Turn off gas and electrical power to unit before performing any maintenance or service operations on this unit. Remember to follow lighting instructions when putting unit back into operation after service or maintenance.

LUBRICATION

- 1 – Combustion air inducer motor bearings are pre-lubricated and sealed. No further lubrication is necessary.
- 2 – Fan motor bearings should be lubricated according to manufacturer's instructions on each motor. If no instruction is provided, use the following as a guide: motors with oiling ports are pre-lubricated for an extended bearing life, re-lubricate with a few drops of SAE No. 10 non-detergent oil once every two years.

BURNERS

- 1 – Periodically examine burner flames for proper appearance during the heating season.
- 2 – Before each heating season examine the burners for any deposits or blockage that may have occurred.
- 3 – Clean burners as follows:
 - a – Turn off both electrical and gas supplies to unit.
 - b – Disconnect gas supply piping, high tension and sensor leads. Remove gas manifold. Remove burner tray.
 - c – Clean burners as necessary. Make sure that burner heads line up properly to ensure flame crossover. Check spark gap on electrode and adjust if required. The gap should be between 0.110" and 0.140" (2.8 mm to 3.6 mm). The gap may be checked with appropriately sized twist drills or feeler gauges.
 - d – Reinstall burner tray, gas manifold, high tension and sensor leads. Reconnect gas supply piping.
 - e – Restore electrical power and gas supply. Follow lighting instructions to light unit. Check burner flame.

FLUE PASSAGEWAY AND FLUE BOX

The flue passages and flue box should be inspected and cleaned prior to each heating season. The sequence of operation should be as follows:

- 1 – Turn off both electrical and gas supply to unit.
- 2 – Disconnect combustion air inducer wiring.
- 3 – Remove screws securing flue box to unit. Remove flue box. If necessary, remove blower assembly from flue box. Clean flue box with wire brush.
- 4 – Remove baffle retention bracket and flue baffles. Clean flue baffles with wire brush.
- 5 - Remove burners as described in “Burners” section.
- 6 – Clean tubes with a wire brush.
- 7 – Reassemble unit. The combustion air and flue box gaskets should also be replaced during reassembly.
- 8 – Restore electrical power and gas supply. Follow lighting instructions to light unit. Check operation of unit.

COMBUSTION AIR INDUCER

Under normal operating conditions, the combustion air inducer should be checked and cleaned prior to the heating season with the power supply disconnected. Use a small brush to clean inducer wheel.

ELECTRICAL

- 1 – Check all wiring for loose connections.
- 2 – Check for correct voltage at unit (unit operating).
- 3 – Check amperage draw.

FLUE AND CHIMNEY

Check all vent and vent connector joints for tightness. Ensure that connections are sealed and that there are no blockages.

FAILURE TO OPERATE

If unit fails to operate check the following:

- 1 – Is thermostat calling for heat?
- 2 – Is main disconnect closed?
- 3 – Is there a breaker tripped or a fuse blown?
- 4 – Is gas turned on at meter?
- 5 – Is manual shutoff valve open?
- 6 – Is unit ignition system in lock out? If unit locks out again, call service technician to inspect unit.
- 7 – Is pressure switch closed? Obstructed flue will cause unit to shut off at pressure switch. Check flue passage and outlet.

REPAIR PARTS

When ordering repair parts include the complete unit model number listed on the unit rating plate.

SAFETY SHUT-OFF VALVE TEST

The safety shut-off valve test procedure is as follows:

- 1 – Turn off the manual gas valve.
- 2 – Set the thermostat to call for heat.
- 3 – System begins normal sequence of operation.
- 4 – After approximately 30 seconds (pre purge period) the LED will fast flash indicating the gas valve is powered.
- 5 – After 10 seconds, the gas valve closes and steps 4 and 5 will repeat two additional times before locking out the gas valve, which will be indicated by two flashes on the LED.
- 6 – To restart the system, de-energize the thermostat call for heat and follow the operating instructions under “Unit Start-Up”.

START-UP AND PERFORMANCE CHECKLIST

| | | |
|---|--|---------------------------|
| Job Name: _____ | Job No.: _____ | Date: _____ |
| Job Location: _____ | City: _____ | State/Province: _____ |
| Installer: _____ | City: _____ | State/Province: _____ |
| Unit Model No.: _____ | Serial No.: _____ | Service Technician: _____ |
| Electrical Connections Tight? _____ | Air Shutters Properly Adjusted (If Installed)? _____ | |
| Supply Voltage _____ | Flue Connections Tight? _____ | |
| Blower Motor Lubrication O.K.? _____ | Fan Timer Operation Checked? _____ | |
| Gas Piping Connections Tight & Leak-Tested? _____ | THERMOSTAT | |
| Blower Motor Amps _____ | Calibrated? _____ | |
| Furnace Btu Input _____ | Heat Anticipator Properly Set? _____ | |
| Line Pressure _____ | Level? _____ | |
| Manifold Pressure _____ w.c. | | |



Unit Heater Limited Warranty – Standard 2 Year

(Applies only to product installed within the United States or Canada)

Term of Standard Warranty: Advanced Distributor Products (ADP) warrants that products sold shall be of merchantable quality, free of defects in material and workmanship, under normal use and service, for a period of two (2) years from the date of installation, **not** to exceed three (3) years from the date of manufacture.

Extended Components: This warranty provides extended coverage on Aluminized Heat Exchangers for **ten (10) years** and Stainless Steel Heat Exchangers for **fifteen (15) years**. The extended warranty coverage begins with the installation date and represents the total warranty period for the specific component. ADP, at its option, will furnish a replacement heat exchanger or allow a credit (in the amount of the heat exchanger original selling price) toward the purchase of a new ADP unit heater. **No extended coverage** granted for **HED series** heat exchangers.

Warranty Procedure: Warranty parts should be replaced by a qualified local contractor or dealer and will require the following information: model number, serial number, date of installation and an accurate description of the problem. Contractor or dealer will contact a local ADP distributor for replacement parts.

Replacement Parts: If, during the term of this warranty, a warranted part fails, ADP will either provide a replacement part free of charge, or may at its option, grant a credit for the original purchase price of the defective article to a distributor of ADP products. ADP may require the return of a defective article for factory inspection to verify and/or determine the root cause of the failure. Covered components include all parts of this unit except for the following **excluded components**, which are not covered by this warranty: cabinet, cabinet pieces, wiring and wiring harnesses.

Care of Equipment: For this warranty to apply, ADP product must be properly installed, operated, and maintained in accordance with the installation, operation and maintenance instructions provided with each unit. Unauthorized alteration of ADP product may void this warranty.

Conditions of Warranty: Replacement parts furnished under this warranty will be warranted for the balance of the original warranty term of the unit (including any extended warranty) and will not serve to extend the original term. This warranty is void if the ADP product is removed from the original installation site. This warranty does not apply to damage caused by shipping, misuse, mishandling or damage caused by floods, winds, fires, lightning, or exposure to corrosive elements/environments (such as salt, chlorine, fluorine or other damaging chemicals).


Limitations of Warranty: The costs of miscellaneous material and labor charges for diagnostics, servicing or replacing parts are not covered. ADP shall have no liability for expenses incurred for repairs without prior, written authorization from ADP. No purchaser, distributor, dealer, representative, agent, person, firm or corporation has authority to alter, add to or modify this warranty, either orally or in writing.

No Other Warranties: ADP makes no warranty, express or implied, of fitness for any particular purpose, or of any other nature whatsoever, with respect to products manufactured or sold by ADP hereunder, except as specifically set forth above and on the face hereof. Any implied warranty of merchantability or fitness for a particular purpose on this product is limited in duration to the duration of this warranty. Some states and provinces do not allow limitations on how an implied warranty lasts, so the above limitation may not apply to you. It is expressly understood and agreed that ADP shall not be liable to buyer, or any customer of buyer, for direct or indirect, special, incidental, consequential or penal damages, or for any expenses incurred by reason of the use or misuse by buyer or third parties of said products. To the extent said products may be considered "consumer products", as defined in Sec. 101 of the Magnuson-Moss Warranty-Federal Trade Commission Improvement Act, ADP makes no warranty of any kind, express or implied, to "consumers," except as specifically set forth above on the face hereof. The foregoing is in lieu of all other warranties, express or implied, notwithstanding the provisions of the Uniform Commercial Code, the Magnuson-Moss Warranty-Federal Trade Commission Improvement Act, or any other statutory or common law, federal or state.

2175 West Park Place Boulevard
Stone Mountain, Georgia 30087

REV 090908

TEMPLATE
Location of Combustion Air Inducer Mounting Holes for
Rotated Inducer





Advanced Distributor Products[®]

Solutions for Your needs

2175 West Park place blvd.
Stone Mountain, GA. 30087
www.adpnow.com
adp.feedback@adpnow.com