

## High Altitude Water Heater Installation Procedure

The purpose of the high altitude technical bulletins is to provide installation instructions to ensure proper operation of Rinnai water heaters at altitudes above sea level. Instruction sheets are based on model and gas type and explain any adjustments or vent length limits. The installation manuals will contain the following statement, "For high altitude installations contact Rinnai at 1-800-621-9419." Upon request, Rinnai Technical Services or Engineering will fax or email the appropriate instruction sheet (technical bulletin) to the installer.

The table below summarizes the procedures in the instruction sheets.

	Natural Gas		Propane	
<b>3237W</b>	Manifold pressure adjustment above 2000 ‘	TB-3	Manifold pressure adjustment above 2000 ‘	TB-4
<b>3237FFU</b>	Manifold pressure adjustment above 2000 ‘ Vent length limited above 5000 ‘	TB-5	Manifold pressure adjustment above 2000 ‘ <b>Not</b> recommended above 5000 ‘	TB-6
<b>2532W</b>	No additional action required up to 10000 ‘	N/A	Manifold pressure adjustment above 2000 ‘	TB-7
<b>2532FFU</b>	Vent length limit above 5000 ‘	TB-8	Manifold pressure adjustment above 2000 ‘ Vent length limit above 5000 ‘	TB-9
<b>2520FFU</b>	Vent length limit above 5000 ‘	TB-10	Manifold pressure adjustment above 2000 ‘	TB-11
<b>2020W</b>	Manifold pressure adjustment above 2000 ‘	TB-12	<b>Not</b> recommended above 2000 ‘ No additional action required below 2000’	N/A
<b>1616W</b>	Manifold pressure adjustment above 5000 ‘	TB-13	Manifold pressure adjustment above 2000 <b>Not</b> recommended above 5000 ‘	TB-14